



Product End-of-Life Disassembly Instructions

Product Category: Networking Equipment

Marketing Name / Model

[List multiple models if applicable.]

ProCurve Switch xl Access Controller Module (J8162A)

ProCurve Wireless Edge Services xl Module (J9001A)

ProCurve Redundant Wireless Service xl Module (J9003A)

Purpose: The document is intended for use by end-of-life recyclers or treatment facilities. It provides the basic instructions for the disassembly of HP products to remove components and materials requiring selective treatment, as defined by EU directive 2002/96/EC, Waste Electrical and Electronic Equipment (WEEE).

1.0 Items Requiring Selective Treatment

1.1 Items listed below are classified as requiring selective treatment.

1.2 Enter the quantity of items contained within the product which require selective treatment in the right column, as applicable.

Item Description	Notes	Quantity of items included in product
Printed Circuit Boards (PCB) or Printed Circuit Assemblies (PCA)	With a surface greater than 10 sq cm 1 on module	2
Batteries	All types including standard alkaline and lithium coin or button style batteries	1
Mercury-containing components	For example, mercury in lamps, display backlights, scanner lamps, switches, batteries	0
Liquid Crystal Displays (LCD) with a surface greater than 100 sq cm	Includes background illuminated displays with gas discharge lamps	0
Cathode Ray Tubes (CRT)		0
Capacitors / condensers (Containing PCB/PCT)		0
Electrolytic Capacitors / Condensers measuring greater than 2.5 cm in diameter or height		0
External electrical cables and cords		0
Gas Discharge Lamps		0
Plastics containing Brominated Flame Retardants		0
Components and parts containing toner and ink, including liquids, semi-liquids (gel/paste) and toner	Include the cartridges, print heads, tubes, vent chambers, and service stations.	0
Components and waste containing asbestos		0
Components, parts and materials containing refractory ceramic fibers		0
Components, parts and materials containing radioactive substances		0

2.0 Tools Required

List the type and size of the tools that would typically be used to disassemble the product to a point where components and materials requiring selective treatment can be removed.

Tool Description	Tool Size (if applicable)
Torx driver	T-10
Nut Driver	3/16"

3.0 Product Disassembly Process

3.1 List the basic steps that should typically be followed to remove components and materials requiring selective treatment:

1. Remove metal bulkhead by removing the screws securing the bulkhead onto the PCA and by pulling the bulkhead away from the PCA.
2. Remove the two screws and springs on both sides of the bulkhead
3. Remove the button style battery from the small PCA
4. Remove the small PCA by pulling it away from the main PCA
5. Remove any Flash on the small PCA by pulling it away from the PCA
6. Remove the Dimm from the big PCA by pressing the catch at both side of the DIMM
7. There's 2 heatsinks (one with screws and the other have no screws on it), unscrew the screws on the heatsink and remove it by pulling it away from the PCA. For the heatsink without screw on it, release catch on the heatsink by pressing the wire catch. Remove the heatsink by pulling it away from the PCA
- 8.
- 9.
- 10.

3.2 Optional Graphic. If the disassembly process is complex, insert a graphic illustration below to identify the items contained in the product that require selective treatment (with descriptions and arrows identifying locations).

