

# **Product end-of-life disassembly instructions**

## Product end-of-life disassembly instructions

Product category: Networking

Marketing Name / Model [List multiple models if applicable.]

AP-515 AP-515, Aruba, XGP

AP-515 OAW-AP515, Alcatel

**Purpose:** The document is intended for use by end-of-life recyclers or treatment facilities. It provides the basic instructions for the disassembly of HPE products to remove components and materials requiring selective treatment, as defined by EU directive 2002/96/EC, Waste Electrical and Electronic Equipment (WEEE).

### 1.0 Items Requiring Selective Treatment

- 1.1 Items listed below are classified as requiring selective treatment.
- 1.2 Enter the quantity of items contained within the product which require selective treatment in the right column, as applicable.

Item Description	Notes	Quantity of items included in product
Printed Circuit Boards (PCB) or Printed Circuit Assemblies (PCA)	With a surface greater than 10 sq cm	1
Batteries	All types including standard alkaline and lithium coin or button style batteries	0
Mercury-containing components	For example, mercury in lamps, display backlights, scanner lamps, switches, batteries	0
Liquid Crystal Displays (LCD) with a surface greater than 100 sq cm	Includes background illuminated displays with gas discharge lamps	0
Cathode Ray Tubes (CRT)		0
Capacitors / condensers (Containing PCB/PCT)		0
Electrolytic Capacitors / Condensers measuring greater than 2.5 cm in diameter or height		0
External electrical cables and cords		0
Gas Discharge Lamps		0
Plastics containing Brominated Flame Retardants weighing > 25 grams (not including PCBs or PCAs already listed as a separate item above)		0
Components and parts containing toner and ink, including liquids, semi-liquids (gel/paste) and toner	Include the cartridges, print heads, tubes, vent chambers, and service stations.	0
Components and waste containing asbestos		0
Components, parts and materials containing refractory ceramic fibers		0
Components, parts and materials containing radioactive substances		0

## 2.0 Tools required

List the type and size of the tools that would typically be used to disassemble the product to a point where components and materials requiring selective treatment can be removed.

Tool Description	Tool Size (if applicable)
Description #1 Torx screwdriver	T9
Description #2 Static electric tweezers	NA
Description #3 Phillips screwdriver	PH2

## 3.0 Product Disassembly Process

3.1 List the basic steps that should typically be followed to remove components and materials requiring selective treatment:


- a. Use Phillips screwdriver to remove the 2 screws on the MNT bracket.
- b. Use T9 screwdriver to remove the 4 screws on the chassis.
- c. Remove the top cover, use static electric tweezers to remove the antenna from the PCBA.
- d. Use PH2 Phillips screwdriver to remove 4 screws on the antenna cover plate.
- e. Remove the antenna cover plate, use PH2 Phillips screwdriver to remove 3 screws on the LED guide beam and PCBA.
- f. Remove the PCBA and LED guide beam from the chassis.

3.2 Optional Graphic. If the disassembly process is complex, insert a graphic illustration below to identify the items contained in the product that require selective treatment (with descriptions and arrows identifying locations).

1. Use Phillips screwdriver to remove the 2 screws on the MNT bracket and remove it. Use T9 screwdriver to remove the 4 screws on the chassis.



2. Remove the top cover, use static electric tweezers to remove the antenna from the PCBA.



3. Use PH2 Phillips screwdriver to remove 4 screws on the antenna cover plate.



4. Remove the antenna cover plate, use PH2 Phillips screwdriver to remove 3 screws on the LED guide beam and PCBA.



5. Remove the PCBA and LED guide beam from the chassis.



[Visit HPE.com](https://www.hpe.com)

[Chat now](#)

© Copyright 2025 Hewlett Packard Enterprise Development LP. The information contained herein is subject to change without notice. The only warranties Hewlett Packard Enterprise products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. Hewlett Packard Enterprise shall not be liable for technical or editorial errors or omissions contained herein.

a00067344ENW, Rev. 1

HEWLETT PACKARD ENTERPRISE

[hpe.com](https://www.hpe.com)

