



Hewlett Packard
Enterprise

HPE FlexNetwork 5130 HI Switch Series

ACL and QoS

Command Reference

Part number: 5200-3614
Software version: Release 13xx
Document version: 6W100-20170315

© Copyright 2015, 2017 Hewlett Packard Enterprise Development LP

The information contained herein is subject to change without notice. The only warranties for Hewlett Packard Enterprise products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. Hewlett Packard Enterprise shall not be liable for technical or editorial errors or omissions contained herein.

Confidential computer software. Valid license from Hewlett Packard Enterprise required for possession, use, or copying. Consistent with FAR 12.211 and 12.212, Commercial Computer Software, Computer Software Documentation, and Technical Data for Commercial Items are licensed to the U.S. Government under vendor's standard commercial license.

Links to third-party websites take you outside the Hewlett Packard Enterprise website. Hewlett Packard Enterprise has no control over and is not responsible for information outside the Hewlett Packard Enterprise website.

Acknowledgments

Intel®, Itanium®, Pentium®, Intel Inside®, and the Intel Inside logo are trademarks of Intel Corporation in the United States and other countries.

Microsoft® and Windows® are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

Adobe® and Acrobat® are trademarks of Adobe Systems Incorporated.

Java and Oracle are registered trademarks of Oracle and/or its affiliates.

UNIX® is a registered trademark of The Open Group.

Contents

ACL commands	1
acl	1
acl copy	3
acl logging interval	4
acl trap interval	4
description	5
display acl	6
display packet-filter	7
display packet-filter statistics	8
display packet-filter statistics sum	11
display packet-filter verbose	12
display qos-acl resource	14
packet-filter	15
packet-filter default deny	16
packet-filter filter	17
reset acl counter	17
reset packet-filter statistics	18
rule (IPv4 advanced ACL view)	19
rule (IPv4 basic ACL view)	23
rule (IPv6 advanced ACL view)	24
rule (IPv6 basic ACL view)	29
rule (Layer 2 ACL view)	31
rule comment	32
step	33
QoS policy commands	35
Traffic class commands	35
display traffic classifier	35
if-match	36
traffic classifier	40
Traffic behavior commands	41
accounting	41
car	42
display traffic behavior	43
filter	45
nest top-most	45
redirect	46
remark customer-vlan-id	47
remark dot1p	47
remark drop-precedence	48
remark dscp	49
remark ip-precedence	50
remark local-precedence	51
remark qos-local-id	51
remark service-vlan-id	52
traffic behavior	52
QoS policy commands	53
classifier behavior	53
control-plane	54
display qos policy	54
display qos policy control-plane	55
display qos policy control-plane pre-defined	57
display qos policy global	58
display qos policy interface	59
display qos policy user-profile	62
display qos vlan-policy	64
qos apply policy (interface view, control plane view)	65

qos apply policy (user profile view).....	66
qos apply policy global	67
qos policy	67
qos vlan-policy.....	68
reset qos policy control-plane.....	69
reset qos policy global.....	69
reset qos vlan-policy	70
Priority mapping commands	71
Priority map commands.....	71
display qos map-table	71
import	72
qos map-table.....	72
Priority trust mode commands	73
display qos trust interface.....	73
qos trust	74
Port priority commands	74
qos priority.....	74
GTS and rate limit commands.....	76
GTS commands	76
display qos gts interface	76
qos gts	77
Rate limit commands	78
display qos lr interface.....	78
qos lr	79
Congestion management commands	80
Common commands.....	80
display qos queue interface	80
SP commands.....	81
display qos queue sp interface	81
qos sp.....	81
WRR commands.....	82
display qos queue wrr interface	82
qos wrr.....	83
qos wrr { byte-count weight }	84
qos wrr group sp	85
WFQ commands.....	86
display qos queue wfq interface.....	86
qos bandwidth queue	87
qos wfq	87
qos wfq { byte-count weight }.....	88
qos wfq group sp.....	89
Queue scheduling profile commands.....	90
bandwidth queue.....	90
display qos qmprofile configuration	90
display qos qmprofile interface	92
qos apply qmprofile.....	92
qos qmprofile.....	93
queue	94
Queue-based accounting commands	95
display qos queue-statistics interface outbound	95
Congestion avoidance commands	97
WRED commands.....	97
display qos wred interface	97
display qos wred table	97
qos wred apply	98
qos wred queue table	99
queue	100
queue ecn.....	101

queue weighting-constant	101
Global CAR commands	103
car name	103
display qos car name	104
qos car	105
reset qos car name	106
Data buffer commands	108
buffer apply	108
buffer queue guaranteed	108
buffer queue shared	109
buffer total-shared	110
burst-mode enable	111
display buffer	111
display buffer usage	112
Time range commands	115
display time-range	115
time-range	115
Document conventions and icons	118
Conventions	118
Network topology icons	119
Support and other resources	120
Accessing Hewlett Packard Enterprise Support	120
Accessing updates	120
Websites	121
Customer self repair	121
Remote support	121
Documentation feedback	121
Index	123

ACL commands

acl

Use **acl** to create an ACL and enter its view, or enter the view of an existing ACL.

Use **undo acl** to delete the specified or all ACLs.

Syntax

```
acl [ ipv6 ] { advanced | basic } { acl-number | name acl-name } [ match-order { auto | config } ]
```

```
acl mac { acl-number | name acl-name } [ match-order { auto | config } ]
```

```
acl [ ipv6 ] number acl-number [ match-order { auto | config } ]
```

```
undo acl [ ipv6 ] { all | { advanced | basic } { acl-number | name acl-name } }
```

```
undo acl mac { all | acl-number | name acl-name }
```

```
undo acl [ ipv6 ] number acl-number
```

Default

No ACLs exist.

Views

System view

Predefined user roles

network-admin

Parameters

ipv6: Specifies the IPv6 ACL type. To specify the IPv4 ACL type, do not use this keyword.

basic: Specifies the basic ACL type.

advanced: Specifies the advanced ACL type.

mac: Specifies the Layer 2 ACL type.

number *acl-number*: Assigns a number to the ACL. The following are available value ranges:

- 2000 to 2999 for basic ACLs.
- 3000 to 3999 for advanced ACLs.
- 4000 to 4999 for Layer 2 ACLs.

name *acl-name*: Assigns a name to the ACL. The *acl-name* argument is a case-insensitive string of 1 to 63 characters. It must start with an English letter and to avoid confusion, it cannot be **all**.

match-order: Specifies the order in which ACL rules are compared against packets.

- **auto**: Compares ACL rules in depth-first order.
- **config**: Compares ACL rules in ascending order of rule ID. The rule with a smaller ID has a higher priority. If you do not specify a match order, the **config** order applies by default.

all: Specifies all ACLs of the specified type.

Usage guidelines

To create a numbered ACL, you can use one of the following command forms:

- **acl** [**ipv6**] **number** *acl-number* (for creating an IPv4, IPv6, or Layer 2 ACL).
- **acl** [**ipv6**] { **advanced** | **basic** } *acl-number* (for creating an IPv4 or IPv6 ACL) or **acl mac** *acl-number* (for creating a Layer 2 ACL).

To enter the view of an existing ACL or delete an ACL, you are not restricted to use only the command that is used to create the ACL. For example, you can use the **acl number** *acl-number* command to create an IPv4 advanced ACL, and use the **acl advanced** *acl-number* command to enter its view. You can also use the **undo acl advanced** *acl-number* command to delete this ACL.

You can change the match order only for ACLs that do not contain any rules.

Matching packets are forwarded through slow forwarding if an ACL rule contains match criteria or has functions enabled in addition to the following match criteria and functions:

- Source and destination IP addresses.
- Source and destination ports.
- Transport layer protocol.
- ICMP or ICMPv6 message type, message code, and message name.
- Logging.
- Time range.

Slow forwarding requires packets to be sent to the control plane for forwarding entry calculation, which affects the device forwarding performance.

Examples

Create IPv4 basic ACL 2000 and enter its view.

```
<Sysname> system-view
[Sysname] acl basic 2000
[Sysname-acl-ipv4-basic-2000]
```

Create IPv4 basic ACL **flow** and enter its view.

```
<Sysname> system-view
[Sysname] acl basic name flow
[Sysname-acl-ipv4-basic-flow]
```

Create IPv4 advanced ACL 3000 and enter its view.

```
<Sysname> system-view
[Sysname] acl advanced 3000
[Sysname-acl-ipv4-adv-3000]
```

Create IPv6 basic ACL 2000 and enter its view.

```
<Sysname> system-view
[Sysname] acl ipv6 basic 2000
[Sysname-acl-ipv6-basic-2000]
```

Create IPv6 basic ACL **flow** and enter its view.

```
<Sysname> system-view
[Sysname] acl ipv6 basic name flow
[Sysname-acl-ipv6-basic-flow]
```

Create IPv6 advanced ACL **abc** and enter its view.

```
<Sysname> system-view
[Sysname] acl ipv6 advanced name abc
[Sysname-acl-ipv6-adv-abc]
```

Create Layer 2 ACL 4000 and enter its view.

```
<Sysname> system-view
[Sysname] acl mac 4000
[Sysname-acl-mac-4000]
```

Create Layer 2 ACL **flow** and enter its view.

```
<Sysname> system-view
[Sysname] acl mac name flow
[Sysname-acl-mac-flow]
```

Related commands

display acl

acl copy

Use **acl copy** to create an ACL by copying an ACL that already exists.

Syntax

```
acl [ ipv6 | mac ] copy { source-acl-number | name source-acl-name } to { dest-acl-number | name dest-acl-name }
```

Views

System view

Predefined user roles

network-admin

Parameters

ipv6: Specifies the IPv6 ACL type.

mac: Specifies the Layer 2 ACL type.

source-acl-number: Specifies an existing source ACL by its number. The following are available value ranges:

- 2000 to 2999 for basic ACLs.
- 3000 to 3999 for advanced ACLs.
- 4000 to 4999 for Layer 2 ACLs.

name *source-acl-name*: Specifies an existing source ACL by its name. The *source-acl-name* argument is a case-insensitive string of 1 to 63 characters.

dest-acl-number: Assigns a unique number to the new ACL. The following are available value ranges:

- 2000 to 2999 for basic ACLs.
- 3000 to 3999 for advanced ACLs.
- 4000 to 4999 for Layer 2 ACLs.

name *dest-acl-name*: Assigns a unique name to the new ACL. The *dest-acl-name* argument is a case-insensitive string of 1 to 63 characters. It must start with an English letter and to avoid confusion, it cannot be **all**.

Usage guidelines

The new ACL and the source ACL must be the same type.

The new ACL has the same properties and content as the source ACL, but uses a different number or name from the source ACL.

To specify the IPv4 ACL type, do not specify the **ipv6** or **mac** keyword.

Examples

```
# Create IPv4 basic ACL 2002 by copying IPv4 basic ACL 2001.
```

```
<Sysname> system-view
[Sysname] acl copy 2001 to 2002
```

```
# Create IPv4 basic ACL paste by copying IPv4 basic ACL test.
```

```
<Sysname> system-view
```

```
[Sysname] acl copy name test to name paste
```

acl logging interval

Use **acl logging interval** to enable logging for packet filtering and set the interval.

Use **undo acl logging interval** to restore the default.

Syntax

```
acl logging interval interval
```

```
undo acl logging interval
```

Default

The interval is 0. The device does not generate log entries for packet filtering.

Views

System view

Predefined user roles

network-admin

Parameters

interval: Specifies the interval at which log entries are generated and output. It must be a multiple of 5, in the range of 0 to 1440 minutes. To disable the logging, set the value to 0.

Usage guidelines

The logging feature is available for IPv4 or IPv6 ACL rules that have the **logging** keyword.

You can configure the ACL module to generate log entries for packet filtering and output them to the information center at the output interval. The log entry records the number of matching packets and the matched ACL rules. If an ACL is matched for the first time, the device immediately outputs a log entry to record the matching packet. For more information about the information center, see *Network Management and Monitoring Configuration Guide*.

Examples

```
# Configure the device to generate and output packet filtering log entries every 10 minutes.
```

```
<Sysname> system-view
```

```
[Sysname] acl logging interval 10
```

Related commands

```
rule (IPv4 advanced ACL view)
```

```
rule (IPv4 basic ACL view)
```

```
rule (IPv6 advanced ACL view)
```

```
rule (IPv6 basic ACL view)
```

acl trap interval

Use **acl trap interval** to enable SNMP notifications for packet filtering and set the interval.

Use **undo acl interval** to restore the default.

Syntax

```
acl trap interval interval
```

undo acl trap interval

Default

The interval is 0. The device does not generate SNMP notifications for packet filtering.

Views

System view

Predefined user roles

network-admin

Parameters

interval: Specifies the interval at which SNMP notifications are generated and output. It must be a multiple of 5, in the range of 0 to 1440 minutes. To disable SNMP notifications, set the value to 0.

Usage guidelines

The SNMP notifications feature is available for IPv4 or IPv6 ACL rules that have the **logging** keyword.

You can configure the ACL module to generate SNMP notifications for packet filtering and output them to the SNMP module at the output interval. The notification records the number of matching packets and the matched ACL rules. If an ACL is matched for the first time, the device immediately outputs a notification to record the matching packet. For more information about SNMP, see *Network Management and Monitoring Configuration Guide*.

Examples

Configure the device to generate and output packet filtering SNMP notifications every 10 minutes.

```
<Sysname> system-view  
[Sysname] acl trap interval 10
```

Related commands

rule (IPv4 advanced ACL view)

rule (IPv4 basic ACL view)

rule (IPv6 advanced ACL view)

rule (IPv6 basic ACL view)

description

Use **description** to configure a description for an ACL.

Use **undo description** to delete an ACL description.

Syntax

description *text*

undo description

Default

An ACL does not have a description.

Views

IPv4 basic/advanced ACL view

IPv6 basic/advanced ACL view

Layer 2 ACL view

Predefined user roles

network-admin

Parameters

text: Specifies a description, a case-sensitive string of 1 to 127 characters.

Examples

```
# Configure a description for IPv4 basic ACL 2000.
<Sysname> system-view
[Sysname] acl basic 2000
[Sysname-acl-ipv4-basic-2000] description This is an IPv4 basic ACL.
```

Related commands

display acl

display acl

Use **display acl** to display ACL configuration and match statistics.

Syntax

```
display acl [ ipv6 | mac ] { acl-number | all | name acl-name }
```

Views

Any view

Predefined user roles

network-admin
network-operator

Parameters

ipv6: Specifies the IPv6 ACL type.

mac: Specifies the Layer 2 ACL type.

acl-number: Specifies an ACL by its number. The following are available value ranges:

- 2000 to 2999 for basic ACLs.
- 3000 to 3999 for advanced ACLs.
- 4000 to 4999 for Layer 2 ACLs.

all: Specifies all ACLs of the specified type.

name *acl-name*: Specifies an ACL by its name. The *acl-name* argument is a case-insensitive string of 1 to 63 characters.

Usage guidelines

This command displays ACL rules in **config** or **auto** order, whichever is configured.

To specify the IPv4 ACL type, do not specify the **ipv6** or **mac** keyword.

Examples

```
# Display configuration and match statistics for IPv4 basic ACL 2001.
<Sysname> display acl 2001
Basic IPv4 ACL 2001, 1 rule, match-order is auto,
This is an IPv4 basic ACL.
ACL's step is 5, start ID is 0
rule 5 permit source 1.1.1.1 0
```

```
rule 5 comment This rule is used on GigabitEthernet1/0/1.
```

Table 1 Command output

Field	Description
Basic IPv4 ACL 2001	Type and number of the ACL. The following field information is about IPv4 basic ACL 2001.
1 rule	The ACL contains one rule.
match-order is auto	The match order for the ACL is auto , which sorts ACL rules in depth-first order. This field is not displayed when the match order is config .
This is an IPv4 basic ACL.	Description of the ACL.
ACL's step is 5	The rule numbering step is 5.
start ID is 0	The start rule ID is 0.
rule 5 permit source 1.1.1.1 0	Content of rule 5. The rule permits packets sourced from the IP address 1.1.1.1.
rule 5 comment This rule is used on GigabitEthernet1/0/1.	Comment of rule 5.

display packet-filter

Use **display packet-filter** to display ACL application information for packet filtering.

Syntax

```
display packet-filter { interface [ interface-type interface-number ] [ inbound | outbound ] | interface vlan-interface vlan-interface-number [ inbound | outbound ] [ slot slot-number ] }
```

Views

Any view

Predefined user roles

network-admin
network-operator

Parameters

interface [*interface-type interface-number*]: Specifies an interface by its type and number. VLAN interfaces are not supported. If you do not specify an interface, this command displays ACL application information for packet filtering on all interfaces except VLAN interfaces.

interface vlan-interface *vlan-interface-number*: Specifies a VLAN interface by its number.

inbound: Specifies the inbound direction.

outbound: Specifies the outbound direction.

slot *slot-number*: Specifies an IRF member device by its member ID. If you do not specify a member device, this command displays ACL application information for packet filtering for the master device.

Usage guidelines

If neither the **inbound** keyword nor the **outbound** keyword is specified, this command displays ACL application information for packet filtering in both directions.

Examples

```
# Display ACL application information for inbound packet filtering on interface GigabitEthernet 1/0/1.  
<Sysname> display packet-filter interface gigabitethernet 1/0/1 inbound
```

```

Interface: GigabitEthernet1/0/1
Inbound policy:
  IPv4 ACL 2001
  IPv6 ACL 2002 (Failed)
  MAC ACL 4003 (Failed), Hardware-count (Failed)
  IPv4 default action: Deny
  IPv6 default action: Deny

```

Table 2 Command output

Field	Description
Interface	Interface to which the ACL applies.
Inbound policy	ACL used for filtering incoming traffic.
Outbound policy	ACL used for filtering outgoing traffic.
IPv4 ACL 2001	IPv4 basic ACL 2001 has been successfully applied.
IPv6 ACL 2002 (Failed)	The device has failed to apply IPv6 basic ACL 2002.
Hardware-count	ACL rule match counting has been successfully enabled.
Hardware-count (Failed)	The device has failed to enable counting ACL rule matches.
IPv4 default action	Packet filter default action for packets that do not match any IPv4 ACLs: <ul style="list-style-type: none"> • Deny—The default action deny has been successfully applied for packet filtering. • Deny (Failed)—The device has failed to apply the default action deny for packet filtering. The action permit still functions. • Permit—The default action permit has been successfully applied for packet filtering.
IPv6 default action	Packet filter default action for packets that do not match any IPv6 ACLs: <ul style="list-style-type: none"> • Deny—The default action deny has been successfully applied for packet filtering. • Deny (Failed)—The device has failed to apply the default action deny for packet filtering. The action permit still functions. • Permit—The default action permit has been successfully applied for packet filtering.
MAC default action	Packet filter default action for packets that do not match any Layer 2 ACLs: <ul style="list-style-type: none"> • Deny—The default action deny has been successfully applied for packet filtering. • Deny (Failed)—The device has failed to apply the default action deny for packet filtering. The action permit still functions. • Permit—The default action permit has been successfully applied for packet filtering.

display packet-filter statistics

Use **display packet-filter statistics** to display packet filtering statistics.

Syntax

```
display packet-filter statistics interface interface-type interface-number { inbound | outbound }  
[[ ipv6 | mac ] { acl-number | name acl-name } ] [ brief ]
```

Views

Any view

Predefined user roles

network-admin

network-operator

Parameters

interface *interface-type interface-number*: Specifies an interface by its type and number.

inbound: Specifies the inbound direction.

outbound: Specifies the outbound direction.

ipv6: Specifies the IPv6 ACL type.

mac: Specifies the Layer 2 ACL type.

acl-number: Specifies an ACL by its number. The following are available value ranges:

- 2000 to 2999 for basic ACLs.
- 3000 to 3999 for advanced ACLs.
- 4000 to 4999 for Layer 2 ACLs.

name *acl-name*: Specifies an ACL by its name. The *acl-name* argument is a case-insensitive string of 1 to 63 characters.

brief: Displays brief statistics.

Usage guidelines

If *acl-number*, **name** *acl-name*, **ipv6**, or **mac** is not specified, this command displays packet filtering statistics for all ACLs.

To specify the IPv4 ACL type, do not specify the **ipv6** or **mac** keyword.

Examples

```
# Display packet filtering statistics for all ACLs on incoming packets of GigabitEthernet 1/0/1.
```

```
<Sysname> display packet-filter statistics interface gigabitethernet 1/0/1 inbound
```

```
Interface: GigabitEthernet1/0/1
```

```
Inbound policy:
```

```
IPv4 ACL 2001, Hardware-count
```

```
From 2011-06-04 10:25:21 to 2011-06-04 10:35:57
```

```
rule 0 permit source 2.2.2.2 0 (2 packets)
```

```
rule 5 permit source 1.1.1.1 0 (Failed)
```

```
Totally 2 packets permitted, 0 packets denied
```

```
Totally 100% permitted, 0% denied
```

```
IPv6 ACL 2000
```

```
MAC ACL 4000
```

```
rule 0 permit
```

```
IPv4 default action: Deny
```

IPv6 default action: Deny

MAC default action: Deny

Table 3 Command output

Field	Description
Interface	Interface to which the ACL applies.
Inbound policy	ACL used for filtering incoming traffic.
Outbound policy	ACL used for filtering outgoing traffic.
IPv4 ACL 2001	IPv4 basic ACL 2001 has been successfully applied.
IPv4 ACL 2002 (Failed)	The device has failed to apply IPv4 basic ACL 2002.
Hardware-count	ACL rule match counting has been successfully enabled.
Hardware-count (Failed)	The device has failed to enable counting ACL rule matches.
From 2011-06-04 10:25:21 to 2011-06-04 10:35:57	Start time and end time of the statistics.
2 packets	Two packets matched the rule. This field is not displayed when no packets matched the rule.
No resource	Resources are not enough for counting matches for the rule. In packet filtering statistics, this field is displayed for a rule when resources are not sufficient for rule match counting.
rule 5 permit source 1.1.1.1 0 (Failed)	The device has failed to apply rule 5.
Totally 2 packets permitted, 0 packets denied	Number of packets permitted and denied by the ACL.
Totally 100% permitted, 0% denied	Ratios of permitted and denied packets to all packets.
IPv4 default action	Packet filter default action for packets that do not match any IPv4 ACLs: <ul style="list-style-type: none">• Deny—The default action deny has been successfully applied for packet filtering.• Deny (Failed)—The device has failed to apply the default action deny for packet filtering. The action permit still functions.• Permit—The default action permit has been successfully applied for packet filtering.
IPv6 default action	Packet filter default action for packets that do not match any IPv6 ACLs: <ul style="list-style-type: none">• Deny—The default action deny has been successfully applied for packet filtering.• Deny (Failed)—The device has failed to apply the default action deny for packet filtering. The action permit still functions.• Permit—The default action permit has been successfully applied for packet filtering.
MAC default action	Packet filter default action for packets that do not match any Layer 2 ACLs: <ul style="list-style-type: none">• Deny—The default action deny has been successfully applied for packet filtering.• Deny (Failed)—The device has failed to apply the default action deny for packet filtering. The action permit still functions.

- | | |
|--|--|
| | <ul style="list-style-type: none">• Permit—The default action permit has been successfully applied for packet filtering. |
|--|--|

Related commands

`reset packet-filter statistics`

display packet-filter statistics sum

Use **display packet-filter statistics sum** to display accumulated packet filtering statistics for an ACL.

Syntax

```
display packet-filter statistics sum { inbound | outbound } [ ipv6 | mac ] { acl-number | name  
acl-name } [ brief ]
```

Views

Any view

Predefined user roles

network-admin
network-operator

Parameters

inbound: Specifies the inbound direction.

outbound: Specifies the outbound direction.

ipv6: Specifies the IPv6 ACL type.

mac: Specifies the Layer 2 ACL type.

acl-number: Specifies an ACL by its number. The following are available value ranges:

- 2000 to 2999 for basic ACLs.
- 3000 to 3999 for advanced ACLs.
- 4000 to 4999 for Layer 2 ACLs.

name *acl-name*: Specifies an ACL by its name. The *acl-name* argument is a case-insensitive string of 1 to 63 characters.

brief: Displays brief statistics.

Usage guidelines

To specify the IPv4 ACL type, do not specify the **ipv6** or **mac** keyword.

Examples

Display accumulated packet filtering statistics for IPv4 basic ACL 2001 on incoming packets.

```
<Sysname> display packet-filter statistics sum inbound 2001
```

```
Sum:
```

```
Inbound policy:
```

```
IPv4 ACL 2001
```

```
rule 0 permit source 2.2.2.2 0 (2 packets)
```

```
rule 5 permit source 1.1.1.1 0
```

```
Totally 2 packets permitted, 0 packets denied
```

```
Totally 100% permitted, 0% denied
```

Display brief accumulated packet filtering statistics for IPv4 basic ACL 2000 on incoming packets.

```
<Sysname> display packet-filter statistics sum inbound 2000 brief
Sum:
  Inbound policy:
    IPv4 ACL 2000
      Totally 2 packets permitted, 0 packets denied
      Totally 100% permitted, 0% denied
```

Table 4 Command output

Field	Description
Sum	Accumulated packet filtering statistics.
Inbound policy	Accumulated packet filtering statistics in the inbound direction.
Outbound policy	Accumulated packet filtering statistics in the outbound direction.
IPv4 ACL 2001	Accumulated packet filtering statistics of IPv4 basic ACL 2001.
2 packets	Two packets matched the rule. This field is not displayed when no packets matched the rule.
Totally 2 packets permitted, 0 packets denied	Number of packets permitted and denied by the ACL.
Totally 100% permitted, 0% denied	Ratios of permitted and denied packets to all packets.

Related commands

reset packet-filter statistics

display packet-filter verbose

Use **display packet-filter verbose** to display ACL application details for packet filtering.

Syntax

```
display packet-filter verbose interface interface-type interface-number { inbound | outbound }
[[ ipv6 | mac ] { acl-number | name acl-name } ] [ slot slot-number ]
```

Views

Any view

Predefined user roles

network-admin

network-operator

Parameters

interface *interface-type interface-number*: Specifies an interface by its type and number. The **slot slot-number** option is not available for an Ethernet interface.

inbound: Specifies the inbound direction.

outbound: Specifies the outbound direction.

ipv6: Specifies the IPv6 ACL type.

mac: Specifies the Layer 2 ACL type.

acl-number: Specifies an ACL by its number. The following are available value ranges:

- 2000 to 2999 for basic ACLs.
- 3000 to 3999 for advanced ACLs.

- 4000 to 4999 for Layer 2 ACLs.

name *acl-name*: Specifies an ACL by its name. The *acl-name* argument is a case-insensitive string of 1 to 63 characters.

slot *slot-number*: Specifies an IRF member device by its member ID. If you do not specify a member device, this command displays ACL application details for packet filtering for the master device.

Usage guidelines

If *acl-number*, **name** *acl-name*, **ipv6**, or **mac** is not specified, this command displays application details of all ACLs for packet filtering.

To specify the IPv4 ACL type, do not specify the **ipv6** or **mac** keyword.

Examples

Display application details of all ACLs for inbound packet filtering on GigabitEthernet 1/0/1.

```
<Sysname> display packet-filter verbose interface gigabitethernet 1/0/1 inbound
```

```
Interface: GigabitEthernet1/0/1
```

```
Inbound policy:
```

```
IPv4 ACL 2001
  rule 0 permit
  rule 5 permit source 1.1.1.1 0 (Failed)
```

```
IPv6 ACL 2000
  rule 0 permit
```

```
MAC ACL 4000
```

```
IPv4 default action: Deny
```

```
IPv6 default action: Deny
```

```
MAC default action: Deny
```

Table 5 Command output

Field	Description
Interface	Interface to which the ACL applies.
Inbound policy	ACL used for filtering incoming traffic.
Outbound policy	ACL used for filtering outgoing traffic.
IPv4 ACL 2001	IPv4 basic ACL 2001 has been successfully applied.
IPv4 ACL 2002 (Failed)	The device has failed to apply IPv4 basic ACL 2002.
Hardware-count	ACL rule match counting has been successfully enabled.
Hardware-count (Failed)	The device has failed to enable counting ACL rule matches.
rule 5 permit source 1.1.1.1 0 (Failed)	The device has failed to apply rule 5.
IPv4 default action	Packet filter default action for packets that do not match any IPv4 ACLs: <ul style="list-style-type: none"> • Deny—The default action deny has been successfully applied for packet filtering. • Deny (Failed)—The device has failed to apply the default action deny for packet filtering. The action permit still functions.

	<ul style="list-style-type: none"> • Permit—The default action permit has been successfully applied for packet filtering.
IPv6 default action	<p>Packet filter default action for packets that do not match any IPv6 ACLs:</p> <ul style="list-style-type: none"> • Deny—The default action deny has been successfully applied for packet filtering. • Deny (Failed)—The device has failed to apply the default action deny for packet filtering. The action permit still functions. • Permit—The default action permit has been successfully applied for packet filtering.
MAC default action	<p>Packet filter default action for packets that do not match any Layer 2 ACLs:</p> <ul style="list-style-type: none"> • Deny—The default action deny has been successfully applied for packet filtering. • Deny (Failed)—The device has failed to apply the default action deny for packet filtering. The action permit still functions. • Permit—The default action permit has been successfully applied for packet filtering.

display qos-acl resource

Use **display qos-acl resource** to display QoS and ACL resource usage.

Syntax

display qos-acl resource [**slot** *slot-number*]

Views

Any view

Predefined user roles

network-admin

network-operator

Parameters

slot *slot-number*: Specifies an IRF member device by its member ID. If you do not specify a member device, this command displays QoS and ACL resource usage for all member devices.

Examples

Display QoS and ACL resource usage.

```
<Sysname> display qos-acl resource
```

```
Interfaces: GE1/0/1 to GE1/0/40, XGE1/0/49 to XGE1/1/8 (slot 1)
```

```
-----
```

Type	Total	Reserved	Configured	Remaining	Usage
VFP ACL	2048	512	0	1536	25%
IFP ACL	4096	1024	0	3072	25%
IFP Meter	2048	512	0	1536	25%
IFP Counter	2048	256	0	1792	12%
EFP ACL	1024	0	0	1024	0%
EFP Meter	512	0	0	512	0%
EFP Counter	512	0	0	512	0%

```
-----
```

Table 6 Command output

Field	Description
Interfaces	Interface range for the resources.
Type	Resource type: <ul style="list-style-type: none"> • ACL—ACL rule resources. • Meter—Traffic policing resources. • Counter—Traffic accounting resources. • VFP—Resources for marking local QoS IDs before Layer 2 forwarding. • IFP—Inbound resources. • EFP—Outbound resources.
Total	Total number of resources.
Reserved	Number of reserved resources.
Configured	Number of resources that has been applied.
Remaining	Number of resources that you can apply.
Usage	Configured and reserved resources as a percentage of total resources. If the percentage is not an integer, this field displays the integer part. For example, if the actual usage is 50.8%, this field displays 50%.

packet-filter

Use **packet-filter** to apply an ACL to an interface to filter packets.

Use **undo packet-filter** to remove an ACL from an interface.

Syntax

```
packet-filter [ ipv6 | mac ] { acl-number | name acl-name } { inbound | outbound }
[ hardware-count ]
```

```
undo packet-filter [ ipv6 | mac ] { acl-number | name acl-name } { inbound | outbound }
```

Default

No ACL is applied to an interface to filter packets.

Views

Layer 2 Ethernet interface view

Layer 2 aggregate interface view

VLAN interface view

Predefined user roles

network-admin

Parameters

ipv6: Specifies the IPv6 ACL type.

mac: Specifies the Layer 2 ACL type.

acl-number: Specifies an ACL by its number. The following are available value ranges:

- 2000 to 2999 for basic ACLs.
- 3000 to 3999 for advanced ACLs.
- 4000 to 4999 for Layer 2 ACLs.

name *acl-name*: Specifies an ACL by its name. The *acl-name* argument is a case-insensitive string of 1 to 63 characters.

inbound: Filters incoming packets.

outbound: Filters outgoing packets.

hardware-count: Enables counting ACL rule matches performed in hardware. If you do not specify this keyword, rule matches for the ACL are not counted.

Usage guidelines

To specify the IPv4 ACL type, do not specify the **ipv6** or **mac** keyword.

The **hardware-count** keyword in this command enables match counting for all rules in an ACL, and the **counting** keyword in the **rule** command enables match counting specific to rules.

To the same direction of an interface, you can apply a maximum of three ACLs: one IPv4 ACL, one IPv6 ACL, and one Layer 2 ACL.

You cannot apply an ACL to the outbound direction of a Layer 2 aggregate interface.

Examples

```
# Apply IPv4 basic ACL 2001 to filter incoming traffic on GigabitEthernet 1/0/1, and enable counting
ACL rule matches performed in hardware.
```

```
<Sysname> system-view
[Sysname] interface gigabitethernet 1/0/1
[Sysname-GigabitEthernet1/0/1] packet-filter 2001 inbound hardware-count
```

Related commands

display packet-filter

display packet-filter statistics

display packet-filter verbose

packet-filter default deny

Use **packet-filter default deny** to set the packet filtering default action to **deny**. The packet filter denies packets that do not match any ACL rule.

Use **undo packet-filter default deny** to restore the default.

Syntax

packet-filter default deny

undo packet-filter default deny

Default

The packet filtering default action is **permit**. The packet filter permits packets that do not match any ACL rule.

Views

System view

Predefined user roles

network-admin

Usage guidelines

The packet filter applies the default action to all ACL applications for packet filtering. The default action appears in the **display** command output for packet filtering.

Examples

```
# Set the packet filter default action to deny.
<Sysname> system-view
[Sysname] packet-filter default deny
```

Related commands

```
display packet-filter
display packet-filter statistics
display packet-filter verbose
```

packet-filter filter

Use **packet-filter filter** to specify the applicable scope of packet filtering on a VLAN interface.

Use **undo packet-filter filter** to restore the default.

Syntax

```
packet-filter filter { route | all }
undo packet-filter filter
```

Default

The packet filtering filters all packets.

Views

VLAN interface view

Predefined user roles

network-admin

Parameters

route: Filters packets forwarded at Layer 3 by the VLAN interface.

all: Filters all packets, including packets forwarded at Layer 3 by the VLAN interface and packets forwarded at Layer 2 by the physical ports associated with the VLAN interface.

Examples

```
# Configure the packet filtering on VLAN-interface 2 to filter packets forwarded at Layer 3.
<Sysname> system-view
[Sysname] interface vlan-interface 2
[Sysname-Vlan-interface2] packet-filter filter route
```

reset acl counter

Use **reset acl counter** to clear statistics for ACLs.

Syntax

```
reset acl [ ipv6 | mac ] counter { acl-number | all | name acl-name }
```

Views

User view

Predefined user roles

network-admin

Parameters

ipv6: Specifies the IPv6 ACL type.

mac: Specifies the Layer 2 ACL type.

acl-number: Specifies an ACL by its number. The following are available value ranges:

- 2000 to 2999 for basic ACLs.
- 3000 to 3999 for advanced ACLs.
- 4000 to 4999 for Layer 2 ACLs.

all: Clears statistics for all ACLs of the specified type.

name *acl-name*: Clears statistics of an ACL specified by its name. The *acl-name* argument is a case-insensitive string of 1 to 63 characters.

Usage guidelines

To specify the IPv4 ACL type, do not specify the **ipv6** or **mac** keyword.

Examples

```
# Clear statistics for IPv4 basic ACL 2001.
```

```
<Sysname> reset acl counter 2001
```

Related commands

display acl

reset packet-filter statistics

Use **reset packet-filter statistics** to clear the packet filtering statistics and accumulated statistics for an ACL.

Syntax

```
reset packet-filter statistics interface [ interface-type interface-number ] { inbound | outbound }  
[ [ ipv6 | mac ] { acl-number | name acl-name } ]
```

Views

User view

Predefined user roles

network-admin

Parameters

interface [*interface-type interface-number*]: Specifies an interface by its type and number. If you do not specify an interface, this command clears packet filtering statistics for all interfaces.

inbound: Specifies the inbound direction.

outbound: Specifies the outbound direction.

ipv6: Specifies the IPv6 ACL type.

mac: Specifies the Layer 2 ACL type.

acl-number: Specifies an ACL by its number. The following are available value ranges:

- 2000 to 2999 for basic ACLs.
- 3000 to 3999 for advanced ACLs.
- 4000 to 4999 for Layer 2 ACLs.

name *acl-name*: Specifies an ACL by its name. The *acl-name* argument is a case-insensitive string of 1 to 63 characters.

Usage guidelines

If *acl-number*, **name** *acl-name*, **ipv6**, or **mac** is not specified, this command clears the packet filtering statistics for all ACLs.

To specify the IPv4 ACL type, do not specify the **ipv6** or **mac** keyword.

Examples

```
# Clear IPv4 basic ACL 2001 statistics for inbound packet filtering on GigabitEthernet 1/0/1.
```

```
<Sysname> reset packet-filter statistics interface gigabitethernet 1/0/1 inbound 2001
```

Related commands

display packet-filter statistics

display packet-filter statistics sum

rule (IPv4 advanced ACL view)

Use **rule** to create or edit an IPv4 advanced ACL rule.

Use **undo rule** to delete an entire IPv4 advanced ACL rule or some attributes in the rule.

Syntax

```
rule [ rule-id ] { deny | permit } protocol [ { { ack ack-value | fin fin-value | psh psh-value | rst rst-value | syn syn-value | urg urg-value } * | established } | counting | destination { dest-address | dest-wildcard | any } | destination-port operator port1 [ port2 ] | { dscp dscp | { precedence precedence | tos tos } * } | fragment | icmp-type { icmp-type [ icmp-code ] | icmp-message } | logging | source { source-address | source-wildcard | any } | source-port operator port1 [ port2 ] | time-range time-range-name ] *
```

```
undo rule rule-id [ { { ack | fin | psh | rst | syn | urg } * | established } | counting | destination | destination-port | { dscp | { precedence | tos } * } | fragment | icmp-type | logging | source | source-port | time-range ] *
```

```
undo rule { deny | permit } protocol [ { { ack ack-value | fin fin-value | psh psh-value | rst rst-value | syn syn-value | urg urg-value } * | established } | counting | destination { dest-address | dest-wildcard | any } | destination-port operator port1 [ port2 ] | { dscp dscp | { precedence precedence | tos tos } * } | fragment | icmp-type { icmp-type [ icmp-code ] | icmp-message } | logging | source { source-address | source-wildcard | any } | source-port operator port1 [ port2 ] | time-range time-range-name ] *
```

Default

No IPv4 advanced ACL rules exist.

Views

IPv4 advanced ACL view

Predefined user roles

network-admin

Parameters

rule-id: Specifies a rule ID in the range of 0 to 65534. If you do not specify a rule ID when creating an ACL rule, the system automatically assigns it a rule ID. This rule ID is the nearest higher multiple of the numbering step to the current highest rule ID, starting from the start rule ID. For example, if the rule numbering step is 5 and the current highest rule ID is 28, the rule is numbered 30.

deny: Denies matching packets.

permit: Allows matching packets to pass.

protocol: Specifies one of the following values:

- A protocol number in the range of 0 to 255.
- A protocol by its name: **gre** (47), **icmp** (1), **ip**, **ipinip** (4), **tcp** (6), or **udp** (17). The **ip** keyword specifies all protocols.

Table 7 describes the parameters that you can specify regardless of the value for the *protocol* argument.

Table 7 Match criteria and other rule information for IPv4 advanced ACL rules

Parameters	Function	Description
source { <i>source-address</i> <i>source-wildcard</i> any }	Specifies a source address.	The <i>source-address</i> <i>source-wildcard</i> arguments specify a source IP address and a wildcard mask in dotted decimal notation. An all-zero wildcard represents a host address. The any keyword specifies any source IP address.
destination { <i>dest-address</i> <i>dest-wildcard</i> any }	Specifies a destination address.	The <i>dest-address</i> <i>dest-wildcard</i> arguments specify a destination IP address and a wildcard mask in dotted decimal notation. An all-zero wildcard mask represents a host address. The any keyword represents any destination IP address.
counting	Counts the times that the rule is matched.	The counting keyword enables match counting specific to rules, and the hardware-count keyword in the packet-filter command enables match counting for all rules in an ACL. If the counting keyword is not specified, matches for the rule are not counted.
precedence <i>precedence</i>	Specifies an IP precedence value.	The <i>precedence</i> argument can be a number in the range of 0 to 7, or in words: routine (0), priority (1), immediate (2), flash (3), flash-override (4), critical (5), internet (6), or network (7).
tos <i>tos</i>	Specifies a ToS preference.	The <i>tos</i> argument can be a number in the range of 0 to 15, or in words: max-reliability (2), max-throughput (4), min-delay (8), min-monetary-cost (1), or normal (0).
dscp <i>dscp</i>	Specifies a DSCP priority.	The <i>dscp</i> argument can be a number in the range of 0 to 63, or in words: af11 (10), af12 (12), af13 (14), af21 (18), af22 (20), af23 (22), af31 (26), af32 (28), af33 (30), af41 (34), af42 (36), af43 (38), cs1 (8), cs2 (16), cs3 (24), cs4 (32), cs5 (40), cs6 (48), cs7 (56), default (0), or ef (46).
fragment	Applies the rule only to non-first fragments.	If you do not specify this keyword, the rule applies to all fragments and non-fragments.
logging	Logs matching packets.	This feature requires that the module (for example, packet filtering) that uses the ACL supports logging.
time-range <i>time-range-name</i>	Specifies a time range for the rule.	The <i>time-range-name</i> argument is a case-insensitive string of 1 to 32 characters. It must start with an English letter. If the time range is not configured, the system creates the rule. However, the rule using the time range can take effect only after you configure the time range. For more information about time range, see <i>ACL and QoS Configuration Guide</i> .

If the *protocol* argument is **tcp** (6) or **udp** (7), set the parameters shown in Table 8.

Table 8 TCP/UDP-specific parameters for IPv4 advanced ACL rules

Parameters	Function	Description
source-port <i>operator port1</i> [<i>port2</i>]	Specifies one or more UDP or TCP source ports.	The <i>operator</i> argument can be lt (lower than), gt (greater than), eq (equal to), neq (not equal to), or range (inclusive range) . The <i>port1</i> and <i>port2</i> arguments are TCP or UDP port numbers in the range of 0 to 65535. The <i>port2</i> argument is needed only when the <i>operator</i> argument is range . TCP port numbers can be represented as: chargen (19), cmd (514), daytime (13), discard (9), dns (53), domain (53), echo (7), exec (512), finger (79), ftp (21), ftp-data (20), gopher (70), hostname (101), irc (194), klogin (543), kshell (544), login (513), lpd (515), nntp (119), pop2 (109), pop3 (110), smtp (25), sunrpc (111), tacacs (49), talk (517), telnet (23), time (37), uucp (540), whois (43), and www (80).
destination-port <i>operator port1</i> [<i>port2</i>]	Specifies one or more UDP or TCP destination ports.	UDP port numbers can be represented as: biff (512), bootpc (68), bootps (67), discard (9), dns (53), dnsix (90), echo (7), mobilip-ag (434), mobilip-mn (435), nameserver (42), netbios-dgm (138), netbios-ns (137), netbios-ssn (139), ntp (123), rip (520), snmp (161), snmptrap (162), sunrpc (111), syslog (514), tacacs-ds (65), talk (517), tftp (69), time (37), who (513), and xdmcp (177).
{ ack <i>ack-value</i> fin <i>fin-value</i> psh <i>psh-value</i> rst <i>rst-value</i> syn <i>syn-value</i> urg <i>urg-value</i> } *	Specifies one or more TCP flags including ACK, FIN, PSH, RST, SYN, and URG.	Parameters specific to TCP. The value for each argument can be 0 (flag bit not set) or 1 (flag bit set). The TCP flags in a rule are ANDed. For example, a rule configured with ack 0 psh 1 matches packets that have the ACK flag bit not set and the PSH flag bit set.
established	Specifies the flags for indicating the established status of a TCP connection.	Parameter specific to TCP. The rule matches TCP packets with the ACK or RST flag bit set.

If the *protocol* argument is **icmp** (1), set the parameters shown in [Table 9](#).

Table 9 ICMP-specific parameters for IPv4 advanced ACL rules

Parameters	Function	Description
icmp-type { <i>icmp-type</i> <i>icmp-code</i> <i>icmp-message</i> }	Specifies the ICMP message type and code.	The <i>icmp-type</i> argument is in the range of 0 to 255. The <i>icmp-code</i> argument is in the range of 0 to 255. The <i>icmp-message</i> argument specifies a message name. Supported ICMP message names and their corresponding type and code values are listed in Table 10 .

Table 10 ICMP message names supported in IPv4 advanced ACL rules

ICMP message name	ICMP message type	ICMP message code
echo	8	0
echo-reply	0	0
fragmentneed-DFset	3	4
host-redirect	5	1
host-tos-redirect	5	3
host-unreachable	3	1

information-reply	16	0
information-request	15	0
net-redirect	5	0
net-tos-redirect	5	2
net-unreachable	3	0
parameter-problem	12	0
port-unreachable	3	3
protocol-unreachable	3	2
reassembly-timeout	11	1
source-quench	4	0
source-route-failed	3	5
timestamp-reply	14	0
timestamp-request	13	0
ttl-exceeded	11	0

Usage guidelines

If an ACL is used for QoS traffic classification or packet filtering, do not specify **neq** for the *operator* argument.

Within an ACL, the permit or deny statement of each rule must be unique. If the rule you are creating or editing has the same deny or permit statement as another rule in the ACL, the rule will not be created or changed.

You can edit ACL rules only when the match order is **config**.

To view the existing IPv4 basic and advanced ACL rules, use the **display acl all** command.

The **undo rule rule-id** command without any optional parameters deletes an entire rule. If you specify optional parameters, the **undo rule rule-id** command deletes the specified attributes for the rule.

The **undo rule { deny | permit }** command can only be used to delete an entire rule. You must specify all the attributes of the rule for the command.

Examples

Create an IPv4 advanced ACL rule to permit TCP packets with the destination port 80 from 129.9.0.0/16 to 202.38.160.0/24.

```
<Sysname> system-view
[Sysname] acl advanced 3000
[Sysname-acl-ipv4-adv-3000] rule permit tcp source 129.9.0.0 0.0.255.255 destination
202.38.160.0 0.0.0.255 destination-port eq 80
```

Create IPv4 advanced ACL rules to permit all IP packets but the ICMP packets destined for 192.168.1.0/24.

```
<Sysname> system-view
[Sysname] acl advanced 3001
[Sysname-acl-ipv4-adv-3001] rule deny icmp destination 192.168.1.0 0.0.0.255
[Sysname-acl-ipv4-adv-3001] rule permit ip
```

Create IPv4 advanced ACL rules to permit inbound and outbound FTP packets.

```
<Sysname> system-view
[Sysname] acl advanced 3002
```

```
[Sysname-acl-ipv4-adv-3002] rule permit tcp source-port eq ftp
[Sysname-acl-ipv4-adv-3002] rule permit tcp source-port eq ftp-data
[Sysname-acl-ipv4-adv-3002] rule permit tcp destination-port eq ftp
[Sysname-acl-ipv4-adv-3002] rule permit tcp destination-port eq ftp-data
# Create IPv4 advanced ACL rules to permit inbound and outbound SNMP and SNMP trap packets.
<Sysname> system-view
[Sysname] acl advanced 3003
[Sysname-acl-ipv4-adv-3003] rule permit udp source-port eq snmp
[Sysname-acl-ipv4-adv-3003] rule permit udp source-port eq snmptrap
[Sysname-acl-ipv4-adv-3003] rule permit udp destination-port eq snmp
[Sysname-acl-ipv4-adv-3003] rule permit udp destination-port eq snmptrap
```

Related commands

acl

acl logging interval

display acl

step

time-range

rule (IPv4 basic ACL view)

Use **rule** to create or edit an IPv4 basic ACL rule.

Use **undo rule** to delete an entire IPv4 basic ACL rule or some attributes in the rule.

Syntax

```
rule [ rule-id ] { deny | permit } [ counting | fragment | logging | source { source-address
source-wildcard | any } | time-range time-range-name ] *
```

```
undo rule rule-id [ counting | fragment | logging | source | time-range ] *
```

```
undo rule { deny | permit } [ counting | fragment | logging | source { source-address
source-wildcard | any } | time-range time-range-name ] *
```

Default

No IPv4 basic ACL rules exist.

Views

IPv4 basic ACL view

Predefined user roles

network-admin

Parameters

rule-id: Specifies a rule ID in the range of 0 to 65534. If you do not specify a rule ID when creating an ACL rule, the system automatically assigns it a rule ID. This rule ID is the nearest higher multiple of the numbering step to the current highest rule ID, starting from the start rule ID. For example, if the rule numbering step is 5 and the current highest rule ID is 28, the rule is numbered 30.

deny: Denies matching packets.

permit: Allows matching packets to pass.

counting: Counts the times that the rule is matched. If you do not specify this keyword, matches for the rule are not counted.

fragment: Applies the rule only to non-first fragments. If you do not specify this keyword, the rule applies to both fragments and non-fragments.

logging: Logs matching packets. This feature is available only when the application module (for example, packet filtering) that uses the ACL supports the logging feature.

source { *source-address source-wildcard* | **any** }: Matches a source address. The *source-address* and *source-wildcard* arguments specify a source IP address and a wildcard mask in dotted decimal notation. A wildcard mask of zeros represents a host address. The **any** keyword represents any source IP address.

time-range *time-range-name*: Specifies a time range for the rule. The *time-range-name* argument is a case-insensitive string of 1 to 32 characters. It must start with an English letter. If the time range is not configured, the system creates the rule. However, the rule using the time range can take effect only after you configure the time range. For more information about time ranges, see *ACL and QoS Configuration Guide*.

Usage guidelines

Within an ACL, the permit or deny statement of each rule must be unique. If the rule you are creating or editing has the same deny or permit statement as another rule in the ACL, the rule will not be created or changed.

You can edit ACL rules only when the match order is **config**.

The **counting** keyword in this command enables match counting specific to rules, and the **hardware-count** keyword in the **packet-filter** command enables match counting for all rules in an ACL.

To view the existing IPv4 basic and advanced ACL rules, use the **display acl all** command.

The **undo rule** *rule-id* command without any optional parameters deletes an entire rule. If you specify optional parameters, the **undo rule** *rule-id* command deletes the specified attributes for the rule.

The **undo rule** { **deny** | **permit** } command can only be used to delete an entire rule. You must specify all the attributes of the rule for the command.

Examples

Create a rule in IPv4 basic ACL 2000 to deny the packets from any source IP subnet but 10.0.0.0/8, 172.17.0.0/16, or 192.168.1.0/24.

```
<Sysname> system-view
[Sysname] acl basic 2000
[Sysname-acl-ipv4-basic-2000] rule permit source 10.0.0.0 0.255.255.255
[Sysname-acl-ipv4-basic-2000] rule permit source 172.17.0.0 0.0.255.255
[Sysname-acl-ipv4-basic-2000] rule permit source 192.168.1.0 0.0.0.255
[Sysname-acl-ipv4-basic-2000] rule deny source any
```

Related commands

acl

acl logging interval

display acl

step

time-range

rule (IPv6 advanced ACL view)

Use **rule** to create or edit an IPv6 advanced ACL rule.

Use **undo rule** to delete an entire IPv6 advanced ACL rule or some attributes in the rule.

Syntax

```
rule [ rule-id ] { deny | permit } protocol [ { { ack ack-value | fin fin-value | psh psh-value | rst
rst-value | syn syn-value | urg urg-value } * | established } | counting | destination { dest-address
dest-prefix | dest-address/dest-prefix | any } | destination-port operator port1 [ port2 ] | dscp dscp |
flow-label flow-label-value | fragment | icmp6-type { icmp6-type icmp6-code | icmp6-message } |
logging | routing [ type routing-type ] | hop-by-hop [ type hop-type ] | source { source-address
source-prefix | source-address/source-prefix | any } | source-port operator port1 [ port2 ] |
time-range time-range-name ] *
```

```
undo rule rule-id [ { { ack | fin | psh | rst | syn | urg } * | established } | counting | destination |
destination-port | dscp | flow-label | fragment | icmp6-type | logging | routing | hop-by-hop |
source | source-port | time-range ] *
```

```
undo rule { deny | permit } protocol [ { { ack ack-value | fin fin-value | psh psh-value | rst rst-value
| syn syn-value | urg urg-value } * | established } | counting | destination { dest-address dest-prefix
| dest-address/dest-prefix | any } | destination-port operator port1 [ port2 ] | dscp dscp | flow-label
flow-label-value | fragment | icmp6-type { icmp6-type icmp6-code | icmp6-message } | logging |
routing [ type routing-type ] | hop-by-hop [ type hop-type ] | source { source-address source-prefix
| source-address/source-prefix | any } | source-port operator port1 [ port2 ] | time-range
time-range-name ] *
```

Default

No IPv6 advanced ACL rules exist.

Views

IPv6 advanced ACL view

Predefined user roles

network-admin

Parameters

rule-id: Specifies a rule ID in the range of 0 to 65534. If you do not specify a rule ID when creating an ACL rule, the system automatically assigns it a rule ID. This rule ID is the nearest higher multiple of the numbering step to the current highest rule ID, starting from the start rule ID. For example, if the rule numbering step is 5 and the current highest rule ID is 28, the rule is numbered 30.

deny: Denies matching packets.

permit: Allows matching packets to pass.

protocol: Specifies one of the following values:

- A protocol number in the range of 0 to 255.
- A protocol name: **gre** (47), **icmpv6** (58), **ipv6**, **ipv6-ah** (51), **ipv6-esp** (50), **tcp** (6), or **udp** (17). The **ipv6** keyword specifies all protocols.

Table 11 describes the parameters that you can specify regardless of the value for the *protocol* argument.

Table 11 Match criteria and other rule information for IPv6 advanced ACL rules

Parameters	Function	Description
source { source-address source-prefix source-address/s ource-prefix any }	Specifies a source IPv6 address.	The <i>source-address</i> argument specifies an IPv6 source address. The <i>source-prefix</i> argument specifies a prefix length in the range of 1 to 128. The any keyword represents any IPv6 source address.
destination { dest-address dest-prefix	Specifies a destination IPv6 address.	The <i>dest-address</i> argument specifies a destination IPv6 address. The <i>dest-prefix</i> argument specifies a prefix length in the

<i>dest-address/dest-prefix any</i>		range of 1 to 128. The any keyword represents any IPv6 destination address.
counting	Counts the times that the rule is matched.	The counting keyword enables match counting specific to rules, and the hardware-count keyword in the packet-filter ipv6 command enables match counting for all rules in an ACL. If the counting keyword is not specified, matches for the rule are not counted.
dscp <i>dscp</i>	Specifies a DSCP preference.	The <i>dscp</i> argument can be a number in the range of 0 to 63, or in words, af11 (10), af12 (12), af13 (14), af21 (18), af22 (20), af23 (22), af31 (26), af32 (28), af33 (30), af41 (34), af42 (36), af43 (38), cs1 (8), cs2 (16), cs3 (24), cs4 (32), cs5 (40), cs6 (48), cs7 (56), default (0), or ef (46).
flow-label <i>flow-label-value</i>	Specifies a flow label value in an IPv6 packet header.	The <i>flow-label-value</i> argument is in the range of 0 to 1048575.
fragment	Applies the rule only to non-first fragments.	If you do not specify this keyword, the rule applies to all fragments and non-fragments.
logging	Logs matching packets.	This feature requires that the module (for example, packet filtering) that uses the ACL supports logging.
routing [type <i>routing-type</i>]	Specifies an IPv6 routing header type.	<i>routing-type</i> : Value of the IPv6 routing header type, in the range of 0 to 255. If you specify the type <i>routing-type</i> option, the rule applies to the specified type of IPv6 routing header. If you do not specify the type <i>routing-type</i> option, the rule applies to all types of IPv6 routing headers.
hop-by-hop [type <i>hop-type</i>]	Specifies an IPv6 Hop-by-Hop Options header type.	<i>hop-type</i> : Value of the IPv6 Hop-by-Hop Options header type, in the range of 0 to 255. If you specify the type <i>hop-type</i> option, the rule applies to the specified type of IPv6 Hop-by-Hop Options header. If you do not specify the type <i>hop-type</i> option, the rule applies to all types of IPv6 Hop-by-Hop Options header.
time-range <i>time-range-name</i>	Specifies a time range for the rule.	The <i>time-range-name</i> argument is a case-insensitive string of 1 to 32 characters. It must start with an English letter. If the time range is not configured, the system creates the rule. However, the rule using the time range can take effect only after you configure the time range. For more information about time range, see <i>ACL and QoS Configuration Guide</i> .

If the *protocol* argument is **tcp** (6) or **udp** (17), set the parameters shown in [Table 12](#).

Table 12 TCP/UDP-specific parameters for IPv6 advanced ACL rules

Parameters	Function	Description
source-port <i>operator port1</i> [<i>port2</i>]	Specifies one or more UDP or TCP source ports.	The <i>operator</i> argument can be lt (lower than), gt (greater than), eq (equal to), neq (not equal to), or range (inclusive range) . The <i>port1</i> and <i>port2</i> arguments are TCP or UDP port numbers in the range of 0 to 65535. The <i>port2</i> argument is needed only when the <i>operator</i> argument is range .
destination-port <i>operator port1</i> [<i>port2</i>]	Specifies one or more UDP or TCP destination ports.	TCP port numbers can be represented as: chargen (19), cmd (514), daytime (13), discard (9), dns (53), domain (53), echo (7), exec (512), finger (79), ftp (21), ftp-data (20), gopher (70), hostname (101), irc (194), klogin (543), kshell (544), login (513), lpd (515), nntp (119), pop2 (109), pop3 (110), smtp (25), sunrpc (111), tacacs (49), talk (517), telnet (23), time (37), uucp (540), whois (43), and www (80).

		UDP port numbers can be represented as: biff (512), bootpc (68), bootps (67), discard (9), dns (53), dnsix (90), echo (7), mobilip-ag (434), mobilip-mn (435), nameserver (42), netbios-dgm (138), netbios-ns (137), netbios-ssn (139), ntp (123), rip (520), snmp (161), snmptrap (162), sunrpc (111), syslog (514), tacacs-ds (65), talk (517), tftp (69), time (37), who (513), and xmcp (177).
{ ack <i>ack-value</i> fin <i>fin-value</i> psh <i>psh-value</i> rst <i>rst-value</i> syn <i>syn-value</i> urg <i>urg-value</i> } *	Specifies one or more TCP flags, including ACK, FIN, PSH, RST, SYN, and URG.	Parameters specific to TCP. The value for each argument can be 0 (flag bit not set) or 1 (flag bit set). The TCP flags in a rule are ANDed. For example, a rule configured with ack 0 psh 1 matches packets that have the ACK flag bit not set and the PSH flag bit set.
established	Specifies the flags for indicating the established status of a TCP connection.	Parameter specific to TCP. The rule matches TCP packets with the ACK or RST flag bit set.

If the *protocol* argument is **icmpv6** (58), set the parameters shown in [Table 13](#).

Table 13 ICMPv6-specific parameters for IPv6 advanced ACL rules

Parameters	Function	Description
icmp6-type { <i>icmp6-type</i> <i>icmp6-code</i> <i>icmp6-message</i> }	Specifies the ICMPv6 message type and code.	The <i>icmp6-type</i> argument is in the range of 0 to 255. The <i>icmp6-code</i> argument is in the range of 0 to 255. The <i>icmp6-message</i> argument specifies a message name. Supported ICMP message names and their corresponding type and code values are listed in Table 14 .

Table 14 ICMPv6 message names supported in IPv6 advanced ACL rules

ICMPv6 message name	ICMPv6 message type	ICMPv6 message code
echo-reply	129	0
echo-request	128	0
err-Header-field	4	0
frag-time-exceeded	3	1
hop-limit-exceeded	3	0
host-admin-prohib	1	1
host-unreachable	1	3
neighbor-advertisement	136	0
neighbor-solicitation	135	0
network-unreachable	1	0
packet-too-big	2	0
port-unreachable	1	4
redirect	137	0
router-advertisement	134	0
router-solicitation	133	0

unknown-ipv6-opt	4	2
unknown-next-hdr	4	1

Usage guidelines

If an ACL is for QoS traffic classification or packet filtering:

- Do not specify the **fragment** keyword.
- Do not specify **neq** for the *operator* argument.
- Do not specify the **routing**, **hop-by-hop**, or **flow-label** keyword if the ACL is for outbound application.
- Do not specify **ipv6-ah** for the *protocol* argument, or set its value to 0, 43, 44, 51, or 60 if the ACL is for outbound application.

If an IPv6 advanced ACL is used for outbound QoS traffic classification or packet filtering, do not specify the **flow-label** parameter.

If an IPv6 advanced ACL is used for packet filtering, do not specify the **fragment** keyword.

Within an ACL, the permit or deny statement of each rule must be unique. If the rule you are creating or editing has the same deny or permit statement as another rule in the ACL, the rule will not be created or changed.

You can edit ACL rules only when the match order is **config**.

To view the existing IPv6 basic and advanced ACL rules, use the **display acl ipv6 all** command.

The **undo rule rule-id** command without any optional parameters deletes an entire rule. If you specify optional parameters, the **undo rule rule-id** command deletes the specified attributes for a rule.

The **undo rule { deny | permit }** command can only be used to delete an entire rule. You must specify all the attributes of the rule for the command.

Examples

Create an IPv6 advanced ACL rule to permit TCP packets with the destination port 80 from 2030:5060::/64 to FE80:5060::/96.

```
<Sysname> system-view
[Sysname] acl ipv6 advanced 3000
[Sysname-acl-ipv6-adv-3000] rule permit tcp source 2030:5060::/64 destination
fe80:5060::/96 destination-port eq 80
```

Create IPv6 advanced ACL rules to permit all IPv6 packets but the ICMPv6 packets destined for FE80:5060:1001::/48.

```
<Sysname> system-view
[Sysname] acl ipv6 advanced 3001
[Sysname-acl-ipv6-adv-3001] rule deny icmpv6 destination fe80:5060:1001:: 48
[Sysname-acl-ipv6-adv-3001] rule permit ipv6
```

Create IPv6 advanced ACL rules to permit inbound and outbound FTP packets.

```
<Sysname> system-view
[Sysname] acl ipv6 advanced 3002
[Sysname-acl-ipv6-adv-3002] rule permit tcp source-port eq ftp
[Sysname-acl-ipv6-adv-3002] rule permit tcp source-port eq ftp-data
[Sysname-acl-ipv6-adv-3002] rule permit tcp destination-port eq ftp
[Sysname-acl-ipv6-adv-3002] rule permit tcp destination-port eq ftp-data
```

Create IPv6 advanced ACL rules to permit inbound and outbound SNMP and SNMP trap packets.

```
<Sysname> system-view
```

```

[Sysname] acl ipv6 advanced 3003
[Sysname-acl-ipv6-adv-3003] rule permit udp source-port eq snmp
[Sysname-acl-ipv6-adv-3003] rule permit udp source-port eq snmptrap
[Sysname-acl-ipv6-adv-3003] rule permit udp destination-port eq snmp
[Sysname-acl-ipv6-adv-3003] rule permit udp destination-port eq snmptrap

# Create IPv6 advanced ACL 3004, and configure two rules: one permits packets with the
Hop-by-Hop Options header type as 5, and the other one denies packets with other Hop-by-Hop
Options header types.
<Sysname> system-view
[Sysname] acl ipv6 advanced 3004
[Sysname-acl-ipv6-adv-3004] rule permit ipv6 hop-by-hop type 5
[Sysname-acl-ipv6-adv-3004] rule deny ipv6 hop-by-hop

```

Related commands

acl
acl logging interval
display acl
step
time-range

rule (IPv6 basic ACL view)

Use **rule** to create or edit an IPv6 basic ACL rule.

Use **undo rule** to delete an entire IPv6 basic ACL rule or some attributes in the rule.

Syntax

```

rule [ rule-id ] { deny | permit } [ counting | fragment | logging | routing [ type routing-type ] |
source { source-address source-prefix | source-address/source-prefix | any } | time-range
time-range-name ] *

undo rule rule-id [ counting | fragment | logging | routing | source | time-range ] *

undo rule { deny | permit } [ counting | fragment | logging | routing [ type routing-type ] | source
{ source-address source-prefix | source-address/source-prefix | any } | time-range
time-range-name ] *

```

Default

No IPv6 basic ACL rules exist.

Views

IPv6 basic ACL view

Predefined user roles

network-admin

Parameters

rule-id: Specifies a rule ID in the range of 0 to 65534. If you do not specify a rule ID when creating an ACL rule, the system automatically assigns it a rule ID. This rule ID is the nearest higher multiple of the numbering step to the current highest rule ID, starting from the start rule ID. For example, if the rule numbering step is 5 and the current highest rule ID is 28, the rule is numbered 30.

deny: Denies matching packets.

permit: Allows matching packets to pass.

counting: Counts the times that the rule is matched. If you do not specify this keyword, matches for the rule are not counted.

fragment: Applies the rule only to non-first fragments. If you do not specify this keyword, the rule applies to both fragments and non-fragments.

logging: Logs matching packets. This feature is available only when the application module (for example, packet filtering) that uses the ACL supports the logging feature.

routing [type *routing-type*]: Applies the rule to the specified type of IPv6 routing header or all types of IPv6 routing headers. The *routing-type* argument specifies the value of the IPv6 routing header type, in the range of 0 to 255. If you do not specify the **type *routing-type*** option, the rule applies to all types of IPv6 routing headers.

source { *source-address source-prefix* | *source-address/source-prefix* | **any }:** Matches a source IPv6 address. The *source-address* argument specifies a source IPv6 address. The *source-prefix* argument specifies an address prefix length in the range of 1 to 128. The **any** keyword represents any IPv6 source address.

time-range *time-range-name*: Specifies a time range for the rule. The *time-range-name* argument is a case-insensitive string of 1 to 32 characters. It must start with an English letter. If the time range is not configured, the system creates the rule. However, the rule using the time range can take effect only after you configure the time range. For more information about time ranges, see *ACL and QoS Configuration Guide*.

Usage guidelines

If an ACL is for QoS traffic classification or packet filtering:

- Do not specify the **fragment** keyword.
- Do not specify the **routing** keyword if the ACL is for outbound application.

Within an ACL, the permit or deny statement of each rule must be unique. If the rule you are creating or editing has the same deny or permit statement as another rule in the ACL, the rule will not be created or changed.

You can edit ACL rules only when the match order is **config**.

The **counting** keyword in this command enables match counting specific to rules, and the **hardware-count** keyword in the **packet-filter ipv6** command enables match counting for all rules in an ACL.

To view the existing IPv6 basic and advanced ACL rules, use the **display acl ipv6 all** command.

The **undo rule *rule-id*** command without any optional parameters deletes an entire rule. If you specify optional parameters, the **undo rule *rule-id*** command deletes the specified attributes for a rule.

The **undo rule { **deny** | **permit** }** command can only be used to delete an entire rule. You must specify all the attributes of the rule for the command.

Examples

Create an IPv6 basic ACL rule to deny the packets from any source IP subnet but 1001::/16, 3124:1123::/32, or FE80:5060:1001::/48.

```
<Sysname> system-view
[Sysname] acl ipv6 basic 2000
[Sysname-acl-ipv6-basic-2000] rule permit source 1001:: 16
[Sysname-acl-ipv6-basic-2000] rule permit source 3124:1123:: 32
[Sysname-acl-ipv6-basic-2000] rule permit source fe80:5060:1001:: 48
[Sysname-acl-ipv6-basic-2000] rule deny source any
```

Related commands

acl

acl logging interval
display acl
step
time-range

rule (Layer 2 ACL view)

Use **rule** to create or edit a Layer 2 ACL rule.

Use **undo rule** to delete an entire Layer 2 ACL rule or some attributes in the rule.

Syntax

```
rule [ rule-id ] { deny | permit } [ cos dot1p | counting | dest-mac dest-address dest-mask | { Isap Isap-type Isap-type-mask | type protocol-type protocol-type-mask } | source-mac source-address source-mask | time-range time-range-name ] *
```

```
undo rule rule-id [ counting | time-range ] *
```

```
undo rule { deny | permit } [ cos dot1p | counting | dest-mac dest-address dest-mask | { Isap Isap-type Isap-type-mask | type protocol-type protocol-type-mask } | source-mac source-address source-mask | time-range time-range-name ] *
```

Default

No Layer 2 ACL rules exist.

Views

Layer 2 ACL view

Predefined user roles

network-admin

Parameters

rule-id: Specifies a rule ID in the range of 0 to 65534. If you do not specify a rule ID when creating an ACL rule, the system automatically assigns it a rule ID. This rule ID is the nearest higher multiple of the numbering step to the current highest rule ID, starting from the start rule ID. For example, if the rule numbering step is 5 and the current highest rule ID is 28, the rule is numbered 30.

deny: Denies matching packets.

permit: Allows matching packets to pass.

cos *dot1p*: Matches an 802.1p priority. The 802.1p priority can be specified by one of the following values:

- A priority number in the range of 0 to 7.
- A priority name: **best-effort** (0), **background** (1), **spare** (2), **excellent-effort** (3), **controlled-load** (4), **video** (5), **voice** (6), or **network-management** (7).

counting: Counts the times that the rule is matched. If you do not specify this keyword, matches for the rule are not counted.

dest-mac *dest-address dest-mask*: Matches a destination MAC address range. The *dest-address* and *dest-mask* arguments represent a destination MAC address and mask in the H-H-H format.

Isap *Isap-type Isap-type-mask*: Matches the DSAP and SSAP fields in LLC encapsulation. The *Isap-type* argument is a hexadecimal number that represents the encapsulation format. The value range for the *Isap-type* argument is 0 to ffff. The *Isap-type-mask* argument is a hexadecimal number that represents the LSAP mask. The value range for the *Isap-type-mask* argument is 0 to ffff. For an ACL with **Isap** specified to work correctly in a QoS policy or packet filter, the values for the *Isap-type* and *Isap-type-mask* arguments must be **aaaa** and **ffff**, respectively.

type *protocol-type protocol-type-mask*: Matches one or more protocols in the Layer 2. The *protocol-type* argument is a hexadecimal number that represents a protocol type in Ethernet_II and Ethernet_SNAP frames. The value range for the *protocol-type* argument is 0 to ffff. The *protocol-type-mask* argument is a hexadecimal number that represents a protocol type mask. The value range for the *protocol-type-mask* argument is 0 to ffff.

source-mac *source-address source-mask*: Matches a source MAC address range. The *source-address* argument represents a source MAC address, and the *sour-mask* argument represents a mask in the H-H-H format.

time-range *time-range-name*: Specifies a time range for the rule. The *time-range-name* argument is a case-insensitive string of 1 to 32 characters. It must start with an English letter. If the time range is not configured, the system creates the rule. However, the rule using the time range can take effect only after you configure the time range. For more information about time ranges, see *ACL and QoS Configuration Guide*.

Usage guidelines

Within an ACL, the permit or deny statement of each rule must be unique. If the rule you are creating or editing has the same deny or permit statement as another rule in the ACL, the rule will not be created or changed.

You can edit ACL rules only when the match order is **config**.

The **counting** keyword in this command enables match counting specific to rules, and the **hardware-count** keyword in the **packet-filter** command enables match counting for all rules in an ACL.

To view the existing Layer 2 ACL rules, use the **display acl mac all** command.

The **undo rule** *rule-id* command without any optional parameters deletes an entire rule. If you specify optional parameters, the **undo rule** *rule-id* command deletes the specified attributes for the rule.

The **undo rule { deny | permit }** command can only be used to delete an entire rule. You must specify all the attributes of the rule for the command.

Examples

Create a rule in Layer 2 ACL 4000 to permit ARP packets and deny RARP packets.

```
<Sysname> system-view
[Sysname] acl mac 4000
[Sysname-acl-mac-4000] rule permit type 0806 ffff
[Sysname-acl-mac-4000] rule deny type 8035 ffff
```

Related commands

acl

display acl

step

time-range

rule comment

Use **rule comment** to configure a comment for an ACL rule.

Use **undo rule comment** to delete an ACL rule comment.

Syntax

rule *rule-id* **comment** *text*

undo rule *rule-id* **comment**

Default

A rule does not have a comment.

Views

IPv4 basic/advanced ACL view

IPv6 basic/advanced ACL view

Layer 2 ACL view

Predefined user roles

network-admin

Parameters

rule-id: Specifies an ACL rule ID in the range of 0 to 65534. The ACL rule must already exist.

text: Specifies a comment about the ACL rule, a case-sensitive string of 1 to 127 characters.

Usage guidelines

This command adds a comment to a rule if the rule does not have a comment. It modifies the comment for a rule if the rule already has a comment.

Examples

Create a rule for IPv4 basic ACL 2000, and add a comment about the rule.

```
<Sysname> system-view
```

```
[Sysname] acl basic 2000
```

```
[Sysname-acl-ipv4-basic-2000] rule 0 deny source 1.1.1.1 0
```

```
[Sysname-acl-ipv4-basic-2000] rule 0 comment This rule is used on gigabitethernet 1/0/1.
```

Related commands

display acl

step

Use **step** to set a rule numbering step for an ACL.

Use **undo step** to restore the default.

Syntax

step *step-value* [**start** *start-value*]

undo step

Default

The rule numbering step is 5, and the start rule ID is 0.

Views

IPv4 basic/advanced ACL view

IPv6 basic/advanced ACL view

Layer 2 ACL view

Predefined user roles

network-admin

Parameters

step-value: Specifies the ACL rule numbering step in the range of 1 to 20.

start *start-value*: Specifies the start rule ID in the range of 0 to 20.

Usage guidelines

The rule numbering step sets the increment by which the system numbers rules automatically. If you do not specify a rule ID when creating an ACL rule, the system automatically assigns it a rule ID. This rule ID is the nearest higher multiple of the numbering step to the current highest rule ID, starting from the start rule ID. For example, if the rule numbering step is 5 and the current highest rule ID is 12, the rule is numbered 15.

The wider the numbering step, the more rules you can insert between two rules. Whenever the step or start rule ID changes, the rules are renumbered, starting from the start rule ID. For example, if there are five rules numbered 0, 5, 9, 10, and 15, changing the step from 5 to 2 causes the rules to be renumbered 0, 2, 4, 6, and 8.

Examples

Set the rule numbering step to 2 for IPv4 basic ACL 2000.

```
<Sysname> system-view
[Sysname] acl basic 2000
[Sysname-acl-ipv4-basic-2000] step 2
```

Related commands

display acl

QoS policy commands

Traffic class commands

display traffic classifier

Use **display traffic classifier** to display traffic classes.

Syntax

```
display traffic classifier user-defined [ classifier-name ] [ slot slot-number ]
```

Views

Any view

Predefined user roles

network-admin

network-operator

Parameters

user-defined: Specifies user-defined traffic classes.

classifier-name: Specifies a traffic class by its name, a case-sensitive string of 1 to 31 characters. If you do not specify a traffic class, this command displays all traffic classes.

slot *slot-number*: Specifies an IRF member device by its member ID. If you do not specify a member device, this command displays the traffic classes for the master device.

Examples

Display all user-defined traffic classes.

```
<Sysname> display traffic classifier user-defined
```

```
User-defined classifier information:
```

```
Classifier: 1 (ID 100)
```

```
Operator: AND
```

```
Rule(s) :
```

```
  If-match acl 2000
```

```
Classifier: 2 (ID 101)
```

```
Operator: AND
```

```
Rule(s) :
```

```
  If-match protocol ipv6
```

```
Classifier: 3 (ID 102)
```

```
Operator: AND
```

```
Rule(s) :
```

```
  -none-
```

Table 15 Command output

Field	Description
Classifier	Traffic class name and its match criteria.
Operator	Match operator you set for the traffic class. If the operator is AND, the traffic class matches the packets that match all its match criteria. If the operator is OR, the traffic class matches the packets that match any of its match criteria.
Rule(s)	Match criteria.

if-match

Use **if-match** to define a match criterion.

Use **undo if-match** to delete a match criterion.

Syntax

if-match *match-criteria*

undo if-match *match-criteria*

Default

No match criterion is configured.

Views

Traffic class view

Predefined user roles

network-admin

Parameters

match-criteria: Specifies a match criterion. [Table 16](#) shows the available match criteria.

Table 16 Available match criteria

Option	Description
acl [ipv6] { <i>acl-number</i> name <i>acl-name</i> }	Matches an ACL. The value range for the <i>acl-number</i> argument is as follows: <ul style="list-style-type: none"> 2000 to 3999 for IPv4 ACLs. 2000 to 3999 for IPv6 ACLs. 4000 to 4999 for Layer 2 MAC ACLs. The <i>acl-name</i> argument is a case-insensitive string of 1 to 63 characters, which must start with an English letter. To avoid confusion, make sure the argument is not all .
any	Matches all packets.
control-plane protocol <i>protocol-name</i> <1-8>	Matches control plane protocols. The <i>protocol-name</i> <1-8> argument specifies a space-separated list of up to eight system-defined control plane protocols. For available system-defined control plane protocols, see Table 17 .
control-plane protocol-group <i>protocol-group-name</i>	Matches a control plane protocol group. The <i>protocol-group-name</i> argument can be critical , important , management , monitor , normal , or redirect .

Option	Description
customer-dot1p <i>dot1p-value&<1-8></i>	Matches 802.1p priority values in inner VLAN tags of double-tagged packets. The <i>dot1p-value&<1-8></i> argument specifies a space-separated list of up to eight 802.1p priority values. The value range for the <i>dot1p-value</i> argument is 0 to 7.
customer-vlan-id <i>vlan-id-list</i>	Matches VLAN IDs in inner VLAN tags of double-tagged packets. The <i>vlan-id-list</i> argument specifies a space-separated list of up to 10 VLAN items. Each item specifies a VLAN or a range of VLANs in the form of <i>vlan-id1 to vlan-id2</i> . The value for <i>vlan-id2</i> must be greater than or equal to the value for <i>vlan-id1</i> . The value range for the <i>vlan-id</i> argument is 1 to 4094.
destination-mac <i>mac-address</i>	Matches a destination MAC address. This option takes effect only on Ethernet interfaces.
dscp <i>dscp-value&<1-8></i>	Matches DSCP values. The <i>dscp-value&<1-8></i> argument specifies a space-separated list of up to eight DSCP values. The value range for the <i>dscp-value</i> argument is 0 to 63 or keywords shown in Table 19 .
ip-precedence <i>ip-precedence-value&<1-8></i>	Matches IP precedence values. The <i>ip-precedence-value&<1-8></i> argument specifies a space-separated list of up to eight IP precedence values. The value range for the <i>ip-precedence-value</i> argument is 0 to 7.
protocol <i>protocol-name</i>	Matches a protocol. The <i>protocol-name</i> argument can be arp , ipv6 , or ip .
qos-local-id <i>local-id-value</i>	Matches a local QoS ID in the range of 1 to 3999.
service-dot1p <i>dot1p-value&<1-8></i>	Matches 802.1p priority values in outer VLAN tags. The <i>dot1p-value&<1-8></i> argument specifies a space-separated list of up to eight 802.1p priority values. The value range for the <i>dot1p-value</i> argument is 0 to 7.
service-vlan-id <i>vlan-id-list</i>	Matches VLAN IDs in outer VLAN tags. The <i>vlan-id-list</i> argument specifies a space-separated list of up to 10 VLAN items. Each item specifies a VLAN or a range of VLANs in the form of <i>vlan-id1 to vlan-id2</i> . The value for <i>vlan-id2</i> must be greater than or equal to the value for <i>vlan-id1</i> . The value range for the <i>vlan-id</i> argument is 1 to 4094. You can use this option to match single-tagged packets.
source-mac <i>mac-address</i>	Matches a source MAC address. This option takes effect only on Ethernet interfaces.

Table 17 Available system-defined control plane protocols

Protocol	Description
arp	ARP packets
arp-snooping	ARP snooping packets
bfd	BFD packets
dhcp	DHCP packets
dhcp-snooping	DHCP snooping packets
dhcpv6	IPv6 DHCP packets

Protocol	Description
dldp	DLDP packets
dot1x	802.1X packets
icmp	ICMP packets
icmpv6	ICMPv6 packets
ip-option	IPv4 packets with the Options field
ipv6-option	IPv6 packets with the Options field
lACP	LACP packets
lldp	LLDP packets
mvrp	MVRP packets (including GVRP packets)
ssh	SSH packets
stp	STP packets
tacacs	TACACS packets
telnet	Telnet packets

Usage guidelines

In a traffic class with the logical OR operator, you can configure multiple **if match** commands for any of the available match criteria.

When you configure a match criterion that can have multiple values in one **if-match** command, follow these restrictions and guidelines:

- You can specify up to eight values for any of the following match criteria in one **if-match** command:
 - 802.1p priority.
 - DSCP.
 - IP precedence.
 - VLAN ID.
- If a packet matches one of the specified values, it matches the **if-match** command.
- To delete a criterion that has multiple values, the specified values in the **undo if-match** command must be the same as those specified in the **if-match** command. The order of the values can be different.

When you configure ACL-based match criteria, follow these restrictions and guidelines:

- If the ACL used as a match criterion does not exist, the traffic class cannot be applied to hardware.
- In a traffic class, you can add two **if-match** statements that use the same ACL as the match criterion. In one statement, specify the ACL by its name. In the other statement, specify the ACL by its number.
- The ACL is used for classification only and the permit/deny actions in ACL rules are ignored. Actions taken on matching packets are defined in traffic behaviors.

You can use both AND and OR operators to define the match relationships between the criteria for a class. For example, you can define relationships among three match criteria in traffic class **classA** as follows:

```
traffic classifier classB operator and
if-match criterion 1
if-match criterion 2
```

```
traffic classifier classA operator or
if-match criterion 3
```

If a traffic class in a QoS policy includes the **customer-vlan-id** match criterion, the QoS policy can be applied only to interfaces.

If a traffic class includes both the **control-plane protocol** or **control-plane protocol-group** criterion and other criteria, the QoS policy that contains the traffic class cannot be applied correctly.

If any traffic class in a QoS policy includes the **control-plane protocol** or **control-plane protocol-group** match criterion, the QoS policy can be applied only to a control plane.

For the **customer-vlan-id** and **service-vlan-id** match criteria, you can configure multiple values in one **if-match** command.

Examples

Define a match criterion for traffic class **class1** to match the packets with a destination MAC address of 0050-ba27-bed3.

```
<Sysname> system-view
[Sysname] traffic classifier class1
[Sysname-classifier-class1] if-match destination-mac 0050-ba27-bed3
```

Define a match criterion for traffic class **class2** to match the packets with a source MAC address of 0050-ba27-bed2.

```
<Sysname> system-view
[Sysname] traffic classifier class2
[Sysname-classifier-class2] if-match source-mac 0050-ba27-bed2
```

Define a match criterion for traffic class **class1** to match the double-tagged packets with 802.1p priority 3 in the inner VLAN tag.

```
<Sysname> system-view
[Sysname] traffic classifier class1
[Sysname-classifier-class1] if-match customer-dot1p 3
```

Define a match criterion for traffic class **class1** to match the packets with 802.1p priority 5 in the outer VLAN tag.

```
<Sysname> system-view
[Sysname] traffic classifier class1
[Sysname-classifier-class1] if-match service-dot1p 5
```

Define a match criterion for traffic class **class1** to match advanced ACL 3101.

```
<Sysname> system-view
[Sysname] traffic classifier class1
[Sysname-classifier-class1] if-match acl 3101
```

Define a match criterion for traffic class **class1** to match the ACL named **flow**.

```
<Sysname> system-view
[Sysname] traffic classifier class1
[Sysname-classifier-class1] if-match acl name flow
```

Define a match criterion for traffic class **class1** to match advanced IPv6 ACL 3101.

```
<Sysname> system-view
[Sysname] traffic classifier class1
[Sysname-classifier-class1] if-match acl ipv6 3101
```

Define a match criterion for traffic class **class1** to match the IPv6 ACL named **flow**.

```
<Sysname> system-view
[Sysname] traffic classifier class1
[Sysname-classifier-class1] if-match acl ipv6 name flow
```

Define a match criterion for traffic class **class1** to match all packets.

```
<Sysname> system-view
[Sysname] traffic classifier class1
[Sysname-classifier-class1] if-match any
```

Define a match criterion for traffic class **class1** to match the packets with a DSCP value of 1, 6, or 9.

```
<Sysname> system-view
[Sysname] traffic classifier class1
[Sysname-classifier-class1] if-match dscp 1 6 9
```

Define a match criterion for traffic class **class1** to match the packets with an IP precedence value of 1 or 6.

```
<Sysname> system-view
[Sysname] traffic classifier class1
[Sysname-classifier-class1] if-match ip-precedence 1 6
```

Define a match criterion for traffic class **class1** to match IP packets.

```
<Sysname> system-view
[Sysname] traffic classifier class1
[Sysname-classifier-class1] if-match protocol ip
```

Define a match criterion for traffic class **class1** to match double-tagged packets with VLAN ID 1, 6, or 9 in the inner VLAN tag.

```
<Sysname> system-view
[Sysname] traffic classifier class1
[Sysname-classifier-class1] if-match customer-vlan-id 1 6 9
```

Define a match criterion for traffic class **class1** to match the packets with VLAN ID 2, 7, or 10 in the outer VLAN tag.

```
<Sysname> system-view
[Sysname] traffic classifier class1
[Sysname-classifier-class1] if-match service-vlan-id 2 7 10
```

Define a match criterion for traffic class **class1** to match the packets with a local QoS ID of 3.

```
<Sysname> system-view
[Sysname] traffic classifier class1
[Sysname-classifier-class1] if-match qos-local-id 3
```

Define a match criterion for traffic class **class1** to match ARP protocol packets.

```
<Sysname> system-view
[Sysname] traffic classifier class1
[Sysname-classifier-class1] if-match control-plane protocol arp
```

Define a match criterion for traffic class **class1** to match packets of the protocols in protocol group **normal**.

```
<Sysname> system-view
[Sysname] traffic classifier class1
[Sysname-classifier-class1] if-match control-plane protocol-group normal
```

traffic classifier

Use **traffic classifier** to create a traffic class and enter its view, or enter the view of an existing traffic class.

Use **undo traffic classifier** to delete a traffic class.

Syntax

```
traffic classifier classifier-name [ operator { and | or } ]
```

```
undo traffic classifier classifier-name
```

Default

No traffic classes exist.

Views

System view

Predefined user roles

network-admin

Parameters

classifier-name: Specifies a name for the traffic class, a case-sensitive string of 1 to 31 characters.

operator: Sets the operator to logic AND (the default) or OR for the traffic class.

and: Specifies the logic AND operator. The traffic class matches the packets that match all its criteria.

or: Specifies the logic OR operator. The traffic class matches the packets that match any of its criteria.

Examples

```
# Create a traffic class named class1.  
<Sysname> system-view  
[Sysname] traffic classifier class1  
[Sysname-classifier-class1]
```

Related commands

```
display traffic classifier
```

Traffic behavior commands

accounting

Use **accounting** to configure a traffic accounting action in a traffic behavior.

Use **undo accounting** to restore the default.

Syntax

```
accounting { byte | packet }
```

```
undo accounting
```

Default

No traffic accounting action is configured.

Views

Traffic behavior view

Predefined user roles

network-admin

Parameters

byte: Counts traffic in bytes.

packet: Counts traffic in packets.

Examples

Configure a traffic accounting action in traffic behavior **database** to count traffic in bytes.

```
<Sysname> system-view
[Sysname] traffic behavior database
[Sysname-behavior-database] accounting byte
```

car

Use **car** to configure a CAR action in absolute value in a traffic behavior.

Use **undo car** to restore the default.

Syntax

car cir *committed-information-rate* [**cbs** *committed-burst-size* [**ebs** *excess-burst-size*]] [**green** *action* | **red** *action* | **yellow** *action*] * [**hierarchy-car** *hierarchy-car-name* [**mode** { **and** | **or** }]]

car cir *committed-information-rate* [**cbs** *committed-burst-size*] **pir** *peak-information-rate* [**ebs** *excess-burst-size*] [**green** *action* | **red** *action* | **yellow** *action*] * [**hierarchy-car** *hierarchy-car-name* [**mode** { **and** | **or** }]]

undo car

Default

No CAR action is configured.

Views

Traffic behavior view

Predefined user roles

network-admin

Parameters

cir *committed-information-rate*: Specifies the committed information rate (CIR) in kbps, which is an average traffic rate. The value range for *committed-information-rate* is 8 to 160000000, in increments of 8.

cbs *committed-burst-size*: Specifies the committed burst size (CBS) in bytes. The value range for *committed-burst-size* is 512 to 256000000, in increments of 512. The default value for this argument is the product of 62.5 and the CIR and must be an integral multiple of 512. When the product is not an integral multiple of 512, it is rounded up to the nearest integral multiple of 512 that is greater than the product. A default value greater than 256000000 is converted to 256000000.

ebs *excess-burst-size*: Specifies the excess burst size (EBS) in bytes. The value range for *excess-burst-size* is 0 to 256000000, in increments of 512. If the PIR is configured, the default EBS is the product of 62.5 and the PIR and must be an integral multiple of 512. When the product is not an integral multiple of 512, it is rounded up to the nearest integral multiple of 512 that is greater than the product. A default value greater than 256000000 is converted to 256000000.

pir *peak-information-rate*: Specifies the peak information rate (PIR) in kbps. The value range for *peak-information-rate* is 8 to 160000000, in increments of 8.

green *action*: Specifies the action to take on packets that conform to the CIR. The default setting is **pass**.

red *action*: Specifies the action to take on packets that conform to neither CIR nor PIR. The default setting is **discard**.

yellow action: Specifies the action to take on packets that conform to the PIR but not to the CIR. The default setting is **pass**.

action: Sets the action to take on the packet:

- **discard:** Drops the packet.
- **pass:** Permits the packet to pass through.
- **remark-dot1p-pass new-cos:** Sets the 802.1p priority value of the 802.1p packet to *new-cos* and permits the packet to pass through. The *new-cos* argument is in the range of 0 to 7.
- **remark-dscp-pass new-dscp:** Sets the DSCP value of the packet to *new-dscp* and permits the packet to pass through. The *new-dscp* argument is in the range of 0 to 63.
- **remark-ip-pass new-local-precedence:** Sets the local precedence value of the packet to *new-local-precedence* and permits the packet to pass through. The *new-local-precedence* argument is in the range of 0 to 7.

hierarchy-car-name: Specifies the name of the used hierarchical CAR action.

mode: Specifies the collaborating mode of the hierarchical CAR action and the common CAR action:

- **and:** Specifies the AND mode (the default mode). In this mode, the traffic rate of a flow is limited by both the common CAR and the total traffic rate defined with hierarchical CAR.
- **or:** Specifies the OR mode. In this mode, a flow can perform one of the following operations:
 - Pass through at the rate equal to the common CAR applied to it.
 - Pass through at a higher rate if the total traffic rate of all flows does not exceed the hierarchical CAR.

Usage guidelines

To use two rates for traffic policing, configure the **car** command with the **pir peak-information-rate** option. To use one rate for traffic policing, configure the **car** command without the **pir peak-information-rate** option.

If you execute the **car** command multiple times in the same traffic behavior, the most recent configuration takes effect.

Examples

Configure a CAR action in traffic behavior **database**:

- Set the CIR to 200 kbps, CBS to 51200 bytes, and EBS to 0.
- Transmit the conforming packets, and mark the excess packets with DSCP value 0 and transmit them.

```
<Sysname> system-view
```

```
[Sysname] traffic behavior database
```

```
[Sysname-behavior-database] car cir 200 cbs 51200 ebs 0 green pass red remark-dscp-pass 0
```

display traffic behavior

Use **display traffic behavior** to display traffic behaviors.

Syntax

```
display traffic behavior user-defined [ behavior-name ] [ slot slot-number ]
```

Views

Any view

Predefined user roles

network-admin

network-operator

Parameters

user-defined: Specifies user-defined traffic behaviors.

behavior-name: Specifies a behavior by its name, a case-sensitive string of 1 to 31 characters. If you do not specify a traffic behavior, this command displays all traffic behaviors.

slot slot-number: Specifies an IRF member device by its member ID. If you do not specify a member device, this command displays the traffic behaviors for the master device.

Examples

Display all user-defined traffic behaviors.

```
<Sysname> display traffic behavior user-defined
```

```
User-defined behavior information:
```

```
Behavior: 1 (ID 100)
```

```
Marking:
```

```
Remark dscp 3
```

```
Committed Access Rate:
```

```
CIR 200 (kbps), CBS 51200 (Bytes), EBS 512 (Bytes)
```

```
Green action : pass
```

```
Yellow action : pass
```

```
Red action   : discard
```

```
Behavior: 2 (ID 101)
```

```
Accounting enable: Packet
```

```
Filter enable: Permit
```

```
Marking:
```

```
Remark dscp 4
```

```
Redirecting:
```

```
Redirect to the CPU
```

Table 18 Command output

Field	Description
Behavior	Name and contents of a traffic behavior.
Marking	Information about priority marking.
Remark dscp	Action of setting the DSCP value for packets.
Committed Access Rate	Information about the CAR action.
Green action	Action to take on green packets.
Yellow action	Action to take on yellow packets.
Red action	Action to take on red packets.
Accounting enable	Class-based accounting action.
Filter enable	Traffic filtering action.
Redirecting	Information about traffic redirecting.
Mirroring	Information about traffic mirroring.
Pre	IP precedence.

filter

Use **filter** to configure a traffic filtering action in a traffic behavior.

Use **undo filter** to restore the default.

Syntax

filter { **deny** | **permit** }

undo filter

Default

No traffic filtering action is configured.

Views

Traffic behavior view

Predefined user roles

network-admin

Parameters

deny: Drops packets.

permit: Transmits packets.

Examples

Configure a traffic filtering action as **deny** in traffic behavior **database**.

```
<Sysname> system-view
[Sysname] traffic behavior database
[Sysname-behavior-database] filter deny
```

nest top-most

Use **nest top-most** to configure an outer VLAN tag adding action in a traffic behavior.

Use **undo nest top-most** to restore the default.

Syntax

nest top-most vlan *vlan-id*

undo nest top-most

Default

No outer VLAN tag adding action is configured.

Views

Traffic behavior view

Predefined user roles

network-admin

Parameters

vlan-id *vlan-id*: Specifies the VLAN ID to be added in the outer VLAN tag, in the range of 1 to 4094.

Usage guidelines

If a QoS policy contains an outer VLAN tag adding action, apply it only to the incoming traffic of an interface.

If you execute the **nest top-most** command multiple times in the same traffic behavior, the most recent configuration takes effect.

Examples

```
# Configure traffic behavior b1 to add an outer VLAN tag with VLAN ID 123.
<Sysname> system-view
[Sysname] traffic behavior b1
[Sysname-behavior-b1] nest top-most vlan 123
```

redirect

Use **redirect** to configure a traffic redirecting action in a traffic behavior.

Use **undo redirect** to restore the default.

Syntax

```
redirect { cpu | interface interface-type interface-number }
undo redirect { cpu | interface interface-type interface-number }
```

Default

No traffic redirecting action is configured.

Views

Traffic behavior view

Predefined user roles

network-admin

Parameters

cpu: Redirects traffic to the CPU.

interface *interface-type interface-number*: Redirects traffic to an interface specified by its type and number.

Usage guidelines

If you execute the **redirect** command multiple times in the same traffic behavior, the most recent configuration takes effect.

A traffic redirecting action takes effect only when the QoS policy is applied to the inbound direction.

For traffic redirecting to an access port, make sure the PVID of the interfaces to which the QoS policy is applied is the same as the PVID of the access port. Otherwise, the access port drops redirected packets.

For traffic redirecting to a trunk port, make sure the PVID of the interfaces to which the QoS policy is applied is in the allowed VLAN list of the trunk port. Otherwise, the trunk port drops redirected packets.

If a QoS policy applied to a user profile contains the **redirect interface** action, make sure the interface and the incoming interface of packets are in the same VLAN.

Examples

```
# Configure redirecting traffic to GigabitEthernet 1/0/1 in traffic behavior database.
<Sysname> system-view
[Sysname] traffic behavior database
```

```
[Sysname-behavior-database] redirect interface gigabitethernet 1/0/1
```

Related commands

classifier behavior

qos policy

traffic behavior

remark customer-vlan-id

Use **remark customer-vlan-id** to configure a CVLAN marking action in a traffic behavior.

Use **undo remark customer-vlan-id** to restore the default.

Syntax

remark customer-vlan-id *vlan-id*

undo remark customer-vlan-id

Default

No CVLAN marking action is configured.

Views

Traffic behavior view

Predefined user roles

network-admin

Parameters

vlan-id: Specifies a CVLAN ID in the range of 1 to 4094.

Examples

Configure traffic behavior **b1** to mark matching packets with CVLAN 111.

```
<Sysname> system-view
```

```
[Sysname] traffic behavior b1
```

```
[Sysname-behavior-b1] remark customer-vlan-id 111
```

remark dot1p

Use **remark dot1p** to configure an 802.1p priority marking action or an inner-to-outer tag priority copying action in a traffic behavior.

Use **undo remark dot1p** to restore the default.

Syntax

remark [**green** | **red** | **yellow**] **dot1p** *dot1p-value*

undo remark [**green** | **red** | **yellow**] **dot1p**

remark dot1p customer-dot1p-trust

undo remark dot1p

Default

No 802.1p priority marking action or inner-to-outer tag priority copying action is configured.

Views

Traffic behavior view

Predefined user roles

network-admin

Parameters

green: Specifies green packets.

red: Specifies red packets.

yellow: Specifies yellow packets.

dot1p-value: Specifies the 802.1p priority to be marked for packets, in the range of 0 to 7.

customer-dot1p-trust: Copies the 802.1p priority value in the inner VLAN tag to the outer VLAN tag.

Usage guidelines

The **remark dot1p dot1p-value** and **remark dot1p customer-dot1p-trust** commands override each other in the same traffic behavior. The **remark dot1p customer-dot1p-trust** command does not take effect on single-tagged packets.

If you execute the **remark dot1p dot1p-value** command multiple times for the same color, the most recent configuration takes effect.

Examples

Configure traffic behavior **database** to mark matching traffic with 802.1p 2.

```
<Sysname> system-view
[Sysname] traffic behavior database
[Sysname-behavior-database] remark dot1p 2
```

Configure an inner-to-outer tag priority copying action in traffic behavior **database**.

```
<Sysname> system-view
[Sysname] traffic behavior database
[Sysname-behavior-database] remark dot1p customer-dot1p-trust
```

remark drop-precedence

Use **remark drop-precedence** to configure a drop priority marking action in a traffic behavior.

Use **undo remark drop-precedence** to restore the default.

Syntax

remark drop-precedence *drop-precedence-value*

undo remark drop-precedence

Default

No drop priority marking action is configured.

Views

Traffic behavior view

Predefined user roles

network-admin

Parameters

drop-precedence-value: Specifies the drop priority to be marked for packets, in the range of 0 to 2.

Usage guidelines

A traffic behavior that includes a drop priority marking action can be applied only to the inbound direction.

If you execute the **remark drop-precedence** command multiple times in the same traffic behavior, the most recent configuration takes effect.

Examples

```
# Configure traffic behavior database to mark matching traffic with drop priority 2.  
<Sysname> system-view  
[Sysname] traffic behavior database  
[Sysname-behavior-database] remark drop-precedence 2
```

remark dscp

Use **remark dscp** to configure a DSCP marking action in a traffic behavior.

Use **undo remark dscp** to delete the action.

Syntax

```
remark [ green | red | yellow ] dscp dscp-value  
undo remark [ green | red | yellow ] dscp
```

Default

No DSCP marking action is configured.

Views

Traffic behavior view

Predefined user roles

network-admin

Parameters

green: Specifies green packets.

red: Specifies red packets.

yellow: Specifies yellow packets.

dscp-value: Specifies a DSCP value, which can be a number from 0 to 63 or a keyword in [Table 19](#).

Table 19 DSCP keywords and values

Keyword	DSCP value (binary)	DSCP value (decimal)
af11	001010	10
af12	001100	12
af13	001110	14
af21	010010	18
af22	010100	20
af23	010110	22
af31	011010	26
af32	011100	28
af33	011110	30

Keyword	DSCP value (binary)	DSCP value (decimal)
af41	100010	34
af42	100100	36
af43	100110	38
cs1	001000	8
cs2	010000	16
cs3	011000	24
cs4	100000	32
cs5	101000	40
cs6	110000	48
cs7	111000	56
default	000000	0
ef	101110	46

Examples

Configure traffic behavior **database** to mark matching traffic with DSCP 6.

```
<Sysname> system-view
[Sysname] traffic behavior database
[Sysname-behavior-database] remark dscp 6
```

remark ip-precedence

Use **remark ip-precedence** to configure an IP precedence marking action in a traffic behavior.

Use **undo remark ip-precedence** to delete the action.

Syntax

remark ip-precedence *ip-precedence-value*

undo remark ip-precedence

Default

No IP precedence marking action is configured.

Views

Traffic behavior view

Predefined user roles

network-admin

Parameters

ip-precedence-value: Specifies the IP precedence value to be marked for packets, in the range of 0 to 7.

Examples

Set the IP precedence to 6 for packets.

```
<Sysname> system-view
[Sysname] traffic behavior database
[Sysname-behavior-database] remark ip-precedence 6
```

remark local-precedence

Use **remark local-precedence** to configure a local precedence marking action in a traffic behavior.

Use **undo remark local-precedence** to delete the action.

Syntax

remark [**green** | **red** | **yellow**] **local-precedence** *local-precedence-value*

undo remark [**green** | **red** | **yellow**] **local-precedence**

Default

No local precedence marking action is configured.

Views

Traffic behavior view

Predefined user roles

network-admin

Parameters

green: Specifies green packets.

red: Specifies red packets.

yellow: Specifies yellow packets.

local-precedence-value: Specifies the local precedence to be marked for packets, in the range of 0 to 7.

Examples

```
# Configure traffic behavior database to mark matching traffic with local precedence 2.
```

```
<Sysname> system-view
```

```
[Sysname] traffic behavior database
```

```
[Sysname-behavior-database] remark local-precedence 2
```

remark qos-local-id

Use **remark qos-local-id** to configure a local QoS ID marking action in a traffic behavior.

Use **undo remark qos-local-id** to restore the default.

Syntax

remark qos-local-id *local-id-value*

undo remark qos-local-id

Default

No local QoS ID marking action is configured.

Views

Traffic behavior view

Predefined user roles

network-admin

Parameters

local-id-value: Specifies the local QoS ID to be marked for packets, in the range of 1 to 3999.

Usage guidelines

You can use one QoS policy to mark the local QoS ID for packets in the inbound direction. Then, you can use another QoS policy to apply other QoS features in the outbound direction based on the marked local QoS ID.

If you execute the **remark qos-local-id** command multiple times in the same traffic behavior, the most recent configuration takes effect.

Examples

Configure the action of marking packets with local QoS ID 2.

```
<Sysname> system-view
[Sysname] traffic behavior database
[Sysname-behavior-database] remark qos-local-id 2
```

remark service-vlan-id

Use **remark service-vlan-id** to configure an SVLAN marking action in a traffic behavior.

Use **undo remark service-vlan-id** to restore the default.

Syntax

remark service-vlan-id *vlan-id*

undo remark service-vlan-id

Default

No SVLAN marking action is configured.

Views

Traffic behavior view

Predefined user roles

network-admin

Parameters

vlan-id: Specifies an SVLAN ID in the range of 1 to 4094.

Examples

Configure traffic behavior **b1** to mark matching packets with SVLAN 222.

```
<Sysname> system-view
[Sysname] traffic behavior b1
[Sysname-behavior-b1] remark service-vlan-id 222
```

traffic behavior

Use **traffic behavior** to create a traffic behavior and enter its view, or enter the view of an existing traffic behavior.

Use **undo traffic behavior** to delete a traffic behavior.

Syntax

traffic behavior *behavior-name*

undo traffic behavior *behavior-name*

Default

No traffic behaviors exist.

Views

System view

Predefined user roles

network-admin

Parameters

behavior-name: Specifies a name for the traffic behavior, a case-sensitive string of 1 to 31 characters.

Examples

```
# Create a traffic behavior named behavior1.
```

```
<Sysname> system-view  
[Sysname] traffic behavior behavior1  
[Sysname-behavior-behavior1]
```

Related commands

display traffic behavior

QoS policy commands

classifier behavior

Use **classifier behavior** to associate a traffic behavior with a traffic class in a QoS policy.

Use **undo classifier** to delete a class-behavior association from a QoS policy.

Syntax

classifier *classifier-name* **behavior** *behavior-name* [**insert-before** *before-classifier-name*]

undo classifier *classifier-name*

Default

No traffic behavior is associated with a traffic class.

Views

QoS policy view

Predefined user roles

network-admin

Parameters

classifier-name: Specifies a traffic class by its name, a case-sensitive string of 1 to 31 characters.

behavior-name: Specifies a traffic behavior by its name, a case-sensitive string of 1 to 31 characters.

insert-before *before-classifier-name*: Inserts the new traffic class before an existing traffic class in the QoS policy. The *before-classifier-name* argument specifies an existing traffic class by its name, a case-sensitive string of 1 to 31 characters. If you do not specify the **insert-before** *before-classifier-name* option, the new traffic class is placed at the end of the QoS policy.

Usage guidelines

A traffic class can be associated only with one traffic behavior in a QoS policy.

If the specified traffic class or traffic behavior does not exist, the system defines a null traffic class or traffic behavior.

Examples

```
# Associate traffic class database with traffic behavior test in QoS policy user1.
```

```
<Sysname> system-view
[Sysname] qos policy user1
[Sysname-qospolicy-user1] classifier database behavior test
```

```
# Associate traffic class database with traffic behavior test in QoS policy user1, and insert traffic class database before an existing traffic class named class-a.
```

```
<Sysname> system-view
[Sysname] qos policy user1
[Sysname-qospolicy-user1] classifier database behavior test insert-before class-a
```

Related commands

qos policy

control-plane

Use **control-plane** to enter control plane view.

Syntax

```
control-plane slot slot-number
```

Views

System view

Predefined user roles

network-admin

Parameters

slot *slot-number*: Specifies an IRF member device by its member ID.

Usage guidelines

A QoS policy applied in control plane view takes effect on all packets to the control plane except the packets sent from the management interface.

Examples

```
# Enter the control plane view of slot 3.
```

```
<Sysname> system-view
[Sysname] control-plane slot 3
[Sysname-cp-slot3]
```

display qos policy

Use **display qos policy** to display QoS policies.

Syntax

```
display qos policy user-defined [ policy-name [ classifier classifier-name ] ] [ slot slot-number ]
```

Views

Any view

Predefined user roles

network-admin

network-operator

Parameters

user-defined: Specifies user-defined QoS policies.

policy-name: Specifies a QoS policy by its name, a case-sensitive string of 1 to 31 characters. If you do not specify a QoS policy, this command displays all user-defined QoS policies.

classifier classifier-name: Specifies a traffic class by its name, a case-sensitive string of 1 to 31 characters. If you do not specify a traffic class, this command displays all traffic classes.

slot slot-number: Specifies an IRF member device by its member ID. If you do not specify a member device, this command displays the QoS policies for the master device.

Examples

Display all user-defined QoS policies.

```
<Sysname> display qos policy user-defined
```

```
User-defined QoS policy information:

Policy: 1 (ID 100)
Classifier: 1 (ID 100)
  Behavior: 1
  Marking:
    Remark dscp 3
  Committed Access Rate:
    CIR 112 (kbps), CBS 51200 (Bytes), EBS 512 (Bytes)
    Green action : pass
    Yellow action : pass
    Red action   : discard
Classifier: 2 (ID 101)
  Behavior: 2
  Accounting enable: Packet
  Filter enable: Permit
  Marking:
    Remark dot1p 4
Classifier: 3 (ID 102)
  Behavior: 3
  -none-
```

For the output description, see [Table 15](#) and [Table 18](#).

display qos policy control-plane

Use **display qos policy control-plane** to display QoS policies applied to a control plane.

Syntax

```
display qos policy control-plane slot slot-number
```

Views

Any view

Predefined user roles

network-admin

network-operator

Parameters

slot *slot-number*: Specifies an IRF member device by its member ID.

Examples

Display the QoS policy applied to the control plane of slot 2.

```
<Sysname> display qos policy control-plane slot 2
```

```
Control plane slot 2
```

```
Direction: Inbound
```

```
Policy: 1
```

```
Classifier: 1
```

```
Operator: AND
```

```
Rule(s) :
```

```
  If-match acl 2000
```

```
Behavior: 1
```

```
Marking:
```

```
  Remark dscp 3
```

```
Committed Access Rate:
```

```
  CIR 112 (kbps), CBS 51200 (Bytes), EBS 512 (Bytes)
```

```
Green action  : pass
```

```
Yellow action  : pass
```

```
Red action     : discard
```

```
Green packets : 0 (Packets) 0 (Bytes)
```

```
Yellow packets: 0 (Packets) 0 (Bytes)
```

```
Red packets   : 0 (Packets) 0 (Bytes)
```

```
Classifier: 2
```

```
Operator: AND
```

```
Rule(s) :
```

```
  If-match protocol ipv6
```

```
Behavior: 2
```

```
Accounting enable:
```

```
  0 (Packets)
```

```
Filter enable: Permit
```

```
Marking:
```

```
  Remark dscp 3
```

```
Classifier: 3
```

```
Operator: AND
```

```
Rule(s) :
```

```
  -none-
```

```
Behavior: 3
```

```
  -none-
```

Table 20 Command output

Field	Description
Direction	Inbound direction on the control plane.
Green packets	Statistics about green packets.

Field	Description
Yellow packets	Statistics about yellow packets.
Red packets	Statistics about red packets.

For the description of other fields, see [Table 15](#) and [Table 18](#).

display qos policy control-plane pre-defined

Use **display qos policy control-plane pre-defined** to display predefined control plane QoS policies.

Syntax

```
display qos policy control-plane pre-defined [ slot slot-number ]
```

Views

Any view

Predefined user roles

network-admin
network-operator

Parameters

slot slot-number: Specifies an IRF member device by its member ID. If you do not specify a member device, this command displays predefined control plane QoS policies for all member devices.

Examples

```
# Display the predefined control plane QoS policy of slot 1.
```

```
<Sysname> display qos policy control-plane pre-defined slot 1
```

```
Pre-defined policy information slot 1
```

Protocol	Priority	Bandwidth	Group
Default	N/A	0 (kbps)	N/A
ARP	8	256 (kbps)	normal
DHCP Snooping	17	256 (kbps)	redirect
DHCP	15	256 (kbps)	normal
802.1x	9	128 (kbps)	important
STP	37	256 (kbps)	critical
LACP	34	64 (kbps)	critical
MVRP	11	256 (kbps)	critical
ICMP	9	640 (kbps)	monitor
IPOPTION	20	64 (kbps)	normal
IPOPTIONv6	13	64 (kbps)	normal
LLDP	25	128 (kbps)	important
DLDP	24	64 (kbps)	critical
TELNET	10	1280 (kbps)	management
SSH	10	1280 (kbps)	management
TACACS	10	1280 (kbps)	management
RADIUS	10	1280 (kbps)	management
HTTP	10	64 (kbps)	management
HTTPS	10	64 (kbps)	management
ARP Snooping	10	256 (kbps)	redirect

ICMPv6	1	512 (kbps)	monitor
DHCPv6	12	256 (kbps)	normal

Table 21 Command output

Field	Description
Pre-defined control plane policy	Contents of the predefined control plane QoS policy.
Default	Protocols other than those listed.
Group	Protocol group of the protocol.

For descriptions of other fields, see [Table 17](#).

display qos policy global

Use **display qos policy global** to display global QoS policies.

Syntax

```
display qos policy global [ slot slot-number ] [ inbound | outbound ]
```

Views

Any view

Predefined user roles

network-admin
network-operator

Parameters

inbound: Displays inbound global QoS policies. An inbound global QoS policy applies to the incoming traffic globally.

outbound: Displays outbound global QoS policies. An outbound global QoS policy applies to the outgoing traffic globally.

slot *slot-number*: Specifies an IRF member device by its member ID. If you do not specify a member device, this command displays global QoS policies for the master device.

Usage guidelines

If you do not specify a direction, this command displays both inbound and outbound global QoS policies.

Examples

```
# Display QoS policies applied globally.
<Sysname> display qos policy global
  Direction: Inbound
  Policy: 1
  Classifier: 1
    Operator: AND
  Rule(s) :
    If-match acl 2000
  Behavior: 1
  Marking:
    Remark dscp 3
  Committed Access Rate:
    CIR 112 (kbps), CBS 51200 (Bytes), EBS 512 (Bytes)
```

```

Green action : pass
Yellow action : pass
Red action : discard
Green packets : 0 (Packets) 0 (Bytes)
Yellow packets: 0 (Packets) 0 (Bytes)
Red packets : 0 (Packets) 0 (Bytes)
Classifier: 2
Operator: AND
Rule(s) :
  If-match protocol ipv6
Behavior: 2
Accounting enable:
  0 (Packets)
Filter enable: Permit
Marking:
  Remark dscp 3
Classifier: 3
Operator: AND
Rule(s) :
  -none-
Behavior: 3
  -none-

```

Table 22 Command output

Field	Description
Direction	Direction (inbound or outbound) in which the QoS policy is applied.
Green packets	Statistics about green packets.
Yellow packets	Statistics about yellow packets.
Red packets	Statistics about red packets.

For the description of other fields, see [Table 15](#) and [Table 18](#).

display qos policy interface

Use **display qos policy interface** to display the QoS policies applied to interfaces or PVCs.

Syntax

```
display qos policy interface [ interface-type interface-number ] [ slot slot-number ] [ inbound | outbound ]
```

Views

Any view

Predefined user roles

network-admin
network-operator

Parameters

interface-type interface-number: Specifies an interface by its type and number.

slot slot-number. Specifies an IRF member device by its member ID. If you do not specify an IRF member device, this command displays QoS policies on the master device. Only virtual interfaces such as VLAN interfaces and aggregate interfaces support this option.

inbound: Displays the QoS policy applied to the incoming traffic of the specified interface.

outbound: Displays the QoS policy applied to the outgoing traffic of the specified interface.

Usage guidelines

If you do not specify a direction, this command displays the QoS policy applied to incoming traffic and the QoS policy applied to outgoing traffic.

Examples

Display the QoS policy applied to the incoming traffic of GigabitEthernet 1/0/1.

```
<Sysname> display qos policy interface gigabitethernet 1/0/1 inbound
```

```
Interface: GigabitEthernet1/0/1
```

```
Direction: Inbound
```

```
Policy: 1
```

```
Classifier: 1
```

```
Matched : 0 (Packets) 0 (Bytes)
```

```
5-minute statistics:
```

```
Forwarded: 0/0 (pps/bps)
```

```
Dropped : 0/0 (pps/bps)
```

```
Operator: AND
```

```
Rule(s) :
```

```
If-match acl 2000
```

```
Behavior: 1
```

```
Marking:
```

```
Remark dscp 3
```

```
Committed Access Rate:
```

```
CIR 112 (kbps), CBS 51200 (Bytes), EBS 512 (Bytes)
```

```
Green action : pass
```

```
Yellow action : pass
```

```
Red action : discard
```

```
Green packets : 0 (Packets) 0 (Bytes)
```

```
Yellow packets: 0 (Packets) 0 (Bytes)
```

```
Red packets : 0 (Packets) 0 (Bytes)
```

```
Classifier: 2
```

```
Matched : 0 (Packets) 0 (Bytes)
```

```
5-minute statistics:
```

```
Forwarded: 0/0 (pps/bps)
```

```
Dropped : 0/0 (pps/bps)
```

```
Operator: AND
```

```
Rule(s) :
```

```
If-match protocol ipv6
```

```
Behavior: 2
```

```
Accounting enable:
```

```
0 (Packets)
```

```
Filter enable: Permit
```

```
Marking:
```

```
Remark dscp 3
```

```
Classifier: 3
  Matched : 0 (Packets) 0 (Bytes)
  5-minute statistics:
    Forwarded: 0/0 (pps/bps)
    Dropped   : 0/0 (pps/bps)
  Operator: AND
  Rule(s)  :
    -none-
  Behavior: 3
    -none-
```

Display the QoS policies applied to all interfaces.

```
<Sysname> display qos policy interface
Interface: GigabitEthernet1/0/1
  Direction: Inbound
  Policy: a
  Classifier: a
    Operator: AND
    Rule(s)  :
      If-match any
    Behavior: a
    Mirroring:
      Mirror to the interface: GigabitEthernet1/0/2
    Committed Access Rate:
      CIR 112 (kbps), CBS 51200 (Bytes), EBS 0 (Bytes)
      Green action   : pass
      Yellow action  : pass
      Red action     : discard
      Green packets  : 0 (Packets)
      Red packets    : 0 (Packets)
```

```
Interface: GigabitEthernet1/0/3
  Direction: Inbound
  Policy: b
  Classifier: b
    Operator: AND
    Rule(s)  :
      If-match any
    Behavior: b
    Committed Access Rate:
      CIR 112 (kbps), CBS 51200 (Bytes), EBS 0 (Bytes)
      Green action   : pass
      Yellow action  : pass
      Red action     : discard
      Green packets  : 0 (Packets)
      Red packets    : 0 (Packets)
```

```
Interface: GigabitEthernet1/0/3
  Direction: Inbound
```

```

Policy: a
Classifier: a
  Operator: AND
  Rule(s) :
    If-match any
Behavior: a
Mirroring:
  Mirror to the interface: GigabitEthernet1/0/4
Committed Access Rate:
  CIR 112 (kbps), CBS 51200 (Bytes), EBS 0 (Bytes)
  Green action  : pass
  Yellow action : pass
  Red action    : discard
  Green packets : 0 (Packets)
  Red packets   : 0 (Packets)

```

Table 23 Command output

Field	Description
Direction	Direction in which the QoS policy is applied to the interface.
Matched	Number of matching packets.
Forwarded	Average rate of successfully forwarded matching packets in a statistics collection period.
Dropped	Average rate of dropped matching packets in a statistics collection period.
Green packets	Traffic statistics for green packets.
Yellow packets	Traffic statistics for yellow packets.
Red packets	Traffic statistics for red packets.

For the description of other fields, see [Table 15](#) and [Table 18](#).

display qos policy user-profile

Use **display qos policy user-profile** to display QoS policies applied to user profiles.

Syntax

```

display qos policy user-profile [ name profile-name ] [ user-id user-id ] [ slot slot-number ]
[ inbound | outbound ]

```

Views

Any view

Predefined user roles

network-admin
network-operator

Parameters

name *profile-name*: Specifies a user profile by its name, a case-sensitive string of 1 to 31 characters. Valid characters include English letters, digits, and underscores (_). The name must start with an

English letter and must be unique. If you do not specify a user profile, this command displays QoS policies applied to all user profiles.

user-id *user-id*: Specifies an online user by a system-assigned, hexadecimal ID in the range of 0 to fffffffe. If you do not specify an online user, this command displays QoS policies applied to user profiles for all online users.

slot *slot-number*: Specifies an IRF member device by its member ID. If you do not specify a member device, this command displays QoS policies applied to user profiles for all member devices.

inbound: Specifies QoS policies applied to incoming traffic.

outbound: Specifies QoS policies applied to outgoing traffic.

Usage guidelines

If you do not specify a direction, this command displays QoS policies applied in the inbound direction and QoS policies applied in the outbound direction.

Examples

Display the QoS policy applied to user profile **abc** for a global user.

```
<Sysname> display qos policy user-profile name abc user-id 30000000 inbound
User-Profile: abc
  User ID: 0x30000000(global)
  Direction: Inbound
  Policy: p1
  Classifier: default-class
    Matched : 0 (Packets) 0 (Bytes)
    Operator: AND
    Rule(s) :
      If-match any
    Behavior: be
    -none-
```

Display the QoS policy applied to user profile **abc** for a local user.

```
<Sysname> display qos policy user-profile name abc user-id 30000001 inbound
User-Profile: abc
  slot 2:
    User ID: 0x30000001(local)
    Direction: Inbound
    Policy: p1
    Classifier: default-class
      Matched : 0 (Packets) 0 (Bytes)
      Operator: AND
      Rule(s) :
        If-match any
      Behavior: be
      -none-
```

Table 24 Command output

Field	Description
global	Indicates a global user, who comes online from a global interface such as an aggregate interface.
local	Indicates a local user, who comes online from a physical interface.

Field	Description
Matched	Number of packets that meet match criteria.
Green packets	Statistics about green packets.
Yellow packets	Statistics about yellow packets.
Red packets	Statistics about red packets.

For the description of other fields, see [Table 15](#) and [Table 18](#).

display qos vlan-policy

Use **display qos vlan-policy** to display QoS policies applied to VLANs.

Syntax

```
display qos vlan-policy { name policy-name | vlan [ vlan-id ] } [ slot slot-number ] [ inbound | outbound ]
```

Views

Any view

Predefined user roles

network-admin
network-operator

Parameters

name *policy-name*: Specifies a QoS policy by its name, a case-sensitive string of 1 to 31 characters.

vlan *vlan-id*: Specifies a VLAN by its ID in the range of 1 to 4094.

inbound: Displays QoS policies applied to incoming traffic.

outbound: Displays QoS policies applied to outgoing traffic.

slot *slot-number*: Specifies an IRF member device by its member ID. If you do not specify a member device, this command displays QoS policies applied to VLANs for the master device.

Usage guidelines

If you do not specify a direction, this command displays QoS policies applied to VLANs in both the inbound and outbound directions.

Examples

```
# Display QoS policies applied to VLAN 2.
<Sysname> display qos vlan-policy vlan 2
Vlan 2
  Direction: Inbound
  Policy: 1
  Classifier: 1
    Operator: AND
  Rule(s) :
    If-match acl 2000
  Behavior: 1
  Marking:
    Remark dscp 3
  Committed Access Rate:
```

```

CIR 112 (kbps), CBS 5120 (Bytes), EBS 512 (Bytes)
Green action : pass
Yellow action : pass
Red action   : discard
Green packets : 0 (Packets) 0 (Bytes)
Yellow packets: 0 (Packets) 0 (Bytes)
Red packets   : 0 (Packets) 0 (Bytes)
Classifier: 2
Operator: AND
Rule(s) :
  If-match protocol ipv6
Behavior: 2
Accounting enable:
  0 (Packets)
Filter enable: Permit
Marking:
  Remark dscp 3
Classifier: 3
Operator: AND
Rule(s) :
  -none-
Behavior: 3
  -none-

```

Table 25 Command output

Field	Description
Direction	Direction in which the QoS policy is applied for the VLAN.
Green packets	Statistics about green packets.
Yellow packets	Statistics about yellow packets.
Red packets	Statistics about red packets.

For the description of other fields, see [Table 15](#) and [Table 18](#).

qos apply policy (interface view, control plane view)

Use **qos apply policy** to apply a QoS policy to an interface or control plane.

Use **undo qos apply policy** to remove an applied QoS policy.

Syntax

```
qos apply policy policy-name { inbound | outbound }
```

```
undo qos apply policy policy-name { inbound | outbound }
```

Default

No QoS policy is applied.

Views

Control plane view

Layer 2 Ethernet interface view

Layer 2 aggregate interface view

Predefined user roles

network-admin

Parameters

policy-name: Specifies a QoS policy by its name, a case-sensitive string of 1 to 31 characters.

inbound: Applies the QoS policy to incoming traffic.

outbound: Applies the QoS policy to outgoing traffic. This keyword is not supported in control plane view.

Usage guidelines

If a class uses control plane protocols or control plane protocol groups as match criteria, the action in the associated traffic behavior can only be **car** or the combination of **car** and **accounting packet**. Only the **cir** keyword in the **car** action can be applied correctly.

Examples

Apply QoS policy **USER1** to the outgoing traffic of GigabitEthernet 1/0/1.

```
<Sysname> system-view
```

```
[Sysname] interface gigabitethernet 1/0/1
```

```
[Sysname-GigabitEthernet1/0/1] qos apply policy USER1 outbound
```

Apply QoS policy **aaa** to the incoming traffic of the control plane of slot 3.

```
<Sysname> system-view
```

```
[Sysname] control-plane slot 3
```

```
[Sysname-cp-slot3] qos apply policy aaa inbound
```

qos apply policy (user profile view)

Use **qos apply policy** to apply a QoS policy to a user profile.

Use **undo qos apply policy** to remove a QoS policy applied to a user profile.

Syntax

```
qos apply policy policy-name { inbound | outbound }
```

```
undo qos apply policy policy-name { inbound | outbound }
```

Default

No QoS policy is applied to a user profile.

Views

User profile view

Predefined user roles

network-admin

Parameters

policy-name: Specifies a QoS policy by its name, a case-sensitive string of 1 to 31 characters.

inbound: Applies the QoS policy to the incoming traffic of the device (traffic sent by online users).

outbound: Applies the QoS policy to the outgoing traffic of the device (traffic received by online users).

Usage guidelines

Deleting a user profile also removes the QoS policies applied to the user profile.

For a user profile to be active, the QoS policy applied in user profile view cannot be empty. A user profile supports only the **car** and **accounting** actions in a QoS policy.

Examples

```
# Apply QoS policy test to incoming traffic of user profile user.
<Sysname> system-view
[Sysname] user-profile user
[Sysname-user-profile-user] qos apply policy test outbound
```

qos apply policy global

Use **qos apply policy global** to apply a QoS policy globally.

Use **undo qos apply policy global** to remove a globally applied QoS policy.

Syntax

```
qos apply policy policy-name global { inbound | outbound }
undo qos apply policy policy-name global { inbound | outbound }
```

Default

No QoS policy is applied globally.

Views

System view

Predefined user roles

network-admin

Parameters

policy-name: Specifies a QoS policy by its name, a case-sensitive string of 1 to 31 characters.

inbound: Applies the QoS policy to the incoming packets on all interfaces.

outbound: Applies the QoS policy to the outgoing packets on all interfaces.

Usage guidelines

A global QoS policy takes effect on all incoming or outgoing traffic depending on the direction in which the QoS policy is applied.

Examples

```
# Globally apply QoS policy user1 to the incoming traffic.
<Sysname> system-view
[Sysname] qos apply policy user1 global inbound
```

qos policy

Use **qos policy** to create a QoS policy and enter its view, or enter the view of an existing QoS policy.

Use **undo qos policy** to delete a QoS policy.

Syntax

```
qos policy policy-name
undo qos policy policy-name
```

Default

No QoS policies exist.

Views

System view

Predefined user roles

network-admin

Parameters

policy-name: Specifies a name for the QoS policy, a case-sensitive string of 1 to 31 characters.

Usage guidelines

To delete a QoS policy that has been applied to an object, you must first remove the QoS policy from the object.

Examples

```
# Create a QoS policy named user1.
<Sysname> system-view
[Sysname] qos policy user1
[Sysname-qospolicy-user1]
```

Related commands

- classifier behavior**
- qos apply policy**
- qos apply policy global**
- qos vlan-policy**

qos vlan-policy

Use **qos vlan-policy** to apply a QoS policy to the specified VLANs.

Use **undo qos vlan-policy** to remove a QoS policy from the specified VLANs.

Syntax

```
qos vlan-policy policy-name vlan vlan-id-list { inbound | outbound }
undo qos vlan-policy policy-name vlan vlan-id-list { inbound | outbound }
```

Default

No QoS policy is applied to a VLAN.

Views

System view

Predefined user roles

network-admin

Parameters

policy-name: Specifies a QoS policy by its name, a case-sensitive string of 1 to 31 characters.

vlan *vlan-id-list*: Specifies a space-separated list of up to eight VLAN IDs or a VLAN ID range in the form of *vlan-id1* **to** *vlan-id2*. The value for *vlan-id2* must be greater than or equal to the value for *vlan-id1*. The value range for the *vlan-id* argument is 1 to 4094.

inbound: Applies the QoS policy to incoming packets.

outbound: Applies the QoS policy to outgoing packets.

Examples

```
# Apply QoS policy test to the incoming traffic of VLAN 200, VLAN 300, VLAN 400, and VLAN 500.
<Sysname> system-view
[Sysname] qos vlan-policy test vlan 200 300 400 500 inbound
```

reset qos policy control-plane

Use **reset qos policy control-plane** to clear the statistics of the QoS policy applied to a control plane.

Syntax

```
reset qos policy control-plane slot slot-number
```

Views

User view

Predefined user roles

network-admin

Parameters

slot *slot-number*: Specifies an IRF member device by its member ID.

Examples

```
# Clear the statistics of the QoS policy applied to the control plane of slot 3.
<Sysname> reset qos policy control-plane slot 3
```

reset qos policy global

Use **reset qos policy global** to clear the statistics of a global QoS policy.

Syntax

```
reset qos policy global [ inbound | outbound ]
```

Views

User view

Predefined user roles

network-admin

Parameters

inbound: Clears the statistics of the global QoS policy applied to incoming traffic globally.

outbound: Clears the statistics of the global QoS policy applied to outgoing traffic globally.

Usage guidelines

If you do not specify a direction, this command clears the statistics of the global QoS policies in both directions.

Examples

```
# Clear the statistics of the global QoS policy applied to the incoming traffic globally.
<Sysname> reset qos policy global inbound
```

reset qos vlan-policy

Use **reset qos vlan-policy** to clear the statistics of the QoS policy applied in a certain direction of a VLAN.

Syntax

```
reset qos vlan-policy [ vlan vlan-id ] [ inbound | outbound ]
```

Views

User view

Predefined user roles

network-admin

Parameters

vlan *vlan-id*: Specifies a VLAN ID in the range of 1 to 4094.

inbound: Clears the statistics of the QoS policy applied to the incoming traffic of the specified VLAN.

outbound: Clears the statistics of the QoS policy applied to the incoming traffic of the specified VLAN.

Usage guidelines

If you do not specify a direction, this command clears the statistics of the QoS policies in both directions of the VLAN.

Examples

```
# Clear the statistics of QoS policies applied to VLAN 2.
```

```
<Sysname> reset qos vlan-policy vlan 2
```

Priority mapping commands

Priority map commands

display qos map-table

Use **display qos map-table** to display the configuration of priority maps.

Syntax

```
display qos map-table [ dot1p-dp | dot1p-exp | dot1p-lp | dscp-dot1p | dscp-dp | dscp-dscp |  
exp-dot1p | exp-dp ]
```

Views

Any view

Predefined user roles

network-admin
network-operator

Parameters

The device provides the following types of priority map.

Table 26 Priority maps

Priority mapping	Description
dot1p-dp	802.1p-drop priority map.
dot1p-exp	802.1p-EXP priority map.
dot1p-lp	802.1p-local priority map.
dscp-dot1p	DSCP-802.1p priority map.
dscp-dp	DSCP-drop priority map.
dscp-dscp	DSCP-DSCP priority map.
exp-dot1p	EXP-802.1p priority map.
exp-dp	EXP-drop priority map.

Usage guidelines

If you do not specify a priority map, this command displays the configuration of all priority maps.

Examples

```
# Display the configuration of the 802.1p-local priority map.
```

```
<Sysname> display qos map-table dot1p-lp  
MAP-TABLE NAME: dot1p-lp   TYPE: pre-define  
IMPORT   :   EXPORT  
  0     :     2  
  1     :     0  
  2     :     1  
  3     :     3  
  4     :     4
```

```

5      :      5
6      :      6
7      :      7

```

Table 27 Command output

Field	Description
MAP-TABLE NAME	Name of the priority map.
TYPE	Type of the priority map.
IMPORT	Input values of the priority map.
EXPORT	Output values of the priority map.

import

Use **import** to configure mappings for a priority map.

Use **undo import** to restore the specified or all mappings to the default for a priority map.

Syntax

```
import import-value-list export export-value
```

```
undo import { import-value-list | all }
```

Default

The default priority maps are used. For more information, see *ACL and QoS Configuration Guide*.

Views

Priority map view

Predefined user roles

network-admin

Parameters

import-value-list: Specifies a list of input values.

export-value: Specifies the output value.

all: Restores all mappings in the priority map to the default.

Examples

```
# Configure the 802.1p-local priority map to map 802.1p priority values 4 and 5 to local priority 1.
```

```
<Sysname> system-view
```

```
[Sysname] qos map-table dot1p-lp
```

```
[Sysname-maptbl-dot1p-lp] import 4 5 export 1
```

Related commands

```
display qos map-table
```

qos map-table

Use **qos map-table** to enter the specified priority map view.

Syntax

```
qos map-table { dot1p-dp | dot1p-exp | dot1p-lp | dscp-dot1p | dscp-dp | dscp-dscp | exp-dot1p | exp-dp }
```

Views

System view

Predefined user roles

network-admin

Parameters

For the description of keywords, see [Table 26](#).

Examples

```
# Enter 802.1p-local priority map view.
<Sysname> system-view
[Sysname] qos map-table dot1p-1p
[Sysname-maptbl-dot1p-1p]
```

Related commands

display qos map-table
import

Priority trust mode commands

display qos trust interface

Use **display qos trust interface** to display the priority trust mode and port priorities of an interface.

Syntax

display qos trust interface [*interface-type interface-number*]

Views

Any view

Predefined user roles

network-admin
network-operator

Parameters

interface-type interface-number. Specifies an interface by its type and number. If you do not specify an interface, this command displays the priority trust mode and port priorities of all interfaces.

Examples

```
# Display the priority trust mode and port priority of GigabitEthernet 1/0/1.
<Sysname> display qos trust interface gigabitethernet 1/0/1
Interface: GigabitEthernet1/0/1
  Port priority trust information
  Port priority:4
Port dscp priority: -
  Port priority trust type: dscp
```

Table 28 Command output

Field	Description
Interface	Interface type and interface number.

Field	Description
Port priority	Port priority set for the interface.
Port priority trust type	Priority trust mode on the interface: dot1p , dscp , or none . If the trust mode is none , the port priority is used for priority mapping.
Override	Indicates whether the precedence derived through priority mapping overwrites the original precedence carried in the packet.

qos trust

Use **qos trust** to configure the priority trust mode for an interface.

Use **undo qos trust** to restore the default.

Syntax

```
qos trust { dot1p | dscp }
```

```
undo qos trust
```

Default

An interface does not trust any packet priority and uses the port priority as the 802.1p priority for mapping.

Views

Layer 2 Ethernet interface view

Predefined user roles

network-admin

Parameters

dot1p: Uses the 802.1p priority in incoming packets for priority mapping.

dscp: Uses the DSCP value in incoming packets for priority mapping.

Examples

```
# Set the priority trust mode to 802.1p priority on GigabitEthernet 1/0/1.
<Sysname> system-view
[Sysname] interface gigabitethernet 1/0/1
[Sysname-GigabitEthernet1/0/1] qos trust dot1p
```

Related commands

```
display qos trust interface
```

Port priority commands

qos priority

Use **qos priority** to change the port priority of an interface.

Use **undo qos priority** to restore the default.

Syntax

```
qos priority [ dscp ] priority-value
```

```
undo qos priority [ dscp ]
```

Default

The port priority is 0, and the DSCP value of packets is not modified.

Views

Layer 2 Ethernet interface view

Predefined user roles

network-admin

Parameters

priority-value: Specifies a priority value. If the **dscp** keyword is not specified, this argument specifies the port priority in the range of 0 to 7. If the **dscp** keyword is specified, this argument specifies the DSCP value to be set for packets, in the range of 0 to 63.

Usage guidelines

When no priority trust mode is configured for an interface, the interface uses the port priority as the 802.1p priority for priority mapping. If the **qos priority dscp *priority-value*** command is configured, the interface modifies the DSCP value of Layer 3 packets in addition to performing priority mapping.

This command is no longer in effect after a priority trust mode is configured.

Examples

Set the port priority of GigabitEthernet 1/0/1 to 2, and modify the DSCP value of Layer 3 packets to 20.

```
<Sysname> system-view
[Sysname] interface gigabitethernet 1/0/1
[Sysname-GigabitEthernet1/0/1] qos priority 2
[Sysname-GigabitEthernet1/0/1] qos priority dscp 20
```

Related commands

display qos trust interface

GTS and rate limit commands

GTS commands

display qos gts interface

Use **display qos gts interface** to display the GTS information for interfaces.

Syntax

```
display qos gts interface [ interface-type interface-number ]
```

Views

Any view

Predefined user roles

network-admin
network-operator

Parameters

interface-type interface-number. Specifies an interface by its type and number. If you do not specify an interface, this command displays the GTS information for all interfaces.

Examples

Display the GTS information for all interfaces.

```
<Sysname> display qos gts interface
Interface: GigabitEthernet1/0/1
Rule: If-match acl 2001
  CIR 512 (kbps), CBS 51200 (Bytes), PIR 5120 (kbps), EBS 0 (Bytes)
  Queue Length: 100 (Packets)
  Queue Size: 70 (Packets)
  Passed      : 0 (Packets) 0 (Bytes)
  Discarded: 0 (Packets) 0 (Bytes)
  Delayed    : 0 (Packets) 0 (Bytes)

Interface: GigabitEthernet1/0/2
Rule: If-match acl 2001
  CIR 64 (kbps), CBS 51200 (Bytes), EBS 0 (Bytes)
  Queue Length: 100 (Packets)
  Queue Size: 70 (Packets)
  Passed      : 0 (Packets) 0 (Bytes)
  Discarded: 0 (Packets) 0 (Bytes)
  Delayed    : 0 (Packets) 0 (Bytes)
```

Table 29 Command output

Field	Description
Interface	Interface name, including the interface type and interface number.
Rule	Match criteria.

Field	Description
CIR	CIR in kbps.
CBS	CBS in bytes.
EBS	EBS in bytes.
PIR	PIR in kbps.
Queue Length	Number of packets that the buffer can hold.
Queue Size	Number of packets in the buffer.
Passed	Number and bytes of packets that have been forwarded.
Discarded	Number and bytes of dropped packets.
Delayed	Number and bytes of delayed packets.

qos gts

Use **qos gts** to set GTS parameters on an interface.

Use **undo qos gts** to delete the GTS configuration on an interface.

Syntax

qos gts queue *queue-id* **cir** *committed-information-rate* [**cbs** *committed-burst-size*]

undo qos gts queue *queue-id*

Default

No GTS parameters are configured on an interface.

Views

Layer 2 Ethernet interface view

Predefined user roles

network-admin

Parameters

queue *queue-id*: Shapes the packets in a queue specified by its ID. The value range for *queue-id* is 0 to 7.

cir *committed-information-rate*: Specifies the CIR in kbps. The *committed-information-rate* argument has the following value ranges:

- 8 to 1048576 for GE interfaces.
- 8 to 10485760 for 10-GE interfaces.
- 8 to 41943040 for 40-GE interfaces.

The specified value must be an integral multiple of 8.

cbs *committed-burst-size*: Specifies the CBS in bytes. The value range for *committed-burst-size* is 512 to 16777216, in increments of 512. The default value for this argument is the product of 62.5 and the CIR and must be an integral multiple of 512. When the product is not an integral multiple of 512, it is rounded up to the nearest integral multiple of 512 that is greater than the product. A default value greater than 16777216 is converted to 16777216.

Usage guidelines

The specified CIR does not take interframe gaps into account and is smaller than the actually shaped rate on an interface.

An interframe gap is a time interval of 12 bits between frames. This gap serves the following roles:

- Allows the device to differentiate one frame from another.
- Allows for time for the device to process the current frame and to be prepared to receive the next frame.

Examples

Shape the packets of queue 1 on GigabitEthernet 1/0/1. The GTS parameters are as follows:

- The CIR is 6400 kbps.
- The CBS is 51200 bytes.

```
<Sysname> system-view
[Sysname] interface gigabitethernet 1/0/1
[Sysname-GigabitEthernet1/0/1] qos gts queue 1 cir 6400 cbs 51200
```

Rate limit commands

display qos lr interface

Use **display qos lr interface** to display the rate limit information for interfaces.

Syntax

```
display qos lr interface [ interface-type interface-number ]
```

Views

Any view

Predefined user roles

network-admin
network-operator

Parameters

interface-type interface-number. Specifies an interface by its type and number. If you do not specify an interface, this command displays the rate limit information for all interfaces.

Examples

Display the rate limit information for all interfaces.

```
<Sysname> display qos lr interface
Interface: GigabitEthernet1/0/1
Direction: Inbound
CIR 2000 (kbps), CBS 20480 (Bytes)
```

Table 30 Command output

Field	Description
Interface	Interface name, including the interface type and interface number.
Direction	Direction to which the rate limit configuration is applied: inbound or outbound.
Passed	Number and bytes of packets that have passed.
Discarded	Number and bytes of dropped packets.
Delayed	Number and bytes of delayed packets.

qos lr

Use **qos lr** to configure rate limiting on an interface.

Use **undo qos lr** to delete the rate limit configuration.

Syntax

```
qos lr { inbound | outbound } cir committed-information-rate [ cbs committed-burst-size ]  
undo qos lr { inbound | outbound }
```

Default

No rate limit is configured on an interface.

Views

Layer 2 Ethernet interface view

Predefined user roles

network-admin

Parameters

inbound: Limits the rate of incoming packets.

outbound: Limits the rate of outgoing packets.

cir *committed-information-rate*: Specifies the CIR in kbps. The *committed-information-rate* argument has the following value ranges:

- 8 to 1048576 for GE interfaces.
- 8 to 10485760 for 10-GE interfaces.
- 8 to 41943040 for 40-GE interfaces.

The specified value must be an integral multiple of 8.

cbs *committed-burst-size*: Specifies the CBS in bytes. The value range for *committed-burst-size* is 512 to 134217728, in increments of 512. The default value for this argument is the product of 62.5 and the CIR and must be an integral multiple of 512. When the product is not an integral multiple of 512, it is rounded up to the nearest integral multiple of 512 that is greater than the product. A default value greater than 134217728 is converted to 134217728.

Examples

Limit the rate of outgoing packets on GigabitEthernet 1/0/1, with CIR 256 kbps and CBS 51200 bytes.

```
<Sysname> system-view  
[Sysname] interface gigabitethernet 1/0/1  
[Sysname-GigabitEthernet1/0/1] qos lr outbound cir 256 cbs 51200
```

Congestion management commands

Common commands

display qos queue interface

Use **display qos queue interface** to display the queuing information for interfaces.

Syntax

```
display qos queue interface [ interface-type interface-number ]
```

Views

Any view

Predefined user roles

network-admin

network-operator

Parameters

interface-type interface-number. Specifies an interface by its type and number. If you do not specify an interface, this command displays the queuing information for all interfaces.

Examples

Display the queuing information for all interfaces.

```
<Sysname> display qos queue interface
Interface: GigabitEthernet1/0/1
Output queue: Strict Priority queuing
Interface: GigabitEthernet1/0/2
Output queue: Strict Priority queuing
Interface: GigabitEthernet1/0/3
Output queue: Strict Priority queuing
Interface: GigabitEthernet1/0/4
Output queue: Strict Priority queuing
Interface: GigabitEthernet1/0/5
Output queue: Strict Priority queuing
Interface: GigabitEthernet1/0/6
Output queue: Strict Priority queuing
```

Table 31 Command output

Field	Description
Interface	Interface name, including the interface type and interface number.
Output queue	Type of the current output queue.
Group	Number of the group that holds the queue. The group number can only be 1.
Weight	Packet-count scheduling weight of the queue. N/A is displayed for a queue that uses the SP scheduling algorithm.

Field	Description
Byte-count	Byte-count scheduling weight of the queue. N/A is displayed for a queue that uses the SP scheduling algorithm.

SP commands

display qos queue sp interface

Use **display qos queue sp interface** to display the SP queuing configuration of an interface.

Syntax

display qos queue sp interface [*interface-type interface-number*]

Views

Any view

Predefined user roles

network-admin
network-operator

Parameters

interface-type interface-number. Specifies an interface by its type and number. If you do not specify an interface, this command displays the SP queuing configuration of all interfaces.

Examples

```
# Display the SP queuing configuration of GigabitEthernet 1/0/1.
<Sysname> display qos queue sp interface gigabitethernet 1/0/1
Interface: GigabitEthernet1/0/1
  Output queue: Strict Priority queuing
```

Table 32 Command output

Field	Description
Interface	Interface type and interface number.
Output queue	Type of the current output queue.

qos sp

Use **qos sp** to enable SP queuing on an interface.

Use **undo qos sp** to restore the default.

Syntax

qos sp
undo qos sp

Default

An interface uses byte-count WRR queuing.

Views

Layer 2 Ethernet interface view

Predefined user roles

network-admin

Examples

```
# Enable SP queuing on GigabitEthernet 1/0/1.
<Sysname> system-view
[Sysname] interface gigabitethernet 1/0/1
[Sysname-GigabitEthernet1/0/1] qos sp
```

Related commands

display qos queue sp interface

WRR commands

display qos queue wrr interface

Use **display qos queue wrr interface** to display the WRR queuing configuration of an interface.

Syntax

display qos queue wrr interface [*interface-type interface-number*]

Views

Any view

Predefined user roles

network-admin
network-operator

Parameters

interface-type interface-number. Specifies an interface by its type and number. If you do not specify an interface, this command displays the WRR queuing configuration of all interfaces.

Examples

```
# Display the WRR queuing configuration of GigabitEthernet 1/0/1.
<Sysname> display qos queue wrr interface gigabitethernet 1/0/1
Interface: GigabitEthernet1/0/1
Output queue: Weighted Round Robin queuing
Queue ID      Queue name    Group      Weight
-----
0             be           1          1
1             af1          1          1
2             af2          1          1
3             af3          1          1
4             af4          1          1
5             ef           1          1
6             cs6          1          1
7             cs7          sp         N/A
```

Table 33 Command output

Field	Description
Interface	Interface type and interface number.
Output queue	Type of the current output queue.
Group	Number of the group a queue is assigned to. By default, all queues belong to group 1.
Weight	Packet-count queue scheduling weight of a queue. N/A is displayed for a queue that uses the SP scheduling algorithm.
Byte count	Byte-count scheduling weight of a queue. N/A is displayed for a queue that uses the SP scheduling algorithm.

qos wrr

Use **qos wrr** to enable WRR queuing on an interface.

Use **undo qos wrr** to restore the default.

Syntax

qos wrr { **byte-count** | **weight** }

undo qos wrr { **byte-count** | **weight** }

Default

An interface uses byte-count WRR queuing.

Views

Layer 2 Ethernet interface view

Predefined user roles

network-admin

Parameters

byte-count: Allocates bandwidth to queues in bytes.

weight: Allocates bandwidth to queues in packets.

Usage guidelines

You must use the **qos wrr** command to enable WRR queuing before you can configure WRR queuing parameters for a queue on an interface.

Examples

Enable packet-count WRR queuing on GigabitEthernet 1/0/1.

```
<Sysname> system-view
[Sysname] interface gigabitethernet 1/0/1
[Sysname-GigabitEthernet1/0/1] qos wrr weight
```

Enable byte-count WRR queuing on GigabitEthernet 1/0/1.

```
<Sysname> system-view
[Sysname] interface gigabitethernet 1/0/1
[Sysname-GigabitEthernet1/0/1] qos wrr byte-count
```

Related commands

display qos queue wrr interface

qos wrr { byte-count | weight }

Use **qos wrr { byte-count | weight }** to configure the WRR queuing parameters for a queue on an interface.

Use **undo qos wrr** to delete the WRR queuing parameters of a queue on an interface.

Syntax

```
qos wrr queue-id group 1 { byte-count | weight } schedule-value
```

```
undo qos wrr queue-id
```

Default

All queues on a WRR-enabled interface are in WRR group 1, and queues 0 through 7 have a weight of 1, 2, 3, 4, 5, 9, 13, and 15, respectively.

Views

Layer 2 Ethernet interface view

Predefined user roles

network-admin

Parameters

queue-id: Specifies a queue by its ID. The value range for this argument is 0 to 7 or keywords in [Table 34](#).

Table 34 The number-keyword map for the *queue-id* argument

Number	Keyword
0	be
1	af1
2	af2
3	af3
4	af4
5	ef
6	cs6
7	cs7

group 1: Specifies WRR group 1. Only WRR group 1 is supported in the current software version.

byte-count: Allocates bandwidth to queues in bytes.

weight: Allocates bandwidth to queues in packets.

schedule-value: Specifies a scheduling weight for the specified queue in WRR queuing. The value range for this argument is 1 to 15.

Usage guidelines

You must use the **qos wrr** command to enable WRR queuing before you can configure WRR queuing parameters for a queue on an interface.

Examples

```
# Enable packet-based WRR queuing on GigabitEthernet 1/0/1, assign queue 0 to WRR group 1, and specify scheduling weight 10 for queue 0.
```

```
<Sysname> system-view
```

```
[Sysname] interface gigabitethernet 1/0/1
[Sysname-GigabitEthernet1/0/1] qos wrr weight
[Sysname-GigabitEthernet1/0/1] qos wrr 0 group 1 weight 10
```

Related commands

```
display qos queue wrr interface
qos wrr
```

qos wrr group sp

Use **qos wrr group sp** to assign a queue to the SP group.

Use **undo qos wrr group sp** to remove a queue from the SP group.

Syntax

```
qos wrr queue-id group sp
undo qos wrr queue-id
```

Default

All queues on a WRR-enabled interface are in WRR group 1.

Views

Layer 2 Ethernet interface view

Predefined user roles

network-admin

Parameters

queue-id: Specifies a queue by its ID. The value range for this argument is 0 to 7 or keywords in [Table 34](#).

Usage guidelines

This command is available only on a WRR-enabled interface. Queues in the SP group are scheduled with SP. The SP group has higher scheduling priority than the WRR groups.

You must use the **qos wrr** command to enable WRR queuing before you can configure this command on an interface.

Examples

```
# Enable WRR queuing on GigabitEthernet 1/0/1, and assign queue 0 to the SP group.
```

```
<Sysname> system-view
[Sysname] interface gigabitethernet 1/0/1
[Sysname-GigabitEthernet1/0/1] qos wrr weight
[Sysname-GigabitEthernet1/0/1] qos wrr 0 group sp
```

Related commands

```
display qos queue wrr interface
qos wrr
```

WFQ commands

display qos queue wfq interface

Use **display qos queue wfq interface** to display the WFQ configuration of an interface.

Syntax

```
display qos queue wfq interface [ interface-type interface-number ]
```

Views

Any view

Predefined user roles

network-admin

network-operator

Parameters

interface-type interface-number. Specifies an interface by its type and number. If you do not specify an interface, this command displays the WFQ configuration of all interfaces.

Examples

```
# Display the WFQ configuration of GigabitEthernet 1/0/1.
```

```
<Sysname> display qos wfq interface gigabitethernet 1/0/1
```

```
Interface: GigabitEthernet1/0/1
```

```
Output queue: Hardware Weighted Fair Queuing
```

Queue ID	Queue name	Group	Byte count	Min Bandwidth
0	be	1	1	64
1	af1	1	1	64
2	af2	1	1	64
3	af3	1	1	64
4	af4	1	1	64
5	ef	1	1	64
6	cs6	1	1	64
7	cs7	1	1	64

Table 35 Command output

Field	Description
Interface	Interface type and interface number.
Output queue	Type of the current output queue.
Group	Number of the group that holds the queue. By default, all queues are in group 1.
Byte-count	Byte-count scheduling weight of the queue. N/A is displayed for a queue that uses the SP scheduling algorithm.
Weight	Packet-count queue scheduling weight of the queue. N/A is displayed for a queue that uses the SP scheduling algorithm.
Min Bandwidth	Minimum guaranteed bandwidth for the queue.

qos bandwidth queue

Use **qos bandwidth queue** to set the minimum guaranteed bandwidth for a queue on an interface.

Use **undo qos bandwidth queue** to restore the default.

Syntax

qos bandwidth queue *queue-id* **min** *bandwidth-value*

undo qos bandwidth queue *queue-id*

Default

The minimum guaranteed bandwidth for a queue is 64 kbps.

Views

Layer 2 Ethernet interface view

Predefined user roles

network-admin

Parameters

queue-id: Specifies a queue by its ID. The value range for this argument is 0 to 7 or keywords in [Table 34](#).

min *bandwidth-value*: Sets the minimum guaranteed bandwidth in kbps. The *bandwidth-value* argument has the following value ranges:

- 8 to 1000000 for GE interfaces.
- 8 to 10000000 for 10-GE interfaces.
- 8 to 40000000 for 40-GE interfaces.

Usage guidelines

The minimum guaranteed bandwidth is the amount of bandwidth guaranteed for a queue when the interface is congested.

You must use the **qos wfq** command to enable WFQ before you can configure this command on an interface.

Examples

```
# Set the minimum guaranteed bandwidth to 100 kbps for queue 0 on GigabitEthernet 1/0/1.
```

```
<Sysname> system-view
[Sysname] interface gigabitethernet 1/0/1
[Sysname-GigabitEthernet1/0/1] qos wfq weight
[Sysname-GigabitEthernet1/0/1] qos bandwidth queue 0 min 100
```

Related commands

qos wfq

qos wfq

Use **qos wfq** to enable WFQ on an interface.

Use **undo qos wfq** to restore the default.

Syntax

qos wfq { **byte-count** | **weight** }

undo qos wfq { **byte-count** | **weight** }

Default

An interface uses byte-count WRR queuing.

Views

Layer 2 Ethernet interface view

Predefined user roles

network-admin

Parameters

byte-count: Allocates bandwidth to queues in bytes.

weight: Allocates bandwidth to queues in packets.

Usage guidelines

You must use the **qos wfq** command to enable WFQ before you can configure WFQ queuing parameters for a queue on an interface.

Examples

```
# Enable packet-count WFQ on GigabitEthernet 1/0/1.
```

```
<Sysname> system-view
[Sysname] interface gigabitethernet 1/0/1
[Sysname-GigabitEthernet1/0/1] qos wfq weight
```

```
# Enable byte-count WFQ on GigabitEthernet 1/0/1.
```

```
<Sysname> system-view
[Sysname] interface gigabitethernet 1/0/1
[Sysname-GigabitEthernet1/0/1] qos wfq byte-count
```

Related commands

display qos queue wfq interface

qos wfq { byte-count | weight }

Use **qos wfq { byte-count | weight }** to assign a queue to a WFQ group with a certain scheduling weight.

Use **undo qos wfq** to delete the WFQ queuing parameters of a queue on an interface.

Syntax

qos wfq *queue-id* group 1 { byte-count | weight } *schedule-value*

undo qos wfq *queue-id*

Default

All queues on a WFQ-enabled interface are in WFQ group 1 and have a weight of 1.

Views

Layer 2 Ethernet interface view

Predefined user roles

network-admin

Parameters

queue-id: Specifies a queue by its ID. The value range for this argument is 0 to 7 or keywords in [Table 34](#).

group 1: Specifies WFQ group 1. Only WFQ group 1 is supported in the current software version.

byte-count: Allocates bandwidth to queues in bytes.

weight: Allocates bandwidth to queues in packets.

schedule-value: Specifies a scheduling weight for the specified queue in WFQ queuing. The value range for this argument is 1 to 15.

Usage guidelines

You must use the **qos wfq** command to enable WFQ before you configure this command.

Examples

Enable byte-count WFQ on GigabitEthernet 1/0/1, and specify scheduling weight 10 for queue 0.

```
<Sysname> system-view
[Sysname] interface gigabitethernet 1/0/1
[Sysname-GigabitEthernet1/0/1] qos wfq byte-count
[Sysname-GigabitEthernet1/0/1] qos wfq 0 group 1 byte-count 10
```

Related commands

display qos queue wfq interface

qos bandwidth queue

qos wfq

qos wfq group sp

Use **qos wfq group sp** to assign a queue to the SP group.

Use **undo qos wfq group sp** to remove a queue from the SP group.

Syntax

qos wfq *queue-id* group sp

undo qos wfq *queue-id*

Default

All queues on a WFQ-enabled interface are in WFQ group 1.

Views

Layer 2 Ethernet interface view

Predefined user roles

network-admin

Parameters

queue-id: Specifies a queue by its ID. The value range for this argument is 0 to 7 or keywords in [Table 34](#).

Usage guidelines

This command is available only on a WFQ-enabled interface. Queues in the SP group are scheduled with SP, instead of WFQ. The SP group has higher scheduling priority than the WFQ groups.

You must use the **qos wfq** command to enable WFQ before you configure this command.

Examples

Enable WFQ on GigabitEthernet 1/0/1, and assign queue 0 to the SP group.

```
<Sysname> system-view
[Sysname] interface gigabitethernet 1/0/1
[Sysname-GigabitEthernet1/0/1] qos wfq weight
```

```
[Sysname-GigabitEthernet1/0/1] qos wfq 0 group sp
```

Related commands

display qos queue wfq interface

qos bandwidth queue

qos wfq

Queue scheduling profile commands

bandwidth queue

Use **bandwidth queue** to set the minimum guaranteed bandwidth for a queue.

Use **undo bandwidth queue** to restore the default.

Syntax

bandwidth queue *queue-id* **min** *bandwidth-value*

undo bandwidth queue *queue-id*

Default

The minimum guaranteed bandwidth for a queue is 64 kbps.

Views

Queue scheduling profile view

Predefined user roles

network-admin

Parameters

queue-id: Specifies a queue by its ID. The value range for this argument is 0 to 7 or keywords in [Table 34](#).

min *bandwidth-value*: Specifies the minimum guaranteed bandwidth in kbps. The value range for the *bandwidth-value* argument is 8 to 100000000.

Usage guidelines

You must configure a queue as a WFQ queue before you set the minimum guaranteed bandwidth for the queue.

The minimum guaranteed bandwidth is the amount of bandwidth guaranteed for a queue when the interface is congested.

Examples

Configure queue 0 as a WFQ queue, and set the minimum guaranteed bandwidth to 100 kbps for queue 0.

```
<Sysname> system-view
```

```
[Sysname] qos qmprofile myprofile
```

```
[Sysname-qmprofile-myprofile] queue 0 wfq group 1 weight 1
```

```
[Sysname-qmprofile-myprofile] bandwidth queue 0 min 100
```

display qos qmprofile configuration

Use **display qos qmprofile configuration** to display the queue scheduling profile configuration.

Syntax

display qos qmprofile configuration [*profile-name*] [**slot** *slot-number*]

Views

Any view

Predefined user roles

network-admin

network-operator

Parameters

profile-name: Specifies a queue scheduling profile by its name, a case-sensitive string of 1 to 31 characters. If you do not specify a queue scheduling profile, this command displays the configuration of all queue scheduling profiles.

slot slot-number: Specifies an IRF member device by its member ID. If you do not specify a member device, this command displays the queue scheduling profile configuration for the master device.

Examples

Display the configuration of queue scheduling profile **myprofile**.

```
<Sysname> display qos qmprofile configuration myprofile
```

```
Queue management profile: q (ID 1)
```

Queue ID	Type	Group	Schedule unit	Schedule value	Min bandwidth	Max bandwidth
----------	------	-------	---------------	----------------	---------------	---------------

be	SP	N/A	N/A	N/A	N/A	N/A
af1	SP	N/A	N/A	N/A	N/A	N/A
af2	SP	N/A	N/A	N/A	N/A	N/A
af3	SP	N/A	N/A	N/A	N/A	N/A
af4	SP	N/A	N/A	N/A	N/A	N/A
ef	SP	N/A	N/A	N/A	N/A	N/A
cs6	SP	N/A	N/A	N/A	N/A	N/A
cs7	SP	N/A	N/A	N/A	N/A	N/A

Table 36 Command output

Field	Description
Queue management profile	Queue scheduling profile name.
Type	Queue scheduling type: <ul style="list-style-type: none">• SP.• WRR.• WFQ.
Group	Priority group to which the queue belongs. The value can only be 1. N/A indicates this field is ignored.
Schedule unit	Scheduling unit: weight or byte-count . N/A indicates that this field is ignored.
Schedule value	This field indicates: <ul style="list-style-type: none">• Number of packets for the weight scheduling unit.• Number of bytes for the byte-count scheduling unit. N/A indicates that this field is ignored.

Field	Description
Min bandwidth	Minimum guaranteed bandwidth for the queue. N/A indicates that this field is ignored.
Max bandwidth	Maximum allowed bandwidth for the queue. N/A indicates that this field is ignored.

display qos qmprofile interface

Use **display qos qmprofile interface** to display the queue scheduling profile applied to an interface.

Syntax

display qos qmprofile interface [*interface-type interface-number*]

Views

Any view

Predefined user roles

network-admin
network-operator

Parameters

interface-type interface-number. Specifies an interface by its type and number. If you do not specify an interface, this command displays the queue scheduling profiles applied to all interfaces.

Examples

Display the queue scheduling profile applied to GigabitEthernet 1/0/1.

```
<Sysname> display qos qmprofile interface gigabitethernet 1/0/1
Interface: GigabitEthernet1/0/1
Queue management profile: myprofile
```

Table 37 Command output

Field	Description
Queue management profile	Name of the queue scheduling profile applied to the interface.

qos apply qmprofile

Use **qos apply qmprofile** to apply a queue scheduling profile to an interface.

Use **undo qos apply qmprofile** to restore the default.

Syntax

qos apply qmprofile *profile-name*
undo qos apply qmprofile

Default

No queue scheduling profile is applied to an interface.

Views

Layer 2 Ethernet interface view

Predefined user roles

network-admin

Parameters

profile-name: Specifies a queue scheduling profile by its name, a case-sensitive string of 1 to 31 characters.

Usage guidelines

You can apply only one queue scheduling profile to an interface.

Examples

```
# Apply queue scheduling profile myprofile to the outbound direction of GigabitEthernet 1/0/1.
<Sysname> system-view
[Sysname] interface gigabitethernet 1/0/1
[Sysname-GigabitEthernet1/0/1] qos apply qmprofile myprofile
```

Related commands

display qos qmprofile interface

qos qmprofile

Use **qos qmprofile** to create a queue scheduling profile and enter its view, or enter the view of an existing queue scheduling profile.

Use **undo qos qmprofile** to delete a queue scheduling profile.

Syntax

```
qos qmprofile profile-name
undo qos qmprofile profile-name
```

Default

No user-created queue scheduling profiles exist.

Views

System view

Predefined user roles

network-admin

Parameters

profile-name: Specifies a name for the queue scheduling profile, a case-sensitive string of 1 to 31 characters.

Usage guidelines

To delete a queue scheduling profile already applied to an interface, first remove it from the interface.

Examples

```
# Create a queue scheduling profile named myprofile and enter queue scheduling profile view.
<Sysname> system-view
[Sysname] qos qmprofile myprofile
[Sysname-qmprofile-myprofile]
```

Related commands

display qos qmprofile interface
queue

queue

Use **queue** to configure queue scheduling parameters.

Use **undo queue** to delete queue scheduling parameter settings.

Syntax

```
queue queue-id { sp | wfq [ group group-id ] { weight | byte-count } schedule-value | wrr group group-id { weight | byte-count } schedule-value }
```

```
undo queue queue-id
```

Default

All queues in a queue scheduling profile use SP queuing.

Views

Queue scheduling profile view

Predefined user roles

network-admin

Parameters

queue-id: Specifies a queue by its ID. The value range for this argument is 0 to 7 or keywords in [Table 34](#).

sp: Enables SP for the queue.

wfq: Enables WFQ for the queue.

wrr: Enables WRR for the queue.

group *group-id*: Specifies a WFQ or WRR group by its ID. The group ID can only be 1.

byte-count: Allocates bandwidth to queues in bytes.

weight: Allocates bandwidth to queues in packets.

schedule-value: Specifies the scheduling weight. The value range for this argument is 1 to 15.

Examples

```
# Create a queue scheduling profile named myprofile, and configure queue 0 to use SP.
```

```
<Sysname> system-view  
[Sysname] qos qmprofile myprofile  
[Sysname-qmprofile-myprofile] queue 0 sp
```

```
# Create a queue scheduling profile named myprofile. Configure queue 1 to meet the following requirements:
```

- The WRR queuing is used.
- The WRR group is group 1.
- The scheduling weight is 10.

```
<Sysname> system-view  
[Sysname] qos qmprofile myprofile  
[Sysname-qmprofile-myprofile] queue 1 wrr group 1 weight 10
```

Related commands

```
display qos qmprofile interface
```

```
qos qmprofile
```

Queue-based accounting commands

display qos queue-statistics interface outbound

Use **display qos queue-statistics interface outbound** to display queue-based outgoing traffic statistics for interfaces.

Syntax

```
display qos queue-statistics interface [ interface-type interface-number ] outbound
```

Views

Any view

Predefined user roles

network-admin

network-operator

Parameters

interface-type interface-number. Specifies an interface by its type and number. If you do not specify an interface, this command displays the queue-based outgoing traffic statistics for all interfaces.

Examples

Display queue-based outgoing traffic statistics for GigabitEthernet 1/0/1.

```
<Sysname> display qos queue-statistics interface gigabitethernet 1/0/1 outbound
Interface: GigabitEthernet1/0/1
Direction: outbound
Forwarded: 0 packets, 0 bytes
Dropped: 0 packets, 0 bytes
Queue 0
  Forwarded: 0 packets, 0 bytes, 0 pps, 0 bps
  Dropped: 0 packets, 0 bytes
  Current queue length: 0 packets
Queue 1
  Forwarded: 0 packets, 0 bytes, 0 pps, 0 bps
  Dropped: 0 packets, 0 bytes
  Current queue length: 0 packets
Queue 2
  Forwarded: 0 packets, 0 bytes, 0 pps, 0 bps
  Dropped: 0 packets, 0 bytes
  Current queue length: 0 packets
Queue 3
  Forwarded: 0 packets, 0 bytes, 0 pps, 0 bps
  Dropped: 0 packets, 0 bytes
  Current queue length: 0 packets
Queue 4
  Forwarded: 0 packets, 0 bytes, 0 pps, 0 bps
  Dropped: 0 packets, 0 bytes
  Current queue length: 0 packets
Queue 5
  Forwarded: 0 packets, 0 bytes, 0 pps, 0 bps
```

```

Dropped: 0 packets, 0 bytes
Current queue length: 0 packets
Queue 6
Forwarded: 0 packets, 0 bytes, 0 pps, 0 bps
Dropped: 0 packets, 0 bytes
Current queue length: 0 packets
Queue 7
Forwarded: 0 packets, 0 bytes, 0 pps, 0 bps
Dropped: 0 packets, 0 bytes
Current queue length: 0 packets

```

Table 38 Command output

Field	Description
Interface	Interface for which queue-based traffic statistics are displayed.
Direction	Direction of traffic for which statistics are collected.
Forwarded	Counts forwarded traffic both in packets and in bytes.
Dropped	Counts dropped traffic both in packets and in bytes.
Current queue length	Number of packets in the queue.

Related commands

reset counters interface (*Interface Command Reference*)

Congestion avoidance commands

WRED commands

display qos wred interface

Use **display qos wred interface** to display the WRED information for interfaces.

Syntax

```
display qos wred interface [ interface-type interface-number ]
```

Views

Any view

Predefined user roles

network-admin
network-operator

Parameters

interface-type interface-number. Specifies an interface by its type and number. If you do not specify an interface, this command displays the WRED information for all interfaces.

Examples

```
# Display the WRED information for all interfaces.  
<Sysname> display qos wred interface  
Interface: GigabitEthernet1/0/3  
Current WRED configuration:  
Applied WRED table name: q1
```

display qos wred table

Use **display qos wred table** to display the WRED table configuration.

Syntax

```
display qos wred table [ name table-name ] [ slot slot-number ]
```

Views

Any view

Predefined user roles

network-admin
network-operator

Parameters

name *table-name*: Specifies a WRED table by its name, a case-sensitive string of 1 to 32 characters. If you do not specify a WRED table, this command displays the configuration of all WRED tables.

slot *slot-number*: Specifies an IRF member device by its member ID. If you do not specify a member device, this command displays the WRED table configuration for the master device.

Examples

```
# Display the configuration of WRED table 1.
<Sysname> display qos wred table name 1
Table name: 1
Table type: Queue based WRED
QID   gmin  gmax  gprob  ymin  ymax  yprob  rmin  rmax  rprob  exponent  ECN
-----
0     100   1000  10     100   1000  10     100   1000  10     9         N
1     100   1000  10     100   1000  10     100   1000  10     9         N
2     100   1000  10     100   1000  10     100   1000  10     9         N
3     100   1000  10     100   1000  10     100   1000  10     9         N
4     100   1000  10     100   1000  10     100   1000  10     9         N
5     100   1000  10     100   1000  10     100   1000  10     9         N
6     100   1000  10     100   1000  10     100   1000  10     9         N
7     100   1000  10     100   1000  10     100   1000  10     9         N
```

Table 39 Command output

Field	Description
Table name	Name of a WRED table.
Table type	Type of a WRED table.
QID	Queue ID.
gmin	Lower limit for green packets.
gmax	Upper limit for green packets.
gprob	Drop probability for green packets.
ymin	Lower limit for yellow packets.
ymax	Upper limit for yellow packets.
yprob	Drop probability for yellow packets.
rmin	Lower limit for red packets.
rmax	Upper limit for red packets.
rprob	Drop probability for red packets.
exponent	Exponent for average queue length calculation.
ECN	Indicates whether ECN is enabled for the queue: <ul style="list-style-type: none"> • Y—Enabled. • N—Disabled.

qos wred apply

Use **qos wred apply** to apply a WRED table to an interface.

Use **undo qos wred apply** to restore the default.

Syntax

qos wred apply [*table-name*]

undo qos wred apply

Default

No WRED table is applied to an interface, and the tail drop mode is used on an interface.

Views

Layer 2 Ethernet interface view

Predefined user roles

network-admin

Parameters

table-name: Specifies a WRED table by its name, a case-sensitive string of 1 to 32 characters. If you do not specify a WRED table, this command applies the default WRED table to the interface.

Examples

```
# Apply WRED table table1 to GigabitEthernet 1/0/1.  
<Sysname> system-view  
[Sysname] interface gigabitethernet 1/0/1  
[Sysname-GigabitEthernet1/0/1] qos wred apply table1
```

Related commands

display qos wred interface
display qos wred table
qos wred queue table

qos wred queue table

Use **qos wred queue table** to create a WRED table and enter its view, or enter the view of an existing WRED table.

Use **undo qos wred queue table** to delete a WRED table.

Syntax

```
qos wred queue table table-name  
undo qos wred queue table table-name
```

Default

No WRED tables exist.

Views

System view

Predefined user roles

network-admin

Parameters

table *table-name*: Specifies a name for the WRED table, a case-sensitive string of 1 to 32 characters.

Usage guidelines

You cannot delete a WRED table in use. To delete it, first remove it from the specified interface.

You can use the **display qos wred table** command to display the default WRED table, which cannot be modified or deleted.

Examples

```
# Create a queue-based WRED table named queue-table1.
<Sysname> system-view
[Sysname] qos wred queue table queue-table1
[Sysname-wred-table-queue-table1]
```

Related commands

display qos wred table

queue

Use **queue** to configure the drop-related parameters for a queue in the queue-based WRED table.

Use **undo queue** to restore the default.

Syntax

```
queue queue-id [ drop-level drop-level ] low-limit low-limit high-limit high-limit
[ discard-probability discard-prob ]
undo queue { queue-id | all }
```

Default

The lower limit is 100, the upper limit is 1000, and the drop probability is 10%.

Views

WRED table view

Predefined user roles

network-admin

Parameters

all: Specifies all queues.

queue-id: Specifies a queue by its ID. The value range for this argument is 0 to 7.

drop-level *drop-level*: Specifies a drop level. This argument is a consideration for dropping packets. The value 0 corresponds to green packets, the value 1 corresponds to yellow packets, and the value 2 corresponds to red packets. If you do not specify a drop level, the subsequent configuration takes effect on the packets in the queue regardless of the drop level.

low limit *low-limit*: Specifies the lower limit for the average queue length. The value range for *low-limit* is 0 to 16000.

high-limit *high-limit*: Specifies the upper limit for the average queue length. The upper limit must be greater than the lower limit. The value range for *high-limit* is 0 to 16000.

discard-probability *discard-prob*: Specifies the denominator for drop probability calculation. The greater the denominator, the smaller the calculated drop probability. The value range for *discard-prob* is 0 to 100.

Usage guidelines

When the average queue size is smaller than the lower threshold, no packet is dropped. When the average queue size is between the lower threshold and the upper threshold, the packets are dropped at random. The longer the queue is, the higher the drop probability is. When the average queue size exceeds the upper threshold, subsequent packets are dropped.

Examples

```
# In queue-based WRED table queue-table1, configure the following drop-related parameters for packets in queue 1:
```

- The drop level is 1.
- The lower limit for the average queue length is 10.
- The upper limit for the average queue length is 20.
- The drop probability is 30%.

```
<Sysname> system-view
[Sysname] qos wred queue table queue-table1
[Sysname-wred-table-queue-table1] queue 1 drop-level 1 low-limit 10 high-limit 20
discard-probability 30
```

Related commands

display qos wred table

qos wred queue table

queue ecn

Use **queue ecn** to enable ECN for a queue.

Use **undo queue ecn** to restore the default.

Syntax

queue *queue-id* **ecn**

undo queue *queue-id* **ecn**

Default

ECN is disabled for a queue.

Views

WRED table view

Predefined user roles

network-admin

Parameters

queue-id: Specifies a queue by its ID in the range of 0 to 7.

Usage guidelines

When both the receiver and sender support ECN, the device can notify the peer end of the congestion status by identifying and setting the ECN flag. ECN avoids deteriorating congestion.

Examples

In WRED table **queue-table1**, enable ECN for queue 1.

```
<Sysname> system-view
[Sysname] qos wred queue table queue-table1
[Sysname-wred-table-queue-table1] queue 1 ecn
```

Related commands

display qos wred table

qos wred queue table

queue weighting-constant

Use **queue weighting-constant** to specify an exponent for average queue length calculation for a queue.

Use **undo queue weighting-constant** to restore the default.

Syntax

queue *queue-id* **weighting-constant** *exponent*

undo queue *queue-id* **weighting-constant**

Default

The exponent for average queue length calculation is 9.

Views

WRED table view

Predefined user roles

network-admin

Parameters

queue-id: Specifies a queue by its ID. The value range for this argument is 0 to 7.

weighting-constant *exponent*: Specifies the WRED exponent for average queue length calculation. The value range for *exponent* is 0 to 15.

Usage guidelines

The bigger the exponent is, the less sensitive the average queue size is to real-time queue size changes. The average queue size is calculated using the formula:

Average queue size = previous average queue size $\times (1-2^{-n})$ + current queue size $\times 2^{-n}$,

where *n* can be configured with the **qos wred weighting-constant** command.

Examples

In WRED table **queue-table1**, set the exponent for average queue length calculation to 12 for queue 1.

```
<Sysname> system-view
```

```
[Sysname] qos wred queue table queue-table1
```

```
[Sysname-wred-table-queue-table1] queue 1 weighting-constant 12
```

Related commands

display qos wred table

qos wred queue table

Global CAR commands

car name

Use **car name** to use a global CAR action in a traffic behavior.

Use **undo car** to restore the default.

Syntax

car name *car-name* [**hierarchy-car** *hierarchy-car-name* [**mode** { **and** | **or** }]]

undo car

Default

No global CAR action is configured in a traffic behavior.

Views

Traffic behavior view

Predefined user roles

network-admin

Parameters

car-name: Specifies the name of an aggregate CAR action. This argument must start with a letter, and is a case-sensitive string of 1 to 31 characters.

hierarchy-car *hierarchy-car-name*: Specifies a hierarchical CAR action by its name, a case-sensitive string of 1 to 31 characters. This argument must start with a letter.

mode: Specifies a collaborating mode between the hierarchical CAR action and the aggregate CAR action, which can be AND (the default) or OR. If you do not specify a collaborating mode, the AND mode applies.

- **and**: Specifies the AND mode (the default mode). In this mode, the rate of a flow is limited by both aggregate CAR and the total traffic rate defined with hierarchical CAR.
- **or**: Specifies the OR mode. In this mode, a flow can perform one of the following operations:
 - Pass through at the rate equal to the aggregate CAR applied to it.
 - Pass through at a higher rate if the total traffic rate of all flows does not exceed the hierarchical CAR.

Examples

Use aggregate CAR action **aggcar-1** in traffic behavior **be1**.

```
<Sysname> system-view
[Sysname] traffic behavior be1
[Sysname-behavior-be1] car name aggcar-1
```

Configure traffic behavior **be1** to use aggregate CAR action **aggcar-1** and hierarchical CAR action **hcar**, with the collaborating mode as **or**.

```
<Sysname> system-view
[Sysname] traffic behavior be1
[Sysname-behavior-be1] car name aggcar-1 hierarchy-car hcar mode or
```

Related commands

display qos car name

display traffic behavior user-defined

display qos car name

Use **display qos car name** to display information about global CAR actions.

Syntax

```
display qos car name [ car-name ]
```

Views

Any view

Predefined user roles

network-admin

network-operator

Parameters

car-name: Specifies a global CAR action by its name. This argument must start with a letter, and is a case-sensitive string of 1 to 31 characters. If you do not specify a global CAR action, this command displays information about all global CAR actions, including aggregate CAR actions and hierarchical CAR actions.

Examples

Display information about all global CAR actions.

```
<Sysname> display qos car name
```

```
Name: a
```

```
Mode: aggregative
```

```
CIR 32 (kbps) CBS: 2048 (Bytes) PIR: 888 (kbps) EBS: 0 (Bytes)
```

```
Green action : pass
```

```
Yellow action : pass
```

```
Red action   : discard
```

```
Slot 0:
```

```
Green packets : 0 (Packets), 0 (Bytes)
```

```
Yellow packets: 0 (Packets), 0 (Bytes)
```

```
Red packets   : 0 (Packets), 0 (Bytes)
```

```
Slot 1:
```

```
Green packets : 0 (Packets), 0 (Bytes)
```

```
Yellow packets: 0 (Packets), 0 (Bytes)
```

```
Red packets   : 0 (Packets), 0 (Bytes)
```

```
Slot 2:
```

```
Apply failed
```

```
Name: b
```

```
Mode: hierarchy
```

```
CIR 64 (kbps) CBS: 2048 (Bytes) PIR: 888 (kbps) EBS: 0 (Bytes)
```

```
Green action : pass
```

```
Yellow action : pass
```

```
Red action   : discard
```

```
Slot 0:
```

```
Green packets : 0 (Packets), 0 (Bytes)
```

```
Yellow packets: 0 (Packets), 0 (Bytes)
```

```
Red packets   : 0 (Packets), 0 (Bytes)
```

```
Slot 1:
```

```
Apply failed
```

```

Slot 2:
  Green packets : 0 (Packets), 0 (Bytes)
  Yellow packets: 0 (Packets), 0 (Bytes)
  Red packets   : 0 (Packets), 0 (Bytes)

```

Table 40 Command output

Field	Description
Name	Name of the global CAR action.
Mode	Type of the CAR action, which can be aggregative or hierarchy .
CIR CBS PIR EBS	Parameters for the CAR action.
Green action	Action to take on green packets: <ul style="list-style-type: none"> • discard—Drops the packets. • pass—Permits the packets to pass through.
Yellow action	Action to take on yellow packets: <ul style="list-style-type: none"> • discard—Drops the packets. • pass—Permits the packets to pass through.
Red action	Action to take on red packets: <ul style="list-style-type: none"> • discard—Drops the packets. • pass—Permits the packets to pass through.
Green packet	Statistics about green packets.
Yellow packet	Statistics about yellow packets.
Red packet	Statistics about red packets.

qos car

Use **qos car aggregative** to configure an aggregate or hierarchical CAR action.

Use **undo qos car** to delete an aggregate or hierarchical CAR action.

Syntax

```
qos car car-name { aggregative | hierarchy } cir committed-information-rate [ cbs
committed-burst-size [ ebs excess-burst-size ] ]
```

```
qos car car-name { aggregative | hierarchy } cir committed-information-rate [ cbs
committed-burst-size ] pir peak-information-rate [ ebs excess-burst-size ]
```

```
undo qos car car-name
```

Default

No aggregate or hierarchical CAR action is configured.

Views

System view

Predefined user roles

network-admin

Parameters

car-name: Specifies the name of the global CAR action. This argument must start with a letter, and is a case-sensitive string of 1 to 31 characters.

aggregative: Specifies the global CAR action as an aggregate CAR action.

hierarchy: Specifies the global CAR action as a hierarchical CAR action.

cir *committed-information-rate*: Specifies the CIR in kbps, which is an average traffic rate. The value range for *committed-information-rate* is 8 to 160000000.

cbs *committed-burst-size*: Specifies the CBS in bytes. The value range for *committed-burst-size* is 512 to 256000000, in increments of 512. The default value for this argument is the product of 62.5 and the CIR and must be an integral multiple of 512. When the product is not an integral multiple of 512, it is rounded up to the nearest integral multiple of 512 that is greater than the product. A default value greater than 256000000 is converted to 256000000.

ebs *excess-burst-size*: Specifies the EBS in bytes. The value range for *excess-burst-size* is 0 to 256000000, in increments of 512. If the PIR is configured, the default EBS is the product of 62.5 and the PIR and must be an integral multiple of 512. When the product is not an integral multiple of 512, it is rounded up to the nearest integral multiple of 512. A default value greater than 256000000 is converted to 256000000.

pir *peak-information-rate*: Specifies the PIR in kbps. The value range for *peak-information-rate* is 8 to 160000000.

action: Specifies the action to take on packets:

- **discard**: Drops the packet.
- **pass**: Permits the packet to pass through.
- **remark-dot1p-pass** *new-cos*: Sets the 802.1p priority value of the 802.1p packet to *new-cos* and permits the packet to pass through. The *new-cos* argument is in the range of 0 to 7.
- **remark-dscp-pass** *new-dscp*: Remarks the packet with a new DSCP value and permits the packet to pass through. The *new-dscp* argument is in the range of 0 to 63. Alternatively, you can specify the *new-dscp* argument with **af11**, **af12**, **af13**, **af21**, **af22**, **af23**, **af31**, **af32**, **af33**, **af41**, **af42**, **af43**, **cs1**, **cs2**, **cs3**, **cs4**, **cs5**, **cs6**, **cs7**, **default**, or **ef**.

Usage guidelines

To use two rates for aggregate CAR, configure the **qos car** command with the **pir** *peak-information-rate* option. To use one rate for aggregate CAR, configure the **qos car** command without the **pir** *peak-information-rate* option.

An aggregate CAR action takes effect only after it is used in a QoS policy.

A hierarchical CAR action takes effect only after it is used in a QoS policy.

Examples

```
# Configure aggregate CAR action aggcar-1, where CIR is 25600, CBS is 512000, and red packets are dropped.
```

```
<Sysname> system-view  
[Sysname] qos car aggcar-1 aggregative cir 25600 cbs 512000 red discard
```

```
# Configure hierarchical CAR action h-car, where CIR is 120 and CBS is 51200.
```

```
<Sysname> system-view  
[Sysname] qos car h-car hierarchy cir 120 cbs 51200
```

Related commands

display qos car name

reset qos car name

Use **reset qos car name** to clear the statistics about global CAR actions.

Syntax

```
reset qos car name [ car-name ]
```

Views

User view

Predefined user roles

network-admin

Parameters

car-name: Specifies a global CAR action by its name. This argument must start with a letter, and is a case-sensitive string of 1 to 31 characters. If you do not specify a global CAR action, this command clears statistics for all global CAR actions, including aggregate CAR actions and hierarchical CAR actions.

Examples

Clear the statistics about global CAR action **aggcar-1**.

```
<Sysname> reset qos car name aggcar-1
```

Data buffer commands

Inappropriate data buffer changes can cause system problems. Before manually changing data buffer settings, make sure you understand its impact on your device. As a best practice, use the **burst-mode enable** command if the system requires large buffer spaces. The **burst-mode enable** command and the **buffer apply** command are mutually exclusive. If you have configured the data buffer by using one command, you must execute the **undo** form of the command before using the other command.

buffer apply

Use **buffer apply** to apply manually configured data buffer settings.

Use **undo buffer apply** to restore the default.

Syntax

buffer apply

undo buffer apply

Views

System view

Predefined user roles

network-admin

Usage guidelines

For data buffer settings to take effect, you must execute this command after configuring data buffer settings.

After applying manually configured data buffer settings, you cannot directly modify the applied settings. To modify them, you must cancel the application, reconfigure data buffer settings, and reapply the new settings.

Examples

```
# Apply manually configured data buffer settings.  
<Sysname> system-view  
[Sysname] buffer apply
```

buffer queue guaranteed

Use **buffer queue guaranteed** to set the fixed-area ratio for a queue.

Use **undo buffer queue guaranteed** to delete the fixed-area ratio setting of a queue.

Syntax

buffer egress [*slot slot-number*] **cell queue** *queue-id* **guaranteed ratio** *ratio*

undo buffer egress [*slot slot-number*] **cell queue** *queue-id* **guaranteed**

Default

The fixed-area ratio for a queue is 12%.

Views

System view

Predefined user roles

network-admin

Parameters

egress: Specifies the egress buffer.

slot *slot-number*: Specifies an IRF member device by its member ID (slot number). If you do not specify an IRF member device, this command applies to all IRF member devices.

cell: Specifies cell resources.

queue-id: Specifies a queue by its ID in the range of 0 to 7.

ratio *ratio*: Specifies the fixed-area ratio, in percentage. The value range for *ratio* is 1 to 100.

Usage guidelines

By default, all queues have an equal share of the fixed area. You can set the fixed-area ratio for a queue. The other queues equally share the remaining part.

The fixed-area space for a queue cannot be used by other queues. Therefore, it is also called the minimum guaranteed buffer for the queue. The sum of fixed-area ratios configured for all queues cannot exceed the total fixed-area ratio. Otherwise, the configuration fails.

Inappropriate data buffer changes can cause system problems. Before manually changing data buffer settings, make sure you understand its impact on your device. As a best practice, use the **burst-mode enable** command if the system requires large buffer spaces.

Examples

Configure queue 0 to use 20% fixed-area space of cell resources in the egress buffer.

```
<Sysname> system-view
```

```
[Sysname] buffer egress cell queue 0 guaranteed ratio 20
```

buffer queue shared

Use **buffer queue shared** to set the maximum shared-area ratio for a queue.

Use **undo buffer queue shared** to delete the maximum shared-area ratio setting of a queue.

Syntax

buffer egress [**slot** *slot-number*] **cell queue** *queue-id* **shared ratio** *ratio*

undo buffer egress [**slot** *slot-number*] **cell queue** *queue-id* **shared**

Default

The maximum shared-area ratio for a queue is 33%.

Views

System view

Predefined user roles

network-admin

Parameters

egress: Specifies the egress buffer.

slot *slot-number*: Specifies an IRF member device by its member ID (slot number). If you do not specify an IRF member device, this command applies to all IRF member devices.

cell: Specifies cell resources.

queue-id: Specifies a queue by its ID in the range of 0 to 7.

ratio *ratio*: Specifies the maximum shared-area ratio, in percentage. The value range for *ratio* is 0 to 100.

Usage guidelines

By default, all queues have an equal share of the shared area. You can set the shared-area space for a queue. The unconfigured queues use the default setting. The shared-area space for each queue is finally determined by the chip based on your configuration and the number of packets to be received and sent.

Inappropriate data buffer changes can cause system problems. Before manually changing data buffer settings, make sure you understand its impact on your device. As a best practice, use the **burst-mode enable** command if the system requires large buffer spaces.

Examples

```
# Configure queue 0 to use up to 10% shared-area space of cell resources in the egress buffer.  
<Sysname> system-view  
[Sysname] buffer egress cell queue 0 shared ratio 10
```

buffer total-shared

Use **buffer total-shared** to set the total shared-area ratio.

Use **undo buffer total-shared** to delete the total shared-area ratio setting.

Syntax

buffer egress [*slot slot-number*] **cell total-shared ratio** *ratio*

undo buffer egress [*slot slot-number*] **cell total-shared**

Default

The total shared-area ratio is 97%.

Views

System view

Predefined user roles

network-admin

Parameters

egress: Specifies the egress buffer.

slot *slot-number*: Specifies an IRF member device by its member ID (slot number). If you do not specify an IRF member device, this command applies to all IRF member devices.

cell: Specifies cell resources.

ratio *ratio*: Specifies the ratio of the shared area, in percentage. The value range for *ratio* is 0 to 100.

Usage guidelines

After you set the shared-area ratio, the remaining buffer space is automatically assigned to the fixed area.

Inappropriate data buffer changes can cause system problems. Before manually changing data buffer settings, make sure you understand its impact on your device. As a best practice, use the **burst-mode enable** command if the system requires large buffer spaces.

Examples

```
# Configure the shared area to use 50% space of cell resources in the egress buffer.  
<Sysname> system-view  
[Sysname] buffer egress cell total-shared ratio 50
```

burst-mode enable

Use **burst-mode enable** to enable the Burst feature.

Use **undo burst-mode enable** to disable the Burst feature.

Syntax

burst-mode enable

undo burst-mode enable

Default

The Burst feature is disabled.

Views

System view

Predefined user roles

network-admin

Usage guidelines

The Burst feature is especially useful for reducing packet losses under the following circumstances:

- Broadcast or multicast traffic is intensive, resulting in bursts of traffic.
- Traffic enters a device from a high-speed interface and goes out of a low-speed interface.
- Traffic enters a device from multiple same-rate interfaces and goes out of an interface with the same rate.

Examples

```
# Enable the Burst feature.  
<Sysname> system-view  
[Sysname] burst-mode enable
```

display buffer

Use **display buffer** to display buffer size settings.

Syntax

display buffer [**slot** *slot-number*] [**queue** [*queue-id*]]

Views

Any view

Predefined user roles

network-admin

network-operator

Parameters

slot *slot-number*: Specifies an IRF member device by its member ID (slot number). If you do not specify an IRF member device, this command displays buffer size settings for all IRF member devices.

queue *queue-id*: Specifies a queue by its number in the range of 0 to 7. If you specify a queue, this command displays the fixed-area ratio and shared-area ratio for the specified queue. If you specify the **queue** keyword without the *queue-id* argument, this command displays the fixed-area ratio and shared-area ratio for each queue. If you do not specify the **queue** keyword, this command displays the total shared-area ratio.

Examples

Display buffer size settings.

```
<Sysname> display buffer
Slot  Type    Eg(Total-shared)
1     cell     97
      Eg: Size of the sending buffer
Total-shared: Size of the shared buffer for all ports
Unit: Ratio
```

Display the fixed-area ratio and shared-area ratio for the queues.

```
<Sysname> display buffer queue
Slot  Queue      Type    Eg(Guaranteed , Shared)
1     0-7         cell    12 , 33
      Eg: Size of the sending buffer
      Guaranteed: Size of the minimum guaranteed buffer per queue
      Shared: Size of the maximum shared buffer per queue
Unit: Ratio
```

Table 41 Command output

Field	Description
Type	Resource type.
Queue	Queue ID in the range of 0 to 7.
Eg	Egress buffer.
(Total-shared)	Total-shared indicates the total shared-area ratio.
(Guaranteed , Shared)	<ul style="list-style-type: none">• Guaranteed indicates the fixed-area ratio of a queue.• Shared indicates the shared-area ratio of a queue.

display buffer usage

Use **display buffer usage** to display buffer usage.

Syntax

```
display buffer usage [ slot slot-number ]
```

Views

Any view

Predefined user roles

network-admin
network-operator

Parameters

slot *slot-number*: Specifies an IRF member device by its member ID (slot number). If you do not specify an IRF member device, this command displays buffer usage for all IRF member devices.

Examples

Display buffer usage.

```
<Sysname> display buffer usage
```

Egress total-shared cell buffer usage on slot 1 :

Total: 3872 KB
Used: 0 KB
Free: 3872 KB

	5sec	1min	5min

Block 1	0%	0%	0%
GigabitEthernet1/0/1	0%	0%	0%
GigabitEthernet1/0/2	0%	0%	0%
GigabitEthernet1/0/3	0%	0%	0%
GigabitEthernet1/0/4	0%	0%	0%
GigabitEthernet1/0/5	0%	0%	0%
GigabitEthernet1/0/6	0%	0%	0%
GigabitEthernet1/0/7	0%	0%	0%
GigabitEthernet1/0/8	0%	0%	0%
GigabitEthernet1/0/9	0%	0%	0%
GigabitEthernet1/0/10	0%	0%	0%
GigabitEthernet1/0/11	0%	0%	0%
GigabitEthernet1/0/12	0%	0%	0%
GigabitEthernet1/0/13	0%	0%	0%
GigabitEthernet1/0/14	0%	0%	0%
GigabitEthernet1/0/15	0%	0%	0%
GigabitEthernet1/0/16	0%	0%	0%
GigabitEthernet1/0/17	0%	0%	0%
GigabitEthernet1/0/18	0%	0%	0%
GigabitEthernet1/0/19	0%	0%	0%
GigabitEthernet1/0/20	0%	0%	0%
GigabitEthernet1/0/21	0%	0%	0%
GigabitEthernet1/0/22	0%	0%	0%
GigabitEthernet1/0/23	0%	0%	0%
GigabitEthernet1/0/24	0%	0%	0%
GigabitEthernet1/0/25	0%	0%	0%
GigabitEthernet1/0/26	0%	0%	0%
GigabitEthernet1/0/27	0%	0%	0%
GigabitEthernet1/0/28	0%	0%	0%
GigabitEthernet1/0/29	0%	0%	0%
GigabitEthernet1/0/30	0%	0%	0%
GigabitEthernet1/0/31	0%	0%	0%
GigabitEthernet1/0/32	0%	0%	0%
GigabitEthernet1/0/33	0%	0%	0%
GigabitEthernet1/0/34	0%	0%	0%
GigabitEthernet1/0/35	0%	0%	0%
GigabitEthernet1/0/36	0%	0%	0%
GigabitEthernet1/0/37	0%	0%	0%
GigabitEthernet1/0/38	0%	0%	0%
GigabitEthernet1/0/39	0%	0%	0%
GigabitEthernet1/0/40	0%	0%	0%
GigabitEthernet1/0/41	0%	0%	0%

GigabitEthernet1/0/42	0%	0%	0%
GigabitEthernet1/0/43	0%	0%	0%
GigabitEthernet1/0/44	0%	0%	0%
GigabitEthernet1/0/45	0%	0%	0%
GigabitEthernet1/0/46	0%	0%	0%
GigabitEthernet1/0/47	0%	0%	0%
GigabitEthernet1/0/48	0%	0%	0%
Ten-GigabitEthernet1/0/49	0%	0%	0%
Ten-GigabitEthernet1/0/50	0%	0%	0%
Ten-GigabitEthernet1/0/51	0%	0%	0%
Ten-GigabitEthernet1/0/52	0%	0%	0%

Table 42 Command output

Field	Description
Egress total-shared cell buffer usage on slot	Usage of cell resources in the shared area on an IRF member device.
Block	Block where the port resides. The block where the ports on the front panel of the device reside is fixed to Block 1.
Total	Total size of the data buffer.
Used	Size of used data buffer.
Free	Size of free data buffer.
5sec	Percentage of the buffer that the port uses for the last 5 seconds.
1min	Percentage of the buffer that the port uses for the last 1 minute.
5min	Percentage of the buffer that the port uses for the last 5 minutes.

Time range commands

display time-range

Use **display time-range** to display time range configuration and status.

Syntax

```
display time-range { time-range-name | all }
```

Views

Any view

Predefined user roles

network-admin

network-operator

Parameters

time-range-name: Specifies a time range name, a case-insensitive string of 1 to 32 characters. It must start with an English letter.

all: Displays the configuration and status of all existing time ranges.

Examples

```
# Display the configuration and status of time range t4.
```

```
<Sysname> display time-range t4  
Current time is 17:12:34 11/23/2010 Tuesday
```

```
Time-range : t4 (Inactive)  
 10:00 to 12:00 Mon  
 14:00 to 16:00 Wed  
 from 00:00 1/1/2011 to 00:00 1/1/2012  
 from 00:00 6/1/2011 to 00:00 7/1/2011
```

Table 43 Command output

Field	Description
Current time	Current system time.
Time-range	Configuration and status of the time range, including its name, status (active or inactive), and start time and end time.

time-range

Use **time-range** to create or edit a time range.

Use **undo time-range** to delete a time range or a statement in the time range.

Syntax

```
time-range time-range-name { start-time to end-time days [ from time1 date1 ] [ to time2 date2 ] | from time1 date1 [ to time2 date2 ] | to time2 date2 }
```

```
undo time-range time-range-name [ start-time to end-time days [ from time1 date1 ] [ to time2 date2 ] | from time1 date1 [ to time2 date2 ] | to time2 date2 ]
```

Default

No time ranges exist.

Views

System view

Predefined user roles

network-admin

Parameters

time-range-name: Specifies a time range name. The name is a case-insensitive string of 1 to 32 characters. It must start with an English letter. To avoid confusion, it cannot be **all**.

start-time to end-time: Specifies a periodic statement. Both *start-time* and *end-time* are in hh:mm format (24-hour clock). The value is in the range of 00:00 to 23:59 for the start time, and 00:00 to 24:00 for the end time. The end time must be greater than the start time.

days: Specifies the day or days of the week (in words or digits) on which the periodic statement is valid. If you specify multiple values, separate each value with a space, and make sure they do not overlap. These values can take one of the following forms:

- A digit in the range of 0 to 6, for Sunday, Monday, Tuesday, Wednesday, Thursday, Friday, and Saturday.
- A day of a week in abbreviated words: **Sun, Mon, Tue, Wed, Thu, Fri, and Sat**.
- **working-day** for Monday through Friday.
- **off-day** for Saturday and Sunday.
- **daily** for the whole week.

from time1 date1: Specifies the start time and date of an absolute statement. The *time1* argument specifies the time of the day in hh:mm format (24-hour clock). Its value is in the range of 00:00 to 23:59. The *date1* argument specifies a date in MM/DD/YYYY or YYYY/MM/DD format, where MM is the month of the year in the range of 1 to 12, DD is the day of the month with the range varying by MM, and YYYY is the year in the calendar in the range of 1970 to 2100. If you do not specify this option, the start time is 01/01/1970 00:00 AM, the earliest time available in the system.

to time2 date2: Specifies the end time and date of the absolute time statement. The *time2* argument has the same format as the *time1* argument, but its value is in the range of 00:00 to 24:00. The *date2* argument has the same format and value range as the *date1* argument. The end time must be greater than the start time. If you do not specify this option, the end time is 12/31/2100 24:00 PM, the maximum time available in the system.

Usage guidelines

If an existing time range name is provided, this command adds a statement to the time range.

You can create multiple statements in a time range. Each time statement can take one of the following forms:

- Periodic statement in the *start-time to end-time days* format. A periodic statement recurs periodically on a day or days of the week.
- Absolute statement in the **from time1 date1 to time2 date2** format. An absolute statement does not recur.
- Compound statement in the *start-time to end-time days from time1 date1 to time2 date2* format. A compound statement recurs on a day or days of the week only within the specified period. For example, to create a time range that is active from 08:00 to 12:00 on Monday between January 1, 2015, 00:00 and December 31, 2015, 23:59, use the **time-range test 08:00 to 12:00 Mon from 00:00 01/01/2015 to 23:59 12/31/2015** command.

You can create a maximum of 1024 time ranges, each with a maximum of 32 periodic statements and 12 absolute statements. The active period of a time range is calculated as follows:

1. Combining all periodic statements.
2. Combining all absolute statements.
3. Taking the intersection of the two statement sets as the active period of the time range.

Examples

Create a periodic time range **t1**, setting it to be active between 8:00 to 18:00 during working days.

```
<Sysname> system-view
```

```
[Sysname] time-range t1 08:00 to 18:00 working-day
```

Create an absolute time range **t2**, setting it to be active in the whole year of 2011.

```
<Sysname> system-view
```

```
[Sysname] time-range t2 from 00:00 1/1/2011 to 24:00 12/31/2011
```

Create a compound time range **t3**, setting it to be active from 08:00 to 12:00 on Saturdays and Sundays of the year 2011.

```
<Sysname> system-view
```

```
[Sysname] time-range t3 08:00 to 12:00 off-day from 00:00 1/1/2011 to 24:00 12/31/2011
```

Create a compound time range **t4**, setting it to be active from 10:00 to 12:00 on Mondays and from 14:00 to 16:00 on Wednesdays in January and June of the year 2011.

```
<Sysname> system-view
```

```
[Sysname] time-range t4 10:00 to 12:00 1 from 00:00 1/1/2011 to 24:00 1/31/2011
```

```
[Sysname] time-range t4 14:00 to 16:00 3 from 00:00 6/1/2011 to 24:00 6/30/2011
```

Related commands

display time-range

Document conventions and icons

Conventions

This section describes the conventions used in the documentation.

Command conventions

Convention	Description
Boldface	Bold text represents commands and keywords that you enter literally as shown.
<i>Italic</i>	<i>Italic</i> text represents arguments that you replace with actual values.
[]	Square brackets enclose syntax choices (keywords or arguments) that are optional.
{ x y ... }	Braces enclose a set of required syntax choices separated by vertical bars, from which you select one.
[x y ...]	Square brackets enclose a set of optional syntax choices separated by vertical bars, from which you select one or none.
{ x y ... } *	Asterisk marked braces enclose a set of required syntax choices separated by vertical bars, from which you select at least one.
[x y ...] *	Asterisk marked square brackets enclose optional syntax choices separated by vertical bars, from which you select one choice, multiple choices, or none.
&<1-n>	The argument or keyword and argument combination before the ampersand (&) sign can be entered 1 to n times.
#	A line that starts with a pound (#) sign is comments.

GUI conventions

Convention	Description
Boldface	Window names, button names, field names, and menu items are in Boldface. For example, the New User window opens; click OK .
>	Multi-level menus are separated by angle brackets. For example, File > Create > Folder .

Symbols

Convention	Description
 WARNING!	An alert that calls attention to important information that if not understood or followed can result in personal injury.
 CAUTION:	An alert that calls attention to important information that if not understood or followed can result in data loss, data corruption, or damage to hardware or software.
 IMPORTANT:	An alert that calls attention to essential information.
NOTE:	An alert that contains additional or supplementary information.
 TIP:	An alert that provides helpful information.

Network topology icons

Convention	Description
	Represents a generic network device, such as a router, switch, or firewall.
	Represents a routing-capable device, such as a router or Layer 3 switch.
	Represents a generic switch, such as a Layer 2 or Layer 3 switch, or a router that supports Layer 2 forwarding and other Layer 2 features.
	Represents an access controller, a unified wired-WLAN module, or the access controller engine on a unified wired-WLAN switch.
	Represents an access point.
	Represents a wireless terminator unit.
	Represents a wireless terminator.
	Represents a mesh access point.
	Represents omnidirectional signals.
	Represents directional signals.
	Represents a security product, such as a firewall, UTM, multiservice security gateway, or load balancing device.
	Represents a security module, such as a firewall, load balancing, NetStream, SSL VPN, IPS, or ACG module.

Examples provided in this document

Examples in this document might use devices that differ from your device in hardware model, configuration, or software version. It is normal that the port numbers, sample output, screenshots, and other information in the examples differ from what you have on your device.

Support and other resources

Accessing Hewlett Packard Enterprise Support

- For live assistance, go to the Contact Hewlett Packard Enterprise Worldwide website:
www.hpe.com/assistance
- To access documentation and support services, go to the Hewlett Packard Enterprise Support Center website:
www.hpe.com/support/hpesc

Information to collect

- Technical support registration number (if applicable)
- Product name, model or version, and serial number
- Operating system name and version
- Firmware version
- Error messages
- Product-specific reports and logs
- Add-on products or components
- Third-party products or components

Accessing updates

- Some software products provide a mechanism for accessing software updates through the product interface. Review your product documentation to identify the recommended software update method.
- To download product updates, go to either of the following:
 - Hewlett Packard Enterprise Support Center **Get connected with updates** page:
www.hpe.com/support/e-updates
 - Software Depot website:
www.hpe.com/support/softwaredepot
- To view and update your entitlements, and to link your contracts, Care Packs, and warranties with your profile, go to the Hewlett Packard Enterprise Support Center **More Information on Access to Support Materials** page:
www.hpe.com/support/AccessToSupportMaterials

ⓘ **IMPORTANT:**

Access to some updates might require product entitlement when accessed through the Hewlett Packard Enterprise Support Center. You must have an HP Passport set up with relevant entitlements.

Websites

Website	Link
Networking websites	
Hewlett Packard Enterprise Information Library for Networking	www.hpe.com/networking/resourcefinder
Hewlett Packard Enterprise Networking website	www.hpe.com/info/networking
Hewlett Packard Enterprise My Networking website	www.hpe.com/networking/support
Hewlett Packard Enterprise My Networking Portal	www.hpe.com/networking/mynetworking
Hewlett Packard Enterprise Networking Warranty	www.hpe.com/networking/warranty
General websites	
Hewlett Packard Enterprise Information Library	www.hpe.com/info/enterprise/docs
Hewlett Packard Enterprise Support Center	www.hpe.com/support/hpesc
Hewlett Packard Enterprise Support Services Central	ssc.hpe.com/portal/site/ssc/
Contact Hewlett Packard Enterprise Worldwide	www.hpe.com/assistance
Subscription Service/Support Alerts	www.hpe.com/support/e-updates
Software Depot	www.hpe.com/support/softwaredepot
Customer Self Repair (not applicable to all devices)	www.hpe.com/support/selfrepair
Insight Remote Support (not applicable to all devices)	www.hpe.com/info/insightremotesupport/docs

Customer self repair

Hewlett Packard Enterprise customer self repair (CSR) programs allow you to repair your product. If a CSR part needs to be replaced, it will be shipped directly to you so that you can install it at your convenience. Some parts do not qualify for CSR. Your Hewlett Packard Enterprise authorized service provider will determine whether a repair can be accomplished by CSR.

For more information about CSR, contact your local service provider or go to the CSR website:

www.hpe.com/support/selfrepair

Remote support

Remote support is available with supported devices as part of your warranty, Care Pack Service, or contractual support agreement. It provides intelligent event diagnosis, and automatic, secure submission of hardware event notifications to Hewlett Packard Enterprise, which will initiate a fast and accurate resolution based on your product's service level. Hewlett Packard Enterprise strongly recommends that you register your device for remote support.

For more information and device support details, go to the following website:

www.hpe.com/info/insightremotesupport/docs

Documentation feedback

Hewlett Packard Enterprise is committed to providing documentation that meets your needs. To help us improve the documentation, send any errors, suggestions, or comments to Documentation Feedback (docsfeedback@hpe.com). When submitting your feedback, include the document title,

part number, edition, and publication date located on the front cover of the document. For online help content, include the product name, product version, help edition, and publication date located on the legal notices page.

Index

[A](#) [B](#) [C](#) [D](#) [F](#) [I](#) [N](#) [P](#) [Q](#) [R](#) [S](#) [T](#) [W](#)

A

accounting, [41](#)
acl, [1](#)
acl copy, [3](#)
acl logging interval, [4](#)
acl trap interval, [4](#)

B

bandwidth queue, [90](#)
buffer apply, [108](#)
buffer queue guaranteed, [108](#)
buffer queue shared, [109](#)
buffer total-shared, [110](#)
burst-mode enable, [111](#)

C

car, [42](#)
car name, [103](#)
classifier behavior, [53](#)
control-plane, [54](#)
Customer self repair, [121](#)

D

description, [5](#)
display acl, [6](#)
display buffer, [111](#)
display buffer usage, [112](#)
display packet-filter, [7](#)
display packet-filter statistics, [8](#)
display packet-filter statistics sum, [11](#)
display packet-filter verbose, [12](#)
display qos car name, [104](#)
display qos gts interface, [76](#)
display qos lr interface, [78](#)
display qos map-table, [71](#)
display qos policy, [54](#)
display qos policy control-plane, [55](#)
display qos policy control-plane pre-defined, [57](#)
display qos policy global, [58](#)
display qos policy interface, [59](#)
display qos policy user-profile, [62](#)
display qos qmprofile configuration, [90](#)
display qos qmprofile interface, [92](#)
display qos queue interface, [80](#)
display qos queue sp interface, [81](#)

display qos queue wfq interface, [86](#)
display qos queue wrr interface, [82](#)
display qos queue-statistics interface outbound, [95](#)
display qos trust interface, [73](#)
display qos vlan-policy, [64](#)
display qos wred interface, [97](#)
display qos wred table, [97](#)
display qos-acl resource, [14](#)
display time-range, [115](#)
display traffic behavior, [43](#)
display traffic classifier, [35](#)
Documentation feedback, [121](#)

F

filter, [45](#)

I

if-match, [36](#)
import, [72](#)

N

nest top-most, [45](#)

P

packet-filter, [15](#)
packet-filter default deny, [16](#)
packet-filter filter, [17](#)

Q

qos apply policy (interface view, control plane view), [65](#)
qos apply policy (user profile view), [66](#)
qos apply policy global, [67](#)
qos apply qmprofile, [92](#)
qos bandwidth queue, [87](#)
qos car, [105](#)
qos gts, [77](#)
qos lr, [79](#)
qos map-table, [72](#)
qos policy, [67](#)
qos priority, [74](#)
qos qmprofile, [93](#)
qos sp, [81](#)
qos trust, [74](#)
qos vlan-policy, [68](#)
qos wfq, [87](#)
qos wfq { byte-count | weight }, [88](#)

qos wfq group sp,89
qos wred apply,98
qos wred queue table,99
qos wrr,83
qos wrr { byte-count | weight },84
qos wrr group sp,85
queue,94
queue,100
queue ecn,101
queue weighting-constant,101

R

redirect,46
remark customer-vlan-id,47
remark dot1p,47
remark drop-precedence,48
remark dscp,49
remark ip-precedence,50
remark local-precedence,51
remark qos-local-id,51
remark service-vlan-id,52
Remote support,121

reset acl counter,17
reset packet-filter statistics,18
reset qos car name,106
reset qos policy control-plane,69
reset qos policy global,69
reset qos vlan-policy,70
rule (IPv4 advanced ACL view),19
rule (IPv4 basic ACL view),23
rule (IPv6 advanced ACL view),24
rule (IPv6 basic ACL view),29
rule (Layer 2 ACL view),31
rule comment,32

S

step,33

T

time-range,115
traffic behavior,52
traffic classifier,40

W

Websites,121