

# Product End-of-Life Disassembly Instructions

Marketing Name / Model [List multiple models if applicable.]	Product Category - Servers
Product Name	HP Integrity rx2800 i2
Model:	Rx2800 i2

**Purpose:** The document is intended for use by end-of-life recyclers or treatment facilities. It provides the basic instructions for the disassembly of HP products to remove components and materials requiring selective treatment.

## 1.0 Items Requiring Selective Treatment

1.1 Items listed below are classified as requiring selective treatment.

1.2 Enter the quantity of items contained within the product which require selective treatment in the right column, as applicable.

Item Description	Notes	Quantity of items included in product
Printed Circuit Boards (PCB) or Printed Circuit Assemblies (PCA)	With a surface greater than 10 sq cm	
Batteries	All types including standard alkaline and lithium coin or button style batteries	
Mercury-containing components	For example, mercury in lamps, display backlights, scanner lamps, switches, batteries	
Liquid Crystal Displays (LCD) with a surface greater than 100 sq cm	Includes background illuminated displays with gas discharge lamps	
Cathode Ray Tubes (CRT)	None	
Capacitors / condensers (Containing PCB / PCT)	None	0
Electrolytic Capacitors / Condensers measuring greater than 2.5 cm in diameter or height	None	0
External electrical cables and cords	None	
Gas Discharge Lamps	None	
Plastics containing Brominated Flame Retardants	None	
Components and parts containing toner and ink, including liquids, semi-liquids (gel/paste) and toner	Include the cartridges, print heads, tubes, vent chambers, and service stations.	
Components and waste containing asbestos	None	
Components, parts and materials containing refractory ceramic fibers	None	
Components, parts and materials containing radioactive substances	None	

## 2.0 Tools Required

List the type and size of the tools that would typically be used to disassemble the product to a point where components and materials requiring selective treatment can be removed.

Tool Description	Tool Size (if applicable)
Torx screw driver T10/T5	T10/T5
Description #2	
Description #3	
Description #4	
Description #5	

## 3.0 Product Disassembly Process

3.1 List the basic steps that should typically be followed to remove components and materials requiring selective treatment:


1. Remove cartridges
2. Remove case parts
3. Remove service stations
4. Take out the battery on system by finger.
- 5.
- 6.
- 7.
- 8.
- 9.

3.2 Optional Graphic. If the disassembly process is complex, insert a graphic illustration below to identify the items contained in the product that require selective treatment (with descriptions and arrows identifying locations).

4. Take out the battery on system by finger, see below picture.



# Battery disassembly on system work instruction-1



## Operation:

1. Take out the battery on system by finger.